



'Wadkin' Through Feed Four Side Straightening/ Planing Machine and Moulder

Model GB

INSTRUCTION MANUAL N° 2005



'Wadkin' Through Feed Four Side Straightening/ Planing Machine and Moulder

Model GB

M/C. No.
TEST No.

Instruction Manual

MANUFACTURERS E.C. DECLARATION OF CONFORMITY

The following machine has undergone "Conformity Assessment" and is "self" certificated in accordance with:-

Supply of Machinery (Safety) Regulations 1992
and Amendment No. 2063

COMPANY

WADKIN PLC
Green Lane Road
Leicester LE5 4PF

RESPONSIBLE PERSON

Mr R T Perks (Managing Director)

MACHINE DESCRIPTION

TYPE THROUGH FEED FOUR SIDE STRAIGHTENING
AND PLANING MACHINE AND MOULDER

MODEL GB

DIRECTIVES COMPLIED WITH

Supply of Machinery (Safety) Regulations 1992
Amendment No. 2063 1994
Draught Proposal CEN/TC 142
ISO 9001 Part 1

SIGNED ON BEHALF OF WADKIN PLC



IMPORTANT

SAFETY PROCEDURES AND CONSIDERATIONS

To ensure safe working conditions, persons operating and assisting with the operation of this machine must ensure that they read and fully understand the instructions given within this manual and have received sufficient training in the use of the machine and the safety aspects to be observed.

Note:- Persons under the age of 18 years must not operate the machine except during the course of training under the supervision of a trained operator.

A) POINTS TO NOTE BEFORE OPERATING OR ASSISTING WITH THE OPERATION OF THE MACHINE.

- 1) You have read and understand the operation and safety aspects of the machine and have been checked out by a qualified supervisor.
- 2) The machine is supplied with full safe guarding. The machine shall not be operated unless the safe guardings are in position and are functional.
- 3) Cutters/blades are the correct type, suitable for the machine and working conditions, rotate in the correct direction of cut, are sharp and correctly fitted.
- 4) Correct spindle and speeds are selected for the cutter equipment and working conditions.
- 5) Loose clothing is either removed or securely fastened back and jewellery removed.
- 6) Adequate working space and lighting is provided.
- 7) All dust extraction equipment is switched on, properly adjusted and working adequately.
- 8) The machine is securely installed (refer to installation section within this manual).
- 9) The machine should only be used for cutting wood or materials with physical and technological characteristics similar to wood, and for which the chip or particle removal process is similar.
- 10) Only use tooling that complies with prEN 847-1. Sawblades made of High Speed Steel (HSS) MUST NOT be used.



B) DURING MACHINING:-

- 1) Wear suitable protective clothing e.g, approved eye protection, ear defenders and dust masks. Gloves shall be worn when handling tooling.
- 2) Stop the machine using the emergency stop or at the mains isolator before making adjustments, cleaning or carrying out maintenance.
- 3) Keep the floor area around the machine clean and free from wood refuse. Do not allow the floor around the machine to become slippery.
- 4) Stop the machine and report immediately to a person in authority any actual or potential malfunction or operator hazard. Do not attempt to repair or rectify the machine unless qualified or authorised to do so.
- 5) The operator must not leave the machine running whilst unattended.
- 6) Never by-pass interlocks.

WARNING:-

Failure to observe correct operating procedures prior to and during operation of this machine can result in severe injury.

DO NOT attempt to operate the machine while under the influence of anything that reduces your alertness.

INSTRUCTION MANUAL

WADKIN

THROUGH FEED FOUR SIDE
STRAIGHTENING/PLANING MACHINE
AND MOULDER

MODEL GB

PREFACE

Health and Safety
Safeguarding machines

www.DaltonsWadkin.com

PREFACE

IMPORTANT

IT IS OUR POLICY AND THAT OF OUR SUPPLIERS TO CONSTANTLY REVIEW THE DESIGN AND CAPACITY OF OUR PRODUCTS. WITH THIS IN MIND WE WOULD REMIND OUR CUSTOMERS THAT WHILE THE DIMENSIONS AND PERFORMANCE DATA CONTAINED HEREIN ARE CURRENT AT THE TIME OF GOING TO PRESS, IT IS POSSIBLE THAT DUE TO THE INCORPORATION OF THE LATEST DEVELOPMENTS TO ENHANCE PERFORMANCE, DIMENSIONS AND SUPPLIERS MAY VARY FROM THOSE ILLUSTRATED

Wadkin Leicester

Green Lane Works, Leicester LE5 4PF, England.
Telephone: 0533 769111 Telex: 34646 Wadkin G.
Fax: 0533 742310

HEALTH AND SAFETY

This machine is designed and constructed using the principles of safeguarding and practical guidance contained in the British Standard Codes of Practice BS5304: 1988 "Safeguard of machinery", BS6854: 1987 "Safeguard woodworking machines" and current guidance issued by the Health and Safety Executive.

The Health & Safety at Work etc Act 1974 places duties in designers, manufacturers and suppliers to ensure that:-

- (1) Articles supplied for use at work are, so far as is reasonably practicable, safe and without risks to health during setting, use, cleaning and maintenance.
- (2) Persons supplied with the articles are provided with adequate information about the use for which they are designed, and about conditions necessary to ensure that they will be safe and without risks to health.

These duties are transferred to you if you re-supply the machine by way of sale, lease, hire or hire-purchase.

Persons who install this machine for use at work have a duty under the Health and Safety at Work etc Act 1974, to ensure so far as is reasonably practicable, that nothing about the way in which it is installed makes it unsafe or a risk to health. This includes such aspects as correct assembly, electrical installation, construction of enclosures, fitting of guards and exhaust ventilation equipment. When installing the machine, consideration must be given to the provision of adequate lighting and working space.

The legal duties of designers, manufacturers, importers, suppliers, erectors and installers are explained in the free Health and Safety Executive leaflet IND(G) 1(L) 1987.

The machine is supplied complete with all necessary safeguards to enable the user to comply with the Woodworking Machines Regulations 1974. Details of correct installation and use, together with guidance on fitting and proper adjustment of guards are described in Sections 1 to 4 of this manual.

You are reminded that the Woodworking Machines Regulations place absolute legal duties on employers and employees to ensure that guards and any other safety devices are securely fitted, correctly adjusted and properly maintained.

Repairs and maintenance must only be undertaken by suitably qualified and competent technicians. Ensure that all power supplies are isolated before any maintenance work commences. Instructions for routine maintenance are given in Section 4 of this manual.

Machine operators must have received sufficient training and instruction as to the dangers arising in connection with the machine, the precautions to be observed and the requirements of the Woodworking Machines Regulations which apply, except where they work under the adequate supervision of a person who has a thorough knowledge and experience of the machine and the required safeguards.

Persons under the age of 18 years must successfully complete an approved course of training before operating this machine at work, unless participating in a course of training under adequate supervision. (N.B. This paragraph is only relevant to; circular sawing machines, any sawing machine fitted with a circular blade, any planing machine for surfacing which is not mechanically fed or any vertical spindle moulding machine.)

Before commencing work, ensure that the cutters/blades are, set to cut in the correct direction, securely fitted, sharp, and are compatible with the machine and spindle speed.

Dust

Wood dust can be harmful to health by inhalation and skin contact and concentrations of small dust particles in the air can form an explosive mixture. These concentrations usually occur in dust extraction equipment which may be destroyed unless explosion precautions have been taken in the design and installation of the equipment.

Employees have duties under the Factories Act 1961 and the Health and Safety at Work etc Act 1974 to control wood dust in the workplace and from 1st October 1989 more specific requirements will be imposed by the Control of Substances Hazardous to Health Regulations 1988.

Employers should carry out an adequate assessment of the possible risks to health associated with wood dust to enable a valid decision to be made about the measures necessary to control the dust. It may be necessary to provide effective exhaust appliances.

Prevention or control of wood dust exposure should, so far as is reasonably practicable, be achieved by measures OTHER than the provision of personal protective equipment.

Airborne dust levels should not exceed 5 mg/cub.m

Further information and reference to practical guidance are contained in the following free leaflets available from the Health and Safety Executive:-

Wood Dust: IND(S) 10(L) 1987
 Hazards and Precautions
 Control Hardwood Dust IND(S) 21(L) 1988

Noise

Noise levels can vary widely from machine to machine depending on conditions of use. Persons exposed to high noise levels, even for a short time, may experience temporary partial hearing loss and continuous exposure to high levels can result in permanent hearing damage. The Woodworking Machines Regulations require employers to take reasonably practicable measures to reduce noise levels where any person is likely to be exposed to a continuous equivalent noise level of 90 dB(A) or more, over an 8 hour working day. Additionally, suitable ear protectors must be provided, maintained and worn.

An adequate assessment of likely noise exposure should be made using manufacturer's data and if necessary, a noise survey should be carried out by a competent person. It may be necessary to construct a suitable noise enclosure, in which case professional advice should be sought.

Machines identified as generating unhealthy noise levels should be appropriately marked with a warning of the need to wear hearing protection and it may be necessary to designate particular areas of the workplace as "Ear protection zones". Suitable warning signs are specified in the Safety Signs Regulations 1980.

Further information and reference are contained in the free Health and Safety Executive leaflet - Noise at Woodworking Machines IND(S) 22(L) 1988.

SAFEGUARDING MACHINES

To comply with the Woodworking Machines Regulations 1974, operators must ensure that they fully understand the instructions given and have received sufficient training in the use of the machine and the particular safety instructions to be observed.

NOTE: Persons under the age of 18 years **must not** operate the machine except under supervision during a course of training.

BEFORE OPERATING THE MACHINE ENSURE THAT:

All guards and fences are securely fitted and correctly adjusted in accordance with the Regulations. Cutters/blades are the correct type and rotate in correct direction of cut, are sharp and securely fastened.

Correct spindle speed is selected for the cutter equipment.

Loose clothing is either removed or fastened and jewellery removed.

Suitable jigs and push sticks are available as appropriate.

Sufficient working space is provided and that lighting is adequate.

All dust extraction equipment is switched on, properly adjusted and working efficiently.

DURING MACHINING:

Wear suitable protective equipment, e.g. goggles, ear defenders, and dust mask.

Stop the machine before making adjustments or cleaning chips from the work area.

Keep the floor area around the machine clean and free from wood refuse.

Do not allow the floor to become slippery with oil or grease.

Report immediately to a person in authority, any machine malfunction or operator hazard. Do not attempt to repair the machine unless qualified to do so.

Ensure all power sources are isolated before commencing any maintenance work.

WARNING: Failure to comply with the Regulations is a criminal offence and could result in legal proceedings.

SECTION 1 GENERAL DESCRIPTION

Operating Practice

- General notes
- Machine feed systems
- Noise
- Common operating problems

Leading Particulars

- Principal dimensions and capacities
- Output of motors

SECTION 2 INSTALLATION

Lifting and Transportation

- Unloading
- Moving
- Unpacking
- Cleaning

Installation Data

- Major dimensions and weight
- Location and foundations
- Supplies and services



CONTENTS

SECTION 3 OPERATING INSTRUCTIONS

General Information

- Safety
- Safety devices
- Warnings
- Machine controls

Mounting the Cutterblocks

- General
- First bottom head
- Fence side head
- Near side head
- Top head
- Second bottom head
- Universal head

Setting up the Machine

- Set infeed table
- Set feed rolls
- Check/adjust fence side head
- Check/adjust near side head
- Check/adjust top and second bottom head
- Check/adjust universal head
- Final adjustments and settings
- Universal head modes
- Reversing switch
- In bottom horizontal mode
- In top horizontal mode
- In near side vertical mode

Dial-a-Size Electronic Positioning

- Near Side and Top Head
- Method of operation and setting

Faults in the Workpieces and their Causes

- General
- Faults caused by Tools
- Faults in Grinding and Setting

Cleaning the Machine

SECTION 4 MAINTENANCE

Scheduled Maintenance

- Lubrication
- Chain drive tensioning
- Vee-belt drive tensioning
- Cleaning

Unscheduled Maintenance

- Changing cutterblock spindle bearings
- Preparation prior to fitting bearings
- Replacing drive belts
- Removal and refit of drive pulleys
- Variable speed pulleys
- Cutters and tool holders
- Shaft drive system

Fault Finding

- Mechanical faults
- Elimination of Vibration
- Electrical faults

Tables

- Approved lubricants
- Motor/drive-belt data

SECTION 5 ILLUSTRATED PARTS LIST

- Bedplate charts
- Bottom heads
- Fence side head unit adjusting mechanism
- Top head — including power rise and fall
- Bottom (excluding First) and top heads axial adjustment
- Universal head adjusting mechanism
- Bottom top and universal head spindle unit
- Fence and near side head spindle unit
- Top head chipbreaker pressure pad and extraction hood
- Near side head chip breaker and extraction hood
- Simplabelt variable speed drive unit
- Drive to chain driven feedworks
- Feed rolls drive chains tensioning
- Feed roll unit chain drive (double swing)
- Shaft drives
- Drive gearboxes and bottom roll drive
- Fences guides and guards — standard machine
- Fences
- Bedplates, fences and guides — universal head
- Single side roller pressure unit
- Double side roller pressure unit
- Top roller pressure unit
- Mounting for top pad or roller pressure unit



CONTENTS

SECTION 6 APPENDICES

Appendix A Dial-a-size

- Dial-a-size Electronic Positioning
- Method of operation
- Setting up

Appendix B 99 Setting Programmable Memory Positioning

- Near Side and Top Head
- Setting
- Method of operation

www.DaltonsWadkin.com

Section 1

- Fig 1 Main view of machine
Figs Operating practice (in text)

Section 2

- Fig 1 Lifting the machine

Section 3

- Fig 1/1 Control panel
Fig 1/2 Machine controls — general view
Fig 2/1 First bottom head
Fig 2/2 Hand controls — first bottom head
Fig 2/3 First bottom head
Fig 3/1 Fence side head
Fig 3/2 Hand controls — fence side head
Fig 4/1 Near side head
Fig 4/2 Hand controls — near side head
Fig 5/1 Top head
Fig 5/2 Hand controls top head
Fig 6/1 Second bottom head
Fig 6/2 Hand controls second bottom head
Fig 7 Universal head spindle
Fig 8 Infeed table setting
Fig 9/1 Feed rolls setting
Fig 9/2 Feed rolls spacer detail
Fig 10 Fence side head setting
Fig 11 Nearside head and chipbreaker
Fig 12 Top and second bottom head setting
Fig 13 Final adjustments and settings
Fig 14 Universal head attachment
Fig 15 Universal head modes
Fig 16 Universal head — top horizontal mode
Fig 17 Dial-a-Size control panel

Section 4

- Fig 1 Chain drive tensioning — feedworks
Fig 2 Chain drive tensioning — feed rolls
Fig 3 Veebelt drive tensioning
Fig 4 Spindle unit bearing assembly
Fig 5 Removing a taper-lock bush
Fig 6 Simlabeled variable speed drive unit

Section 5

- Fig 1 Bedplate charts
Fig 2 Bottom heads
Fig 3 Fence side head unit adjusting mechanism
Fig 4 Top head — including power rise and fall
Fig 5 Bottom (excluding First) and top heads axial adjustment
Fig 6 Universal head adjusting mechanism
Fig 7 Bottom top and universal head spindle unit
Fig 8 Fence and near side head spindle unit
Fig 9 Top head chipbreaker pressure pad and extraction hood
Fig 10 Near side head chip breaker and extraction hood
Fig 11 Simlabeled variable speed drive unit
Fig 12 Drive to chain driven feedworks



LIST OF ILLUSTRATIONS

Section 5 (cont.)

- Fig 13 Feed rolls drive chains tensioning
- Fig 14 Feed roll unit chain drive (double swing)
- Fig 15 Shaft drives
- Fig 16 Drive gearboxes and bottom roll drive
- Fig 17 Fences guides and guards — standard machine
- Fig 17a Fences
- Fig 18 Bedplates, fences and guides — universal head
- Fig 19 Single side roller pressure unit
- Fig 20 Double side roller pressure unit
- Fig 21 Top roller pressure unit
- Fig 22 Mounting for top pad or roller pressure unit

Section 6

- Fig 1 Dial-a-Size control panel
- Fig 2 Control panel

www.DaltonsWadkin.com


SECTION 1 GENERAL DESCRIPTION

OPERATING PRACTICE

General Notes on Wadkin Planing and Moulding Machines

A planing and moulding machine produces planed or moulded surfaces on all four sides of lengths of timber, both hard and softwood, at feed speeds determined by the cutter equipment and quality of surface finish required.

A series of 'ridges' (cutter marks) is created on the surface of the timber as it is moved past a rotating cutterblock (see Fig 1). The quality of surface finish is determined by the number of knife marks per 25mm (1") (the pitch of the cutter marks). The closer the pitch the better the quality of surface finish.




From experience a good quality surface finish has knife marks at a pitch of 1.5 to 2 mm. Reducing the pitch improves the surface finish but increases the wear on the cutters, increasing the pitch reduces the quality.

The number of cutter knives in a cutterblock will only be effective when all are rotating in precisely the same cutting circle. Two main factors influence this:


- The fit of the cutterblock on the spindle
- The concentricity of grinding.

The conventional method of mounting a cutterblock is to lock a plain bore block on to a plain ground spindle with a locknut. The tolerances in each component give a possible 0.05mm (0.002") clearance in the bore and thus eccentric running (see Fig 2).



The Wadkin Hydrofix locking system eliminates this clearance by pressurising the bore of the cutterblock onto the spindle (see Fig 3).

Axial locking is not required and a simple safety collar is recommended to prevent the cutterblock moving axially, or rotating on the spindle, if the hydraulic pressure is not applied.




Because the Hydrofix locking is also used while the knives in the cutterblock are ground in the toolroom, it can be seen that the high accuracy of the grinding process is transferred directly to the planing and moulding machine. This accuracy, together with the true running of the precision spindle of the moulder, reduces the running of the knives to within 0.002 to 0.005mm of the true cutting circle. However, this minimum run-out is still such that only one knife leaves a finishing cut, no matter how many are in the block.

SECTION 1

OPERATING PRACTICE

To ensure that all the knives in a cutterblock run in an absolutely true cutting circle, the technique of jointing is used, in which the jointing 'stone' trues all the knives while rotating at cutting speed in the planing and moulding machine (see Fig 4).



It can be seen that for a given spindle speed and quality of surface finish (pitch of knife marks), the feed speed may be increased in direct relationship to the number of knives in the cutterblock.

$$\text{Cuttermark pitch} = \frac{\text{Feedspeed in mm per min}}{\text{Block rpm} \times \text{No of Cutters}}$$


For example $\frac{12 \times 1000}{6000 \times 1} = 2\text{m pitch}$

for a spindle running at 6000 rpm and a feed speed of 12m/min and unjointed (1 knife finishing)

Jointing a 4 knife block and increasing the feed speed to (4×12) ie: 48m/min gives the same resulting pitch (finish).

Jointing can be carried out on straight planing blocks — 'straight' jointing, and on profile blocks — 'plunge' jointing.

The process of jointing, which can be repeated several times, produces a heel on the knives. In the interests of quality this must not be allowed to exceed a certain width. This is approx 0.5mm on softwood and 0.7mm on hardwood (see Fig 5).



Both high speed steel and carbide knives may be jointed but require a different composition of jointing stone.

An alternative method of increasing output is to increase the spindle speed thus permitting a faster feed speed for a given quality of surface finish. 'Wadkin' can offer alternative spindle speeds up to a maximum of 15000 rpm. This highest spindle speed, achieved with very high precision, lubricated for life bearings, permits a $2\frac{1}{2} \times$ (250%) increase in output without jointing.


Typical surface finish pitch values for different applications are listed:

Sawmilling	1.5 to 2.5 mm
Joinery	1.5 to 2 mm
Strip moulding	1.3 to 2.0 mm
Furniture	1 to 1.5 mm

Machine Feed Systems

Push Feed (Fig 6)

This original method of feeding a planing and moulding machine is still provided, and consists of two top driven and two opposed bottom driven feed rolls at the infeed end of the machine. An idle roller and pad pressures between the cutterheads controls the timber down to the bed and across to the fence as it passes through the machine. It follows that if bowed or twisted stock is fed to the cutters, that while a perfect profile will be produced, the component will be as twisted or bowed as it entered.




The pushfeed machine has the disadvantage that the last piece of timber is always left in the machine; traction stops as the trailing end leaves the feedworks. The last piece can only be retrieved by following with a scrap length or by reverse feeding, in which case the component is unfinished.


Through feed (Fig. 7)

Through feed was developed to overcome the handicap of the last piece remaining in cut, and to eliminate the heavy top and side pressures.


Drive rolls between each cutterhead feed the components through the machine.



A long infeed table before the first bottom head, together with the much lighter loading on the timber, enables straightening of the component ie: the underside being straightened (surfaced) at the first bottom head, and the edge (fence side) being straightened at the first side head (see Fig 8).




An alternative method of straightening combines underside and fence side straightening, using a single cutterblock, planing the underside in the normal way and machining a reference edge with a rebating disc on the same block (see Fig 9).



The above straightening techniques are most successful on timber which is bowed and has square ends, typical of softwood. For timber which is twisted and has out-of-square ends, typical of some hardwoods, an alternative technique is provided.


Grooved bed straightening (Fig 10)

In this design, grooving cutters on the first bottom head permit support in the form of rails right through the cut, thus preventing 'dipping in' of the twisted timber, or 'buckling' as out-of-square ends come into contact with each other. The grooves on the underside are subsequently machined out on a second bottom head, which is obligatory. Fitting a standard lip plate and cutterblock converts the machine to conventional use.



Hopper Feeding (Fig 11)

To enable the operator to feed timber at relatively fast feed speeds and still maintain butt up, (this may be difficult on short lengths), various types of hopper feed are available.



SECTION 1

OPERATING PRACTICE

Components are stacked in a hopper at the infeed end of the machine and automatically fed one at a time from the bottom of the stack at a rate to ensure 'butt-up'. A slipping device prevents the hopper feed trying to overdrive the machine feed.

Feeding at very high feed speeds, typically on flooring, cladding etc, also presents problems to the operator, again a special feeding device. (Fast feed table, Fig 12) can be provided.

The fast feed table, in line with the machine feed, receives timber from a tilt hoist and cross chains, the driven rollers in the fast feed table and an overhead hydraulically driven nip roll ensure butt up before entry into the machine feedworks, a slipping arrangement prevents overdriving.




FIG 12

Outfeed Equipment

Generally used on high feed speed machines, this equipment can be provided at the outfeed end of 'Wadkin' moulders to transfer to another process, ie: stack, bundle, wrap, count, etc. Outfeed equipment can be provided and programmed to print on each component some identifying information. eg. Job No. Date, etc. Combinations of these facilities enable the finished components to be presented in a variety of ways at the outfeed end of the machine.

Extra Head Positions

Typically a planing and moulding machine has four heads to machine all four faces, these can be augmented with the addition of other heads. The most common is a second bottom head to ensure clean up on the underside. Where the amount of timber to be removed is great, or where the mould detail is complex, it

may be necessary to provide extra top side or bottom heads. These are available on both push and through feed machines.

Splitting (Fig 13)

Splitting is a common operation, usually done on the last bottom head, and often requiring very large horse powers. Such a head is available and may be fitted with anti kick-back fingers to prevent ejection towards the operator.




FIG 13

Universal Head

A universal head, either three or four position (always last head on the machine) can be provided to order, or the machine prepared to fit the head at a later date. The three position head may be used as a top head, bottom head or near side head and at any angular position in between. The four position head has the added capability of use as a fence side head.

The universal head gives greater flexibility for splitting and moulding on a conventional machine, and special pressures, chipbreakers, etc. can be provided to ensure perfect control of the workpiece.

Dial-a-Size Positioning (Fig 14)

On machines which are used for a large variety of small quantity batches of square dressed




FIG 14

material, the set up time can be reduced by fitting Dial-a-size positioning (see Fig 17 in Operating Instructions).

The near side head horizontal adjustment is motorised and fitted with an encoder, the motorised vertical movement of the top head and feed is also fitted with an encoder.

A programmable memory stores the widths and thicknesses of the workpieces to be produced, and on command the two heads are repositioned to the preset dimensions. In a similar manner, where components of random width are machined (eg. Table tops, see Fig 15). The machine can be arranged to sense the width of the incoming pieces and automatically move the outside head to the required position.

Whilst being a slow operation, (butt feeding is not possible and the feed speed is slow), the facility does have great advantage to some users.




FIG 15

Feed Enhancement

The 'Wadkin' push feed and through feed systems are the result of years of experience in the planing and moulding industry, and for the great majority of work are exemplary. However, the great variety of timbers available, and the different conditions in which they are presented to the machine is acknowledged in the various options available to enhance feeding and minimise bed wear.

Bed Lubrication

A lubricant is introduced to the surface of the machine bed, from a manual or auto pump; this reduces friction, improves feeding capability and reduces bed wear.

An alternative; of introducing air between the timber and the bed of the machine, can be provided for those machines that do not have a second bottom head to machine off the small amount of oil introduced to the underside of

the timber, or where the material being machined must not in any circumstances be contaminated with oil.

A hard chrome plated bed is also available. This is usually used on high feed speed machines or where particularly abrasive timber is being machined. The reduction in bed wear is very considerable, and feeding is improved because of the low coefficient of friction of chrome plating.

The top driven feed rolls of a through feed moulder are normally spring loaded down onto the workpiece. The required amount of load can vary with the nature of the work being run, although as a general rule it must be as light as practicable, and variation in rough timber thickness will of course increase the load as the feed rolls yield more. Adjustment of the loading is done at each individual roll.

Pneumatic loading can be provided; this has a number of advantages. The loading does not vary with any variation in lift, and the amount of loading can be changed more easily.

One regulator controls the loading to rolls before the top head, and the other regulator controls the rolls after the top head.

Noise



Planing and moulding machines, by virtue of the number of cutter heads and the speed of the heads, produce high noise levels, typically between 95dB and 115dB when cutting.

The woodworking machine regulations require that an operator is not to be subjected to noise levels above 90 dBA for 8 hours, some precautions are therefore required.

The manufacturers can supply (or give information about suppliers) a suitable sound enclosure. It is also possible with materials generally available in a sawmill, to make an enclosure on site. It should be noted however that even with a sound enclosure, under some circumstances, because of 'break out' (at say the infeed end), the noise level at the operating positions will be above 90 dBA.

For personal safety reasons the operator should wear ear defenders.

See **WARNINGS** in Operating Instructions before operating the machine.

SECTION 1

OPERATING PRACTICE

LEADING PARTICULARS

Principal Dimensions and Capacities

Maximum size of timber admitted	230mmx130mm
Maximum size of finished work	220mmx120mm thick
Feed speed infinitely variable	6.0 to 20 metres per min.
Pressure adjustment of Feed Rolls	6 bar (reduced)
Limit switch at the extremities of the Rise and Fall beam	
Feed Rolls	140mm dia. 2x20mm + 1x10mm wide rolls to each position (50mm max width)
Diameter of Cutter Spindles	40mm
Speed of Cutter Spindles	6000 rpm
Diameter of Cutterblocks	Minimum: 100mm all heads. Maximum: 180mm First bottom and Universal heads. 195mm sides, Top and Second Bottom heads (where fitted)
Maximum straightening	10mm
Maximum cut of First Bottom Horizontal head	10mm
Maximum cut of Fence Side Vertical head	10mm
Length of Infeed table	2 metres

Output of Motors

Feed motor	2.2kW (3hp)
Rise and Fall motor	0.37kW (0.5hp)

Spindle motors

GB 220 and SUPER GB 220	OPTION
1st Bottom Head	4 kW (5.5hp) 5.5kW (7.5hp)
Fence Side Head	7.5kW (10hp)
Near Side Head	5.5kW (7.5hp) 7.5kW (10hp)
Top Head	

GB 220M and SUPER GB 220M	OPTION
1st Bottom Head	4 kW (5.5hp) 5.5kW (7.5hp)
Fence Side Head	7.5kW (10hp)
Near Side Head	5.5kW (7.5hp) 7.5kW (10hp)
Top Head	7.5kW (10hp)

UNIVERSAL HEAD ATTACHMENT

Universal Head	5.5kW (7.5hp)
----------------	---------------

Common Operating Problems

When resolving problems, always work in a systematic logical sequence. Work from the infeed end of the machine through to the outfeed end, checking for faults in a progressive manner.

In this way faults will not be overlooked and remedial action can be taken where needed.

Set (spring loaded) top/side pad pressures with minimum amount of lift. Set side guides (not spring loaded) just up to timber ie: not clear, not trapping. When feeding wide pieces, on a through feed machine it is normally better to space feed rollers than have a solid bank (see Fig 9/2).

FAULT Timber stops in machine

Check

Setting of cutterblocks to table and fences.
Amount of pressure applied to feedrolls (pneumatic or spring)
Sharpness of cutters.
Yield of chipbreakers and pad pressures.
Tightness of side guides onto timber.
Oil level of bed lubrication pump (if fitted).
Size of joint on cutting edges (if fitted).
Position of feedrolls on workpiece.

FAULT Ripples appear on surface of workpiece

Check

Setting of cutterblocks to table or fences.
Pressure is applied to feedrolls (pneumatic or spring)
Sharpness of cutters.
Chipbreakers are set correctly and have sufficient pressure to control timber.
All locks are applied.
All pressure pads are in contact with timber.
Spindle speed (if two speed spindle fitted)
Tooling is suitable for the work.

FAULT Bumps on infeed or outfeed end of workpieces

Check

Setting of cutterblocks to table and fences.
Sharpness of cutters.
Chipbreakers are set correctly and have sufficient pressure to control timber.
All locks are applied.
All pressure pads are in contact with timber.
Position of side and top pressure rollers.
Bed and fences for build up of resin or chips.

FAULT Machine will not straighten timber

Check

Setting of cutterblocks to table and fences (accurate setting of knife edge to table/fence is critical to obtain perfect straightening).
Sharpness of cutters.
Feed rollers and top/side pressures should not be used before the first bottom head.
Is the amount of cut set at the infeed fence and table adequate for the amount of bow in the timber?
Is the timber to be straightened a stable section?
Is the workpiece within the length of the straightening table and fence?



SECTION 1

OPERATING PRACTICE

FAULT Timber runs away from fence**Check**

Position of side pressure roller before first bottom head (if fitted, and section being worked does not require straightening).

Near side head chipbreaker is in contact with timber.

Top idle roller pressures at side heads are parallel to fence.

Side guides after fence sidehead are adjusted correctly.

Mating faces of feed rolls and spacers are clean.

Tooling

Contrary to what would appear, it is not always wise to have the maximum number of knives in a cutterblock, particularly when running unjointed. eg: it is more expensive in horse power to run four knives than two.

When practicable, and heads are available, rough on one head and finish on another, or take part of a mould out on one head and the second part on another. Each subsequent joint on a knife increases the width of land. Overjointing (too wide a land) causes hammering, produces raised grain, and uses more power.

SECTION 2 INSTALLATION

LIFTING AND TRANSPORTATION

Unloading (Fig 1)

Verify the weight of the machine (see **Installation Data**). Ensure that all lifting equipment used is capable of lifting this weight as a minimum.

To lift the machine, place two 45mm diameter steel rods 1.2 metres long in the holes provided in the machine body (see Figure 1). To gain access to one of the holes it will be necessary to remove the cover (identified) from the rear of the machine.

Carefully place two short slings of suitable capacity on the crane hook. Keep these as wide apart as possible by inserting wooden chocks between the machine body and the slings to avoid damage. Locate the slings securely on the steel rods.

THE MACHINE IS DELIVERED WITH THE LARGE SAFETY COVER REMOVED, THIS MUST BE REFITTED BEFORE OPERATING ANY DRIVE OR CUTTER.



Moving

In the process of moving, avoid jolting or vibrating the machine. If the ground is flat the machine can be positioned on wooden plinths and moved by rollers instead of lifting.

IMPORTANT: When lifting, the machine has a tendency to tilt backwards (towards the electric motors and the motor mounting brackets). Allowance should be made for this in positioning.

Unpacking

Undo the packing and make sure that damage has not occurred during transit; undo the case of accessories and ascertain that the machine is complete with all fittings.




FIG 1 LIFTING THE MACHINE

Cleaning

Before levelling the machine, carefully remove the anti-rust material particularly from the bright parts.

Clean the machine with paraffin or diesel and a soft rag. Do not use a substitute – it may precipitate an explosion.

SECTION 2

INSTALLATION

INSTALLATION DATA

Major Dimensions and Weight*Overall Dimensions and Weights:*

Four Head machine	with Universal Head
Length: 3700mm	4400mm
Width: 1600mm	1600mm
Height: 1600mm	1600mm
Weight: 2686kg	3296kg

Location and Foundations

To obtain the best results from the 'Wadkin' woodworking machine it is important that the floor on which the machine is to stand has been prepared and is dry. Level the machine from the middle of the bed between the adjustable screw supports by the use of a spirit level. Place the steel plates supplied with the machine under the adjustable levelling screws.

Suggested levelling aids:

Straightedge 2 metres long
 Feelers (thickness gauges) 0.50, 0.10, 0.15 and 0.2mm
 Engineer's spirit level
 Rule 1 metre long, 0.2 mm graduations

Levelling longitudinally

Place the spirit level on the table and moving the level lengthwise check any variation. Adjust machine level by use of the adjustment screws in the feet of the machine. Deviation should not be more than 0.2 mm.

The straightening table (ie: table before the First Bottom Head), should be in line with the table after the First Bottom Head. Maximum tolerance is 0.1mm in 1600mm.

Levelling transversely

Place the spirit level across the table at right angles to the fence and repeat this action at intervals of 800mm. Total variation at each position should not exceed 0.1mm.

The foundations

The size of the foundations depends upon the specific machine model, format of the heads and disposition of the exhaust outlets and will be provided for individual machines.

If the floor consists of 100mm-150mm (4 to 6 inches) solid concrete, no special foundation is necessary. M12 'HILTI' type holding down bolts (not supplied with the machine) can be used to secure the machine to the floor.

NOTE: THE MACHINE MUST BE BOLTED DOWN BEFORE USE

See Foundation Plan for details of floor area required.

Supplies and Services*Electrical Supply*

The customer is responsible for an adequate electrical supply. Details of power requirements are provided with the machine.

The machine is delivered with its complete electrical equipment ready for connection.

The electrical connection and schematic diagram are found in the electrical control cubicle of the machine. All that is required is to connect the power supply to the disconnect (Isolator) switch at the electrical control cubicle or panel.

POINTS TO NOTE WHEN CONNECTING THE POWER SUPPLY

Check the voltage, phase and frequency correspond with those on the machine nameplate details.

Check the main fuses are of the correct capacity in accordance with the machine nameplate details.

Connect the incoming supply leads to the appropriate terminals.

Check all connections are sound and that equipment is earthed.

Check the spindle rotation is correct. When looking from the front of the machine the feed rolls should rotate in a clockwise direction. To reverse the rotation on any drive, reverse any two of the line lead connections at the incoming supply.

IMPORTANT: ANY ELECTRICAL MODIFICATIONS SHOULD BE CARRIED OUT BY A COMPETANT ELECTRICIAN.

Pneumatic pressure equipment (where fitted).

Where the machine is equipped with pneumatic pressure operated feedrolls, the number of connections are shown on the pneumatic circuit diagram and foundation plan. To make the system operative connect up the air pipes and fittings to a suitable air supply.

The size of the air inlet connection is 1/4in. BSP female.

The size of the air pipe is 8mm O.D. x 5mm I.D.

Pressure required is 6 bar (approx. 90 psi), see **Operating Instructions** for feedroll pressures.

The air consumption is approximately 200 cu.dm/hr (7cu.feet/hr).

Exhaust (Dust Extraction) Connections

The size of the connections are given on the Foundation and Dust Extraction Plan.

The part of the air extraction pipe fitted to the exhaust hood should be flexible and detachable. The length of the flexible part is dependant on the way the pipe is used and the adjustment required on the work spindle. As a guide use a flexible pipe one metre long for the lower and fence side spindles and two metres for the top and near side spindles.

The flow of air to the exhaust hoods should be approximately 25 to 30 metres per second.

Volume of Air Required

For Horizontal/Vertical Spindles	17-20 cu. metres/min. (600-700 cu.ft/min)
For Universal Spindle	17-20 cu. metres/min. (600-700 cu.ft/min.)

The total volume of air required for the Dust Extraction is directly related to the total number of spindles.

Schematic Diagram for Electrical Services

The electrical wiring and schematic diagram will be in the electrical control cubicle of the machine.

SECTION 3 OPERATING INSTRUCTIONS

GENERAL INFORMATION

Safety

The safe operation of woodworking machinery requires constant alertness and close attention to the work in hand.

Read this instruction manual, the Preface, and the Safety Notes carefully before operating the machine.

Blunt cutters often contribute to accidents. An efficient machinist knows when sharpening is necessary, but if there is reluctance to spend time on grinding and resetting, the cutters may run beyond their efficient limits and instead of cutting efficiently and smoothly they will tend to chop and snatch at the workpiece. This not only increases the risk of accidents but also lowers the quality of work.

Customers are strongly advised at all times to use high tensile cutterblock bolts which should be tensioned by means of a torque spanner. When choosing cutterblocks ensure they are suitable for the minimum cutting speed of the machine.

It is recommended that personnel involved with the machine are acquainted with the Woodworking Machines Regulations 1974 and also Booklet No. 41 'Safety in the use of woodworking machines', issued by the Department of Employment and available from Her Majesty's Stationery Office. Also BSI Code of Practice 'Safeguarding Woodworking Machines' Part 1 BS 6854.

Safety Devices

The safety covers and dust hoods must be closed during the time the machine is running. Cover the non-used part of the cutterblocks with the guards provided.

Only remove the feed roller guard when changing rollers and with spindles switched off at the control panel.

Spindles which are run in two directions (ie:

Universal Head), should be fitted with a locking collar to prevent unforeseen unlocking on mode changeover.

Do not work spindles if the spindle nuts or intermediate collars are not securely tightened.

Only remove the cover of the drive belt housing when changing or retensioning belts. The drive spindle must be stationary before making any adjustments.

WARNINGS

Notice to Operators

Read and follow the guidelines given in **Safeguarding Machines** and **Safety Notes** which are repeated on the bed of the machine.

Before operating the machine

Ensure that all guards and fences are securely fitted and correctly adjusted. Guards and other safety devices are NOT to be removed while the machine is in operation. They are there for YOUR SAFETY.

Ensure cutters/blades are the correct type and rotate in correct direction of cut, are sharp and securely fastened.

Correct spindle speed and feed is selected for the cutter equipment.

Remove or fasten loose clothing; confine long hair and remove jewellery, etc.

Ensure suitable jigs and push sticks are available as appropriate.

Ensure sufficient working space is provided and that lighting is adequate.

Switch on all dust extraction equipment, ensure it is working correctly.

SECTION 3

OPERATING INSTRUCTIONS

Machine Controls (Fig 1/1, Fig 1/2)

Before starting the machine, operators should familiarise themselves with the various controls and their usage (Fig 1/1).

Check direction of spindle rotation, ensuring that the spindles rotate freely. Check each spindle motor separately.

Check the infeed table raise and lower operation.

The machine has continuous feedworks. When started, timber stock will be fed to the cutter heads until the pass is completed or the machine is stopped. The feed speed is variable and can be adjusted by a handwheel at the drive gearbox to give throughput speeds between 6 and 20 metres a minute. **Only adjust the variable speed drive while in motion.**

The feed rolls have serrated teeth up to the top cutter head after which they are rubber covered. The serrated rolls need to be adjusted to 5mm lower than the thinnest workpiece; the rubber covered rolls should be adjusted to 3mm lower than the workpiece.

The height of the feed roll adjustment is indicated by the graduated scale on the vertical pillar adjacent to the feed table. Adjustment of

the feed rolls is made by pressing the pushbuttons marked:



— raise feed rolls

— lower feed rolls

The pushbuttons are positioned on the Electrical Control Panel located at the infeed end of the machine and also at the control station located at the outfeed end of the machine.

The adjustment for height of the rubber covered (plain) rolls may be made independently to suit the finished workpiece.

The panel mounted control station at the infeed end of the machine contains the following features:

- START-STOP Pushbutton;
with indicator light, for each spindle.
- START-STOP Feed Pushbutton;
with indicator light.
- FORWARD-REVERSE
(Inch) Feed Pushbuttons.
- RAISE-LOWER Pushbuttons;
for beam adjustment.
- MASTER STOP (Emergency) Button.
- REVERSING Switch;
for Universal Head operation.




FIG 1/1 CONTROL PANEL

MOUNTING THE CUTTERBLOCKS

General

To change cutterblocks, remove dust hood covers and unscrew the cutterblock nut from the spindle with the combination spanner supplied with the machine.

- (1) Place the combination spanner on the hexagon of the spindle and on the two flat faces of the cutterblock locknut.
- (2) Hold the spanner (top) securing the spindle firmly in position and unscrew the cutterblock locknut with the bottom spanner.

NOTE: Spindles have right or lefthand threads as follows:

- Bottom Horizontal spindle — left-hand thread
- Near Side Vertical spindle — left-hand thread
- Top Horizontal spindle — right-hand thread
- Fence Side Vertical spindle — right-hand thread

DO NOT use any form of percussion tool on the cutter heads, damage to spindle bearings can result. **DO NOT** use a boxspanner or an extension spanner.

- (3) Carefully clean the spindles, cutterblocks, sleeves and any intermediate spacers before refitting.

WARNING

Ensure that a locking collar is fitted to the Universal Head spindle.


- (4) After fitting, turn the spindle by hand to ensure the cutterblock is free. Close the cover.
- (5) Operate the spindle for a short period to ensure it rotates freely and without vibration.

CAUTION

On vertical spindles take care not to allow the cutter block to fall onto the spindle shoulder while fitting. This can cause damage and subsequent vibration.

First Bottom Head (Fig 2/1, Fig 2/2, Fig 2/3)

- (1) Remove guard for access, remove existing cutterblock as follows:
 - a. Release cutterblock (1) using the combination spanner provided on the spindle hexagon (2) and the two flat faces of the cutterblock locknut (3).
 - b. Withdraw cutterblock from spindle.
- (2) Check that the spindle (4), flange (5) and the flange end of the replacement cutterblock are clean.



- (3) Slide the new cutterblock (1) onto the spindle (4) and tighten using the combination spanner provided.

NOTE: Do not use excess force.

- (4) Ensure the outfeed table (6) is clean.
- (5) Place a straightedge (7) on the outfeed table projecting over the bottom horizontal cut.

SECTION 3

OPERATING INSTRUCTIONS

terblock (1). The cutter blades should just touch the underside of the straightedge. If necessary, reset the cutter height as follows:

- a. Release locking handle (8) and adjust the cutterblock height by rotating the handwheel (9) clockwise to raise the spindle, or anticlockwise to lower.
- b. Refasten the locking handle (8).




FIG 2/2 HAND CONTROLS —
FIRST BOTTOM HEAD

- (6) Place the straightedge (7) against the out-feed fence guide (10) and check that the cutter flange (11) is in line with the guide (ie; just touching the straightedge). If necessary, adjust the cutterblock laterally as follows:

- a. Release the hexagon nut (12) on the bottom head vertical slide casting at the rear of the machine and rotate the spindle adjuster as required.
- b. Retighten the hexagon nut (12).

Fence Side Head (Fig 3/1, Fig 3/2).

- (1) Ensure that the machine bed is clean.
- (2) Set the fence guide (1) with a straightedge (2) against the fence guide and cutters (3) in




FIG 2/3 FIRST BOTTOM HEAD

a similar manner to that used for the First Bottom Head. If necessary adjust the spindle laterally as follows:

- a. Release the locking handle (4).
- b. Rotate the handwheel (5) clockwise to advance the spindle or anticlockwise to retract the spindle.
- c. Refasten the locking handle (4).

NOTE: Maximum lateral adjustment is 65mm.




FIG 3/1 FENCE SIDE HEAD

- (3) Set the axial position (height) of the cutterblock (6) as follows:
 - a. Release the locking handle (7) and adjust the cutter height by rotating the handwheel (8) anticlockwise to lower the spindle or clockwise to raise the spindle.
 - b. Refasten the locking handle (7).




FIG 3/2 HAND CONTROLS —
FENCE SIDE HEAD

Near Side Head (Fig 4/1, Fig 4/2)

- (1) Ensure that the machine bed is clean.
- (2) Check the digital readout, using a datum block (1) of known width inserted between the fence guide (2) and cutter (3). The cutterblades should just touch the near side of the datum block. If necessary, reposition as follows:




FIG 4/1 NEAR SIDE HEAD

- a. Release locking handle (5).
- b. Rotate handwheel (6) clockwise to advance the spindle or anticlockwise to retract the spindle.
- c. Refasten locking handle (5).
- d. Reset digital readout, where fitted, to the known dimension.




FIG 4/2 HAND CONTROLS —
NEAR SIDE HEAD

- (3) Set the chipbreaker (7) as follows:
 - a. Remove the cover of the dusthood.
 - b. Release the locking handle (8)
 - c. Adjust the chipbreaker (7) so that it clears the smallest cutting circle by approximately 2mm (Fig 4/1).
 - d. Refasten the locking handle (8).
 - e. Unscrew the bolts (9) and adjust the chipbreaker (7) to suit the cutterblock diameter so that it clears the cutterblock by 20mm (Fig 4/1).
 - f. Retighten the bolts (9).

Top Head (Fig 5/1, Fig 5/2)

- (1) Ensure that the machine bed is clean.
- (2) Using the same datum block (1) as in Near Side Head, set the cutter (2) as follows:
 - a. Release locking handle (3).
 - b. Rotate handwheel (4) clockwise to lower the spindle or anticlockwise to raise the spindle.
 - c. Refasten locking handle (3).
 - d. Reset digital readout, where fitted, to the known dimension.

SECTION 3

OPERATING INSTRUCTIONS




FIG 5/1 TOP HEAD

NOTE: To use the automatic vertical adjustment: release locking handle (3), engage lever (5) and hold until clutch is engaged. If the clutch does not readily engage, operate the handwheel (4) by turning slightly (to right or left) until engagement is made. To raise or lower spindle, press the appropriate button at the control station (6).




FIG 5/2 HAND CONTROLS — TOP HEAD

The automatic vertical adjustment only works in conjunction with the powered height adjustment to the feedrolls. After positioning the spindle, lift the hand lever (5) to disengage the automatic vertical adjustment. Finally, if necessary, adjust manually with handwheel (4). Refasten the locking handle (3).

- (4) If necessary, change chipbreaker shoe (7) to maintain leading edge as close to cut as possible ie 20mm. Alternative lengths are provided see Illustrated Parts List.

Second Bottom Head (Fig 6/1, Fig 6/2) — when fitted

- (1) Ensure the machine bed is clean.
- (2) Using a straightedge (1) as in setting up the First Bottom Head, set the cutter height by adjusting cutterblock (2). The blades of the cutter should just touch the underside of the straightedge. To reset cutter height:
 - a. Release locking handle (4), rotate handwheel (5) clockwise to raise the spindle, or anticlockwise to lower.
 - b. Refasten locking handle (4).




FIG 6/1 SECOND BOTTOM HEAD

To adjust the cutterblock laterally: use handwheel (6) to advance or retract the spindle.

- (3) Set up the guide (3) to the required dimension.




FIG 6/2 HAND CONTROLS — SECOND BOTTOM HEAD

Universal Head (Fig 7) — when fitted

- (1) The cutterblock (1) is removed and replaced in an identical manner to First Bottom Head, steps (1) to (3), Fig 2/1, using the combination spanner on nut (2) and the cutterblock locknut flats. This assumes the head in Bottom Horizontal mode.
- (2) Check direction of cut. Ensure the locking collar (3) is fitted.

NOTE: In the Bottom Head position always change the cutterblock from the rear of the machine. However, in the Vertical mode it is possible to change the cutterblock from the nearside, using a similar procedure. (See Fig 15 for Universal Head modes). Fig 7 shows the head in the near-side vertical (angled or canted) mode.

WARNING

As the universal head can be run in the reverse direction of rotation, depending on position, it is essential the locking collar is always fitted.




FIG 7 UNIVERSAL HEAD SPINDLE

SETTING UP THE MACHINE

Set Infeed Table (Fig 8)

- (1) To set the height of the infeed table (1), unclamp table by turning the locking handle (2) in an anticlockwise direction. Set the height required from direct reading on the graduated scale (3) by moving handle to right or left as required. Secure table in position by turning handle (2) in a clockwise direction. The maximum adjustment available is 10mm.
- (2) Set the fence (4) adjustment with handle (5) after releasing clamp (6). Refasten clamp (6) after adjustment. Set the amount of cut required by direct reading on the scale (9).
- (3) The adjustable guard (7) must be set to within 5mm of the maximum timber size. Slacken star handwheel (8), set guard (7) and retighten handwheel.




FIG 8 INFEED TABLE — SETTING

Set Feed Rolls (Fig 9/1, Fig 9/2)

First Bottom Head described, others similar.

- (1) Set the feed rolls (1) to suit width and thickness of timber, ie: width of rolls to be as width of timber.

NOTE: To achieve maximum traction on wide timber, it may be advisable to space rolls apart, rather than having a solid bank of feed rolls (see Fig. 9/2).

Use the Control Station pushbutton (Fig 1/2) to set the thickness.

If necessary, change the rolls as follows:




FIG 9/1 FEED ROLLS — SETTING

- a. Slacken centre screw (2), using a 10mm hexagon spanner.
- b. Remove 'C' washer (3), add or remove rolls, or spacers (4), to suit width of stock (Fig 9/2), ensuring that each roll drive pin engages with its mating part.
- c. Refit 'C' washer (3) and retighten centre screw (2).
- (2) Set feed roll height 5mm lower than thinnest workpiece. Set outfeed rolls 3mm (see Fig 13).
- (3) When set up, inch timber through the machine up to the fence side cutter (5) and switch off.





FIG 9/2 FEED ROLLS — SPACER DETAIL

Check/Adjust at Fence Side Head (Fig 10)


- (1) Adjust the side roller pressures to the timber so that moderate force is exerted on the timber:
 - a. Adjust the side rollers (1) by unscrewing the two nuts (2) and adjusting side rollers to suit width of stock.
- (2) Adjust the top roller pressure to the timber as follows:
 - a. Adjust the top roller (3) by loosening one screw (4) for lateral adjustment and right hand screw (5) above the roller for height adjustment. Retighten screws.



Check/Adjust at Near Side Head (Fig 11)

- (1) Check the setting of the chipbreaker (1) adjacent to the near side head. Reset if necessary, using locking handle (2) to release slide bar (3). Retighten locking handle (2).
- (2) Inch timber through machine up to top cutter.

- (3) Release locking handle (4) and set side guide (5) after near side head, to the timber width as machined. Refasten locking handle (4).



Check/Adjust at Top and Second Bottom Head (Fig 12)

- (1) Inch timber through all spindles and stop with timber over second bottom head. Switch off.
- (2) If necessary, reset pressure pad after top head to new dimensions of timber as follows:
 - a. Loosen two screws (1) then slide pad (2) laterally.
 - b. Retighten screws.
- (3) Adjust pad pressure to timber thickness using starwheel (3).
- (4) Restart and feed timber through machine. Set side guide (4) by slackening screws (5), slide guide laterally to hold timber to rear fence without trapping. Retighten screws.
- (5) Set outfeed rolls (6) height to suit timber (Fig 13 refers).

SECTION 3

OPERATING INSTRUCTIONS




FIG 12 TOP AND SECOND BOTTOM HEAD — SETTING

Check/Adjust at Universal head (if fitted)

- (1) Inch timber through machine and set side guide (13) by slackening screws (14) and sliding guide laterally. Retighten screws, (see Fig 14).
- (2) Adjust feed roll height as for Second Bottom Head.

Final Adjustments and Settings (Fig 13)

- (1) Check infeed (serrated) feed rolls (1) for height setting.
- (2) Check the plain feed rolls (2) suit the new dimension of the workpiece.
- (3) Pass a test piece through the machine and check the dimensions and profile.
- (4) When fitted with pneumatic loading set the air pressure on feed rolls (2) using the air supply regulators (3) and associated gauges.

NOTE: The first regulator and gauge is for the rolls up to the top head (1), this should be set to a lower pressure than the plain rolls (2).

The following pressures are recommended:

- a. steel rolls 3 bar (1 bar = 14.5 psi.)
- b. rubber covered rolls 4 bar

- (5) On standard machine, set the spring pressure on feed rolls manually, using the hand adjuster screws on the spring tensioners (4).




FIG 13 FINAL ADJUSTMENTS AND SETTINGS

- a. To increase spring pressure, turn the knurled screw on the top of the spring tensioner in a clockwise direction. To decrease spring pressure, turn the screw anti-clockwise.
 - b. If the screw is turned through a distance of 5mm, pressure on roller is approximately 250N (25kg). If the screw is turned through a maximum distance of 16mm, pressure on roller is approximately 500 N (50kg).
- (6) Check pressure pad adjustment (5) after top head. Raise or lower by use of the starwheel.
 - (7) Set the machine feed speed by rotation of the handwheel on the speed indicator dial with the machine running.

NOTE: DO NOT adjust with machine feed stationary.

Universal Head Modes (Fig 14, Fig 15, Fig 16)

The universal spindle attachment can be positioned above or below the bed and at any angle between horizontal and vertical. Basically it can be considered as a three position head providing:

- Bottom Horizontal mode
- Top Horizontal mode
- Nearside Vertical mode (at any angle 0-90 degrees.)

NOTE: After any change of mode, run the motor momentarily to check direction of spindle rotation (see **Reversing Switch**).

When the spindle is in the bottom position, two adjustable bedplates are fitted to suit the cutting circle of the cutterblock. If the spindle is in the nearside vertical, angled, or top horizontal position, metal rails are fitted as




FIG 14 UNIVERSAL HEAD ATTACHMENT

SECTION 3

OPERATING INSTRUCTIONS

bedplates. The forward rail is secured by two square-headed bolts.

In this situation the outfeed table is adjusted vertically to the same height as the bedplate after the **Second Bottom Head**, using the handwheel (10). Adjust the feedrolls (20) and roller pressure to suit the thickness of work (see Fig 13).

Height and lateral adjustment of the universal head can be made in 0.1mm increments using the traverse screws (4) and (5). Angle adjustments can be made using the wormdrive shaft (6).

Reversing Switch

A reversing switch is fitted to the control panel to change the drive motor direction of rotation as below:

- | | |
|---|--|
| Switch to the right (FWD) (spindle in bottom head position) | — Universal head motor rotates clockwise when viewed on fan end of motor |
| Switch to the left (REV) (spindle in top or near-side vertical positions) | — Universal head motor rotates anticlockwise |

NOTE: Check direction of spindle rotation before commencing work (see Fig 15).

4.

In Bottom Horizontal Mode

- (1) Remove the dust cover from the spindle hood and fit the extractor hood (19) to the frame support using two M8x12 mm long hexagon bolts. Connect the dust extractor.
- (2) Set the spindle in the required position under the table.

NOTE: In this position always change the cutterblock from the rear of the machine.

- (3) Fit the cutterblock see **Mounting the Cutterblocks**. The adjustment of the cutterblock in relation to the bedplate (11) is as follows:

a. To adjust vertically: release locking handle (7), place crank handle on square of vertical traverse (4), turn handle clockwise to raise head or anticlockwise to lower. Refasten locking handle (7) after making adjustment.




FIG 15 UNIVERSAL HEAD MODES

b. To adjust laterally: release locking handle (8), place crank handle on square of traverse screw (5), turn clockwise to move head forward or anticlockwise to move backward. Refasten locking handle (8) after adjustment.

- (4) Adjust the outfeed table (9) height in relation to the infeed table to suit timber cut using handwheel (10).

Level with a straightedge in the same manner as **First and Second Bottom Heads**.

- (5) Set guide (13) for width and height using setscrews (14) and locking handles (15) (see Fig. 14).

In Top Horizontal Mode (Fig 16)

- (1) Set the spindle in the required working position, above the bedplates, using the traverse screws (4) and (5).
- (2) Remove the pressure rollers and pressure shoes, together with clamps and support bars. Fit dust extraction hood (22).

NOTE: In raising or moving the spindle, ensure it does not come into contact with any part of the machine. Check direction of rotation of spindle after each change of mode.

- (3) Adjust the outfeed table (9) to the same height as the infeed table (11). Replace bedplates with the metal rails (12) (12a) provided. These are placed side by side ; the last rail fitted prevents sideways movement of the others.

The rails ensure a continuous feed transfer between the infeed and outfeed tables.




FIG 16 UNIVERSAL HEAD —
TOP HORIZONTAL MODE

- (4) Fit the cutterblock. Note change in direction of spindle rotation. Adjust vertically and laterally, using traverse screws (4) and (5), as required.
- (5) Mount pressure shoes, when supplied, before and after the cutterblock.
- (6) Select reverse motor drive (left hand position REV) at control panel. Check rotation of spindle.
- (7) Before feeding the timber, spin the cutterblock to ensure there is adequate clearance at dust hood and moving parts.
- (8) Set guide (13) to suit width of timber in the same way as **Bottom Horizontal Mode**

after releasing setscrews (4). Vertical height is set using handles (15). Retighten after adjustment.

In Nearside Vertical Mode

The universal head in the nearside vertical mode will accommodate a cutterblock having a cutting circle of 125 to 180 mm. The spindle can be positioned at any angle between vertical and horizontal as required (see Fig 14), using the wormdrive shaft (6). In addition, the cutter can be positioned vertically and laterally in relation to the workpiece, in increments of 0.1mm, using the traverse screws (4) and (5).

NOTE: In the nearside and angled positions it is necessary to remove the dust-hood (19).

- (1) To adjust vertically: release the locking handle (7), place crank handle on square of vertical traverse screw (4), turn clockwise to raise head or anticlockwise to lower. Refasten locking handle (7) after adjustment.
- (2) To adjust laterally: release the locking handle (8), place crank handle on square of lateral traverse screw (5), turn clockwise to move forward or anticlockwise to move back. Refasten locking handle (8) after adjustment.
- (3) To angle (cant) the spindle: unscrew the two hexagon nuts (16) at the spindle carriage (17), place crank handle on square of worm drive (6) and adjust angle. Retighten the two nuts (16) after adjustment. The angle is measured in degrees from the horizontal on the graduated scale (18).
- (4) Fit metal rails (12a) to suit width of the work.
- (5) Select reverse motor drive (lefthand position REV) at the control panel. Check rotation of spindle.
- (6) Adjust the feed roll pressure, pressure shoes and side guides on first workpiece to ensure a smooth feed.

FAULTS IN THE WORKPIECES AND THEIR CAUSES

General

- | | |
|--|---|
| <p>FAULT — Blips at the leading end of the underside of the timber.</p> <p>Cause — The cutterblock is too low in relation to the outfeed bedplate.</p> <p>Remedy — Adjust the cutterblock correctly.</p> <p>FAULT — Scars on the trailing end of the underside of the timber.</p> <p>Cause — The cutterblock is too high in relation to the outfeed bedplate.</p> <p>Remedy — Adjust the cutterblock correctly.</p> <p>FAULT — The trailing end of the top face of the timber shows blips.</p> <p>Cause — Pad and roller pressures are incorrectly adjusted.</p> <p>Remedy — Adjust the pad pressures correctly</p> | <p>outfeed bedplate, or are badly ground.</p> <p>Remedy — Adjust, or sharpen the cutters carefully</p> <p>FAULT — Burn marks on the stock.</p> <p>Cause — Cutters are blunt and need regrinding.</p> <p>Remedy — Regrind cutters.</p> |
|--|---|

Faults in Grinding and Setting

- | |
|---|
| <p>FAULT — Nicks in the edges of the cutters especially carbide.</p> <p>Cause — Generally caused by removing too much metal when regrinding. This results in undue stresses and subsequent cracking and breaking away of the cutting edge when machining.</p> <p>Remedy — Take greater care when regrinding cutters.</p> <p>FAULT — Vibrating heads</p> <p>Cause — Cutterblocks have been set up incorrectly. Reset.</p> |
|---|

Faults Caused by Tools

- | |
|--|
| <p>FAULT — Out of square stock after planing.</p> <p>Cause — The cutters are not parallel to the</p> |
|--|

CLEANING THE MACHINE

Machines are designed to need a minimum of maintenance. However, it is recommended that the machine be cleaned thoroughly once a week. This is essential when working on hardwood such as Sipo (Utile) or similar.

If cleaning with compressed air, take care not to direct the jet onto the spindle and moving shaft, bearing housings, etc. Clean the spindles and remove all remains of resin and grease. Do the same with the cutterblock collars and

machine tables (bedplates) and lightly lubricate.

Check that all machine parts slide easily at friction points. Lubricate as indicated in the lubricating instructions (see **Maintenance**).

Adjust the variable speed drive unit through the full range once a week to avoid the feed drive mechanism jamming.

SECTION 4 MAINTENANCE

SCHEDULED MAINTENANCE

Scheduled maintenance consists of regularly maintaining the machine in a good operating condition, capable of safely producing good quality trouble free work, with the minimum of downtime.

This includes tasks such as daily/weekly cleaning and lubrication which can and should be performed by the operator. Tasks carried out at longer intervals will require more specialised knowledge and tools to perform.

Lubrication

Much attention has been given to keeping lubrication and maintenance to a minimum. In consequence, 'sealed for life' bearings and 'Oilite' bushes have been used. The cutter-block spindles have been fitted with permanently lubricated bearings; these should only require replacement of lubricant if the spindle bearings are replaced. However, there are exceptions as follows:

Electric motors, where 'sealed for life' bearings have not been fitted, are provided with grease nipples. These should be greased at *monthly* intervals with Wadkin L6 grease.

There is no requirement for periodic lubrication of the feed rolls motor driven variable speed unit.

Daily

Grease the machine slideways and the various traverse screws with Wadkin Grade L6 grease (see **Approved Lubricants**).

A hand operated lubricating pump is fitted to provide oil feed lubrication to the machine bed. The hand lever should be operated to deliver the required amount of oil to the bed. A tap is fitted to the pump to control the oil flow rate to a preset amount.

The oil reservoir holds 1 litre (1.76 pints) of oil. Replenish with Wadkin Grade L4 oil (see **Approved Lubricants**) as needed.

Weekly

On machines fitted with chain driven feed-

works, the chains should be lubricated at least weekly with an oil can using Wadkin Grade L4 oil. Access to the horizontal chains in the top beam is gained by removing covers on top of the beam.

Monthly/3 Monthly

Grease machine drive spindles and drive motor shafts, where fitted with grease nipples, using Wadkin Grade L6 grease unless otherwise stated. Do not overfill bearing housings.

Generally, machine drive spindles will be lubricated *monthly*.

Chain Drive Tensioning (Fig.1, Fig.2)

Adjustment is provided to all chain drives. These should be checked at regular intervals (Monthly/3 Monthly), if the drive snatches on start-up or is noisy.

Two types of chain adjuster are fitted; a roller arm or sprocket, or a slipperblock (on horizontal chain drive through beam).

Checking/Adjustment is carried out as follows:

A. Roller arm/sprocket.

- (1) Remove the drive cover.
- (2) Check chain for adjustment or wear. Adjustment is correct if no slack is present in the chain.
- (3) To adjust: Reposition the chain tensioner arm (1), by slackening the two securing screws (2) and sliding the arm with roller or sprocket toward the chain. Take up any slack in the chain. Retighten screws (2) after adjustment, (see Fig 1).

NOTE: Do not overtension chain

- (4) Refit drive cover

B. Slipper block (Nylatron runner)

- (1) Remove the drive cover, or covers.
- (2) Check chain for adjustment. Adjustment is correct if no slack is present in the chain.

SECTION 4

MAINTENANCE




FIG 1 CHAIN DRIVE TENSIONING — FEEDWORKS

- (3) To adjust: Reposition the chain runner/tensioner block (1) in relation to the support plate (2), by resetting the two support screws (3), after releasing locknuts (4). Take up slack in the chain. Retighten lock nuts (4) after setting, (see Fig 2).

NOTE: Do not overtension chain.

- (4) Refit drive cover or covers.

Vee-Belt Drive Tensioning (Fig.3)

Check drive belts at regular intervals (as indicated below). If the need arises retension. Insufficient tension causes slipping and premature belt wear. Too much tension causes bearing wear. Tension as indicated in Checking/Adjustment.

Observe the operation of the machine when first put into service. After approximately one hours effective use, check and retension belts to take up initial belt stretch.

In general, Vee-belts will require adjustment at intervals to take up any slack due to use. *Three-monthly* intervals are recommended as an initial guide for the feedworks drive.

It is important to check the condition and tension of the cutterspindle drive belts at more frequent intervals, depending on conditions of use, if problems relating to quality of finish are to be avoided. *Monthly* intervals are recommended initially.

Checking/Adjustment is carried out as follows:

- (1) Remove the drive cover.
- (2) Check belt tension. The belt should be capable of being depressed approximately $1\frac{1}{2}$ to 2 cm by application of average thumb pressure (see Fig.3).
- (3) To adjust: fit spanner (1) provided, to adjusting screw (2), located at motor support bracket and turn in an anticlockwise direction to tension the belt drive (see Fig.3).





FIG 2 CHAIN DRIVE TENSIONING — FEED ROLLS

NOTE: Do not overtension belts.

(4) Refit drive cover.

There may be occasions where the tensioning arrangement does not follow that described. However, all belt drive adjustment follows the same general principle; this involves moving the drive pulley centres or motor platform, thus taking up any slack in the belt drive. The method used will normally be self evident. Retighten any securing features fitted.

If one or more of the vee-belts becomes faulty it will be necessary to replace as a complete set. (see **Replacing Drive Belts**). It is impossible to obtain a correctly tensioned drive, with all belts taking an equal share of the load, by mixing old and new, or different belts.



Cleaning

Woodworking machines are designed to need a minimum of maintenance. However, a certain level of maintenance, especially cleaning and lubrication, will pay dividends in quality of work.

It is recommended that the machine be cleaned thoroughly once a week, especially when working on hardwood or highly resinous material, to prevent choking of ventilator airways and build up of deposits on working parts.

Clean all spindles regularly and remove all remains of resin and grease. Do the same with cutterblock collars and machine tables. Check that all machine parts slide, or rotate freely. Lightly lubricate as directed, do not overlubricate.

If cleaning with compressed air, take care not to direct the jet onto the spindle bearing housings, moving shafts, etc., to avoid forcing dust and debris into bearings and housings.

UNSCHEDULED MAINTENANCE

Unscheduled maintenance consists of replacing or correcting items which are worn, damaged, or are otherwise unserviceable. Generally items which are defective will be replaced.

These tasks require specialised knowledge and tools to perform. Following this type of maintenance, the machine will need to be set up prior to return to work.

All unscheduled tasks — such as changing bearings, should be performed by competent personnel.

Changing Cutterblock Spindle Bearings (Fig.4)

The bearings (5) have been fitted to the cutterblock spindles (6) in an orthodox manner. At

SECTION 4

MAINTENANCE

the non-drive end of the spindle a liquid engineering adhesive ('Loctite' grade 241) has been applied to the internal thread diameter of the bearing nut (4).

NOTE: This nut can be right or left-hand thread, dependant upon spindle rotation and tightens against the direction of rotation.

To dis-assemble parts joined by 'Loctite' adhesive use normal tools and methods. If the holding force of the 'Loctite' joint is too great then apply gentle heat and break the bond while the parts are still hot. The bonding adhesive may be left as a powder and must be removed before applying further adhesive.

Preparation Prior to Fitting Bearings

Before fitting a new bearing, the protective lubricant must be meticulously removed with petroleum spirit, triethanolamine, or other volatile solvent.

In order to prevent the moving parts from being damaged by drying out due to over cleaning, add a small amount of the bearing lubricant to the cleaning agent at the second bath. The film of grease which remains after the solvent has evaporated will provide protection for the bearing until charged with lubricant.

The new bearings should be charged with 'Kluber' lubricant, type 'Isoflex' NBU 15. It is important that the correct amount of grease is applied, preferably using the formula:

$$G \text{ (weight in grams)} = d \times B \times 0.01$$

where; d = bore of bearing in mm
 B = width in mm

This is approximately sufficient to fill one third of the bearing volume.

To remove the bearings:

- (1) Remove pulley assembly from spindle by unscrewing the M12 hexagon screw (1). Withdraw pulley (2) and remove parallel key (3) from spindle.
- (2) Remove bearing nuts (4). Remove existing bearings (5), using a bearing puller on the bearing rings. Take care not to damage the spindle or housing.
- (3) After Preparation; fit new bearings (5) to spindle (6) and housing (7), include spring discs (8) as previously fitted. Use only

sufficient pressure to fit bearings, applying pressure to the inner ring only. Ensure that bearing ring fits up to location shoulder on the spindle.

- (4) Reassemble spindle unit, lubricate bearing (see **Preparation**). Fit bearing nuts (4). Tighten nuts until assembly is secure. Do not over tighten.
- (5) Check that spindle assembly runs freely and without end float.
- (6) Refit parallel key (3), pulley and M12 hexagon securing screw. Tighten screw to spindle until the assembly is secure.




FIG 4 SPINDLE UNIT BEARING ASSEMBLY

Replacing Drive Belts

Drive belts must be replaced as a set to obtain correct drive performance. Before access can be gained to any drive belt it will be necessary to remove the guard covers.

To Replace a Drive Belt:

- (1) Relieve tension on the drive by reducing drive centres. This can be done by either:
 - a. Releasing the fixing bolts on the motor support bracket and sliding the motor forward, or
 - b. Slackening off the motor tensioner bolt, or bolts.
- (2) Remove old drive belts. Fit a new set of belts, same size, type and reference (see **Motor Drive Belt Data**).
- (3) Retension the new belt set (see **Vee-Belt Drive Tensioning — Scheduled Maintenance**), reversing step (1) a. or b., as applicable to drive motor attachment. Secure fixing bolts.

It may at times be necessary to remove a drive pulley. The motor shaft pulleys are fitted with Taper-Lock bushes (see Fig.5), cutterblock spindles are fitted with parallel keys.

Removal and Refit of Drive Pulleys (Fig.5)

To remove a Taper-Lock bush pulley:

- (1) Slacken off all screws (1) several turns using a hexagonal key. Remove one or two screws according to number of jacking holes (2).
- (2) Insert screws in jacking holes after oiling thread and point of grub screws, or thread and head of cap screws, as applicable.
- (3) Tighten screws (1) alternately until bush (3) is loosened in pulley hub and assembly is free on shaft.
- (4) Remove pulley assembly from shaft.

To refit a Taper-Lock bush pulley:

- (1) Ensure that mating taper surfaces are completely clean and free from oil or dirt. Insert bush in hub and line up screw holes.
- (2) Oil thread and point of grub screws, or thread and head of cap screws. Place screws (1) loosely in threaded holes in hub of pulley.
- (3) Clean shaft, fit hub and bush to the shaft as a unit. Locate in position. On fitting; the bush will nip the shaft first, then hub will be drawn onto bush.

NOTE: It is necessary to axially align drive and driven pulleys.

- (4) Using a hexagon key, alternately tighten screws (1), until all screws are pulled up securely. Use a short length of pipe on key to increase leverage.
- (5) After the bush (3) has been tightened onto the shaft, fit the parallel key (4). The key is side fitting with top clearance.
- (6) After the drive has been running under load for a short time, stop and check tightness of screws. Tighten if needed.
- (7) Fill empty screw holes with grease to exclude dirt.

Variable Speed Drive Pulleys (Fig.6)

The variable speed pulleys incorporated within the feed roll drive unit are virtually maintenance free.

There are two drive arrangements possible; both employ the 'Simplabelt' drive unit for speed variation. The only difference is in the method of power takeoff. The unit is:

- a. Fitted with a gearbox for shaft drive.
- b. Fitted with a worm box for chain drive.

The method of adjustment and fitting a new drive belt to the unit is the same for either arrangement.

Should it be necessary to repair the feed drive, or fit a new drive belt, proceed as follows:




FIG 5 REMOVING A TAPER-LOCK BUSH

SECTION 4

MAINTENANCE

To Dismantle*A. General*

- (1) Adjust the drive unit to the maximum output speed before dismantling. Switch off drive.
- (2) Unscrew socket head capscrews (23) and remove the complete adjustment device (24).

B. Removing wide section drive belt

- (1) Unscrew socket head capscrews (20) and support the motor (3).
- (2) Separate cover (18) and connecting casting (2) so that the belt (17) can be removed from the variable speed pulley (13).
- (3) Remove belt (17) from the variable speed pulley (9).

C. Dismantling variable speed pulleys, motor and housing

- (i) Mechanically adjustable variable speed pulley (motor shaft)

- (1) Unscrew axial tightening screw (16) and remove end cap (14).
- (2) Position a suitable extractor behind the circlip of the pulley and with an extractor, remove pulley (13) from the motor shaft.

- (ii) Spring loaded variable speed pulley (gearbox shaft)


- (1) Unscrew axial tightening screw (16) and remove cap (8).

- (2) Remove the spring and spring retaining cap with a suitable extractor. Then using an extractor (gripping behind the hub flange) remove the pulley (9) from the gearbox shaft.

(iii) Motor and housing

- (1) Unscrew hexagon head screws (5) and remove motor.

- (2) Unscrew hexagon head screws (11) and remove housing from gearbox.

**FIG 6 SIMPLABELT VARIABLE SPEED DRIVE UNIT**

To Assemble

The assemble procedure is the reverse sequence to dismantle. ie: steps C, B, A.

- (1) When refitting the wide section drive belt; first place belt onto the fully opened mechanical variable speed pulley (13), then over the rim of the spring loaded variable speed pulley (9).

NOTE: Only original 'Simplabelt' wide section drive belts must be used.

Spare Parts

When ordering spare parts, all the data shown on the unit nameplate must be quoted.

Cutters and Tool Holders

When choosing cutters, make sure they are suitable for a speed of 6000 rpm. Dynamically balance and check for defects and cracks.

The life of a cutterblock is directly related to the quality of the steel and nature of timber to be worked. It is impossible to give exact values of cutter life; the following is a guide.

High speed steel	HLS	2-5 hours
Very high speed steel	HSS	3-8 hours
Carbide steel	HM	20-70 hours

Honing at regular intervals will prolong the life of the cutters.

When regrinding cutters it is very important to ensure the edge does not become overheated. Overheating can be prevented if light grinding cuts are taken.

Ensure that all cutters of a multiple cutterblock are the same, the objective being that all should cut the timber evenly and equally.

The performance of any tool depends to a large extent on the care in the way it is used. The life of the cutters and the surface finish of the workpiece are directly related to the care which is given to the work.

Shaft Drive system (Fig 7)

The GB woodworking machine may be fitted with an alternative drive arrangement, incorporating a shaft drive to the spindles through the beam in place of the chain drive.

When the shaft arrangement is used, the power transfer is via a right angle gearbox to each spindle. Each gearbox is filled with lubricant on assembly and will normally not need any attention for long periods (10,000 hour intervals).

The cardan shafts should be lubricated at *Monthly* intervals using Wadkin Grade L6 grease.

The lubricant in the helical gearbox fitted to the variable speed control power take-off should be changed at (10,000 hr intervals). Request information for this item before changing lubricant.

NOTE: The worm gearbox fitted to the chain drive is lubricated for life.

No other maintenance will normally be required on the shaft drive.




FIG 7 SHAFT DRIVE SYSTEM

SECTION 4

MAINTENANCE

FAULT FINDING

Mechanical Faults

Apart from mechanical failure (breakage) the majority of mechanical faults can be attributed to incorrectly tensioned drive chains or belts; the setting of cutterblocks and cutterblades; items working loose due to vibration — failure to set or tighten correctly; wrong speed setting; or misuse.

Therefore to get the best performance it is essential that the machine is set-up and used correctly, when many mechanical faults can be avoided.

Elimination of Vibration

It is important to check condition and tension of the cutter spindle drive belts regularly (see **Scheduled Maintenance**).

It is also important that the cutters are evenly ground and set to run true in the cutterblock, the assembled cutterblock should be statically balanced before fitting to the spindle.

In the case of high speed machines it is highly recommended that cutterblocks be dynamically balanced (see **Maintenance: Cutters and Toolholders**).

Electrical Faults

FAULT The machine does not run when any 'START' button is operated

Diagnosis

- a. Disconnect (isolator) switch has not been closed
- b. Main fuse or control circuit fuse has blown
- c. Overload relay has tripped

Remedial Action

- a. Check and close if needed
- b. Replace fuse
- c. Reset relay. Check reason for trip

FAULT A motor does not start — loud humming sound

Diagnosis

- a. An open circuit in at least two 'line leads' of the motor
- b. The fuses of the motor have blown

Remedial Action

- a. Check circuit and rectify
- b. Replace fuse

FAULT An air break magnetic contactor does not operate

Diagnosis

- a. The contacts are burned and make improper contact
- b. Broken connection wire
- c. An overload relay has tripped
- d. A fuse has blown

Remedial Action

- a. Clean or replace contacts
- b. Remake connections
- c. Reset relay. Check reason for overload
- d. Replace fuse

FAULT A Star/Delta connected motor does not operate when the contactor is connected in star

Remedial Action

Check/Remedy the symptoms outlined in paragraph above

FAULT When a motor is started, the fuses blow and the overload relay trips

Diagnosis

- a. The motor does not run freely
- b. There is a short circuit in the wiring mains
- c. The motor windings or winding are/is earthed

Remedial Action

- a. Check that the motor is free running
- b. Check the circuit wiring
- c. Check the windings in turn for electrical continuity and also earth faults with a 'Megger'

FAULT The motor overheats when running 'light' (unloaded)

Diagnosis

- a. The motor windings are connected in delta instead of star
- b. The mains voltage is too high
- c. The ventilating air ducts of the motor frame have become blocked with dust or chips, the cooling air passage has become impeded, or the cooling fan (if fitted) is not functioning correctly

Remedial Action

- a. Check connections
- b. Check mains voltage and correct
- c. Clean airways. Check fan operation

FAULT Motor overheats while working

Diagnosis

- a. The motor is overloading
- b. The motor is running under single phase conditions

Remedial Action

- a. Check reason and correct
- b. Check electrical circuits

FAULT The motor makes an abnormal noise

Diagnosis

- a. The cause can be of a mechanical or electrical nature
- b. If the noise is caused by an electrical fault, the noise will disappear when power is switched off
- c. If the noise is caused by a mechanical fault, the noise will diminish as speed of rotation decreases

Remedial Action

- a. Establish mechanical or electrical origin
- b.c. Check symptoms. Deduce by elimination to locate position and nature of fault



SECTION 4

MAINTENANCE

FAULT The Air Break Magnetic Starter is noisy**Diagnosis**

- a. The mains voltage is too low
- b. The surfaces of the 'fixed' and 'moving' contacts are dirty

Remedial Action

- a. Check mains voltage and correct
- b. Clean or replace contacts

FAULT The air break magnetic starter remains 'closed' after a STOP button has been operated**Diagnosis**

- a. The contactor 'fixed' and 'moving' contacts have welded together following a short circuit

Remedial Action

- a. Check and remove cause of the short circuit. Replace the damaged contacts. It may be necessary to replace the complete contactor if too damaged

FAULT A fault condition arises on a motor and the overload current relay fails to operate.**Diagnosis**

- a. The overload relay may be incorrectly rated – it should correspond to the normal full load current of the motor (given on the motor nameplate) for Direct-on-Line starting
- b. If the overload relay is connected in a Star/Delta starter, the rating of the overload should be the normal full load current of the motor (given on the motor nameplate) multiplied by 1/1.73 (0.58)

Remedial Action

- a. Replace with correctly rated relay

FAULT A Spindle stops, but the motor still runs**Diagnosis**

- a. The drive belts are loose, broken, or have come off

Remedial Action

- a. Retension or replace belts

FAULT The Rise and Fall drive motor does not operate**Diagnosis**

- a. The limit switch on the top horizontal head, or the limit switch at the end of the machine is jammed by wood chips or is damaged
- b. The push button is faulty

Remedial Action

- a. Check and clean the limit switches
- b. Check and clean the push button

FAULT If the limit switch between the Top Head and Beam is operated simultaneously with either of the two Beam Vertical Traverse limit switches, the Beam will not lower

Diagnosis

Disengage the clutch on top head and manually wind down the top head until limit switch is released, then bring beam down by normal procedure (pushbutton control)

The foregoing observations are of a general nature and intended to be of assistance to avoid the incidence of breakdown. They do not preclude the user from calling a qualified electrician. In the case of an electrical fault or breakdown, in the interest of personal safety, it is always advisable to call a qualified electrician if the fault repeats.

TABLES

APPROVED LUBRICANTS

WADKIN	CASTROL	B.P.	SHELL	MOBIL	ESSO	GULF	CALTEX
L1	HYSPIN AWS 32	ENERGOL HLP 32	VITROL 32	DTE OIL LIGHT 24	NUTO 44 OR ESSTIC H44	HARMONY 43 AW	RANDO OIL HDA
L2	ALPHA ZN 150	ENERGOL HP 150 OR CS 150	VITREA 150	VACTRA EXTRA HEAVY	ESSTIC 65	SERVICE 13	URSA P40
L4	MAGNA 68	ENERGOL HP 68 OR CS 68	VITREA 68	VACTRAL OIL HEAVY MEDIUM	ESSTIC 50	SERVICE 51	URSA P20
L6	SPHEEROL AP 3	ENERGREASE LS3	ALVANIA GREASE NO. 3	MOBILPLEX GREASE NO. 48	BEACON 3	GULFCROWN GREASE NO. 3	REGAL STARTAK PREMIUM 3

- L1 OIL Hydraulic oil with anti-corrosion, anti-oxidation, anti-wear, anti-foam performance.
- L2 OIL Gear oil (Viscosity 150 centi-strokes at 40°C).
- L4 OIL Plain mineral oil (Viscosity 68 centi-strokes at 40°C).
- L6 GREASE Grease NLG1 No. 3 consistency Lithium bearing grease.

SECTION 4

MAINTENANCE

MOTOR AND DRIVE BELT DATA

Belts and pulleys for spindle drive to			FIRST BOTTOM HEAD						Frequency 50 Hertz			
Motor			Motor Pulley		Taper Lock Bush			Belts			Spindle Pulley	Spindle Speed
Frame Size	K.W.	H.P.	Fenner Ref.	Wadkin Code	Bore M.M.	Fenner Ref.	Wadkin Code	Fenner Ref.	Wadkin Code	Quan.	Wadkin Number	R.P.M.
D112	4.0	5.5	031Z 0222	K30 78 237	28	2012	K30 77 114	SPZ 850	K30 78 213	2	GA 109	6000
D132	5.5 7.5	7.5 10.0	031Z 0223	30 78 218	38	2012	K30 77 113	SPZ 850	K30 78 213	3	GA 410	6000

Belts and pulleys for spindle drive to			FIRST BOTTOM HEAD						Frequency 60 Hertz			
Motor			Motor Pulley		Taper Lock Bush			Belts			Spindle Pulley	Spindle Speed
Frame Size	K.W.	H.P.	Fenner Ref.	Wadkin Code	Bore M.M.	Fenner Ref.	Wadkin Code	Fenner Ref.	Wadkin Code	Quan.	Wadkin Number	R.P.M.
D112	4.0	5.5	031Z 0202	K30 78 294	28	1610	K30 77 184	SPZ 800	K30 78 208	2	GA 109	6000
D132	5.5 7.5	7.5 10.0	031Z 0203	K30 78 272	38	2012	K30 77 113	SPZ 800	K30 78 208	3	GA 410	6000

Belts and pulleys for spindle drive to			FIRST FENCE SIDE HEAD						Frequency 50 Hertz			
Motor			Motor Pulley		Taper Lock Bush			Belts			Spindle Pulley	Spindle Speed
Frame Size	K.W.	H.P.	Fenner Ref.	Wadkin Code	Bore M.M.	Fenner Ref.	Wadkin Code	Stephens Ref.	Wadkin Code	Quan.	Wadkin Number	R.P.M.
D112	4.0	5.5		GA 415				Meteor CE 3P	K30 05 383	1	GA 413	6000
D132	5.5 7.5	7.5 10.0		GA 416				Meteor CE 6P	K30 05 384	1	GA 413	6000

Belts and pulleys for spindle drive to			FIRST FENCE SIDE HEAD						Frequency 60 Hertz			
Motor			Motor Pulley		Taper Lock Bush			Belts			Spindle Pulley	Spindle Speed
Frame Size	K.W.	H.P.	Fenner Ref.	Wadkin Code	Bore M.M.	Fenner Ref.	Wadkin Code	Stephens Ref.	Wadkin Code	Quan.	Wadkin Number	R.P.M.
D112	4.0	5.5		GA 415				Meteor CE 6P	K30 05 384	1	GA 414	6000
D132	5.5 7.5	7.5 10.0		GA 416				Meteor CE 6P	K30 05 385	1	GA 414	6000

Belts and pulleys for spindle drive to NEAR SIDE HEAD Frequency 50 Hertz												
Motor			Motor Pulley		Taper Lock Bush			Belts			Spindle Pulley	Spindle Speed
Frame Size	K.W.	H.P.	Fenner Ref.	Wadkin Code	Bore M.M.	Fenner Ref.	Wadkin Code	Stephens Ref.	Wadkin Code	Quan.	Wadkin Number	R.P.M.
D112	4.0	5.5		GA 415				Meteor CE 3P	K30 05 417		GA 413	6000
D132	5.5 7.5	7.5 10.0		GA 416				Meteor CE 6P	K30 05 418			6000

Belts and pulleys for spindle drive to NEAR SIDE HEAD Frequency 60 Hertz												
Motor			Motor Pulley		Taper Lock Bush			Belts			Spindle Pulley	Spindle Speed
Frame Size	K.W.	H.P.	Fenner Ref.	Wadkin Code	Bore M.M.	Fenner Ref.	Wadkin Code	Stephens Ref.	Wadkin Code	Quan.	Wadkin Number	R.P.M.
D112	4.0	5.5		GA 415				Meteor CE 3P	K30 05 417		GA 414	6000
D132	5.5 7.5	7.5 10.0		GA 416				Meteor CE 6P	K30 05 414			6000

Belts and pulleys for spindle drive to FIRST TOP HEAD Frequency 50 Hertz												
Motor			Motor Pulley		Taper Lock Bush			Belts			Spindle Pulley	Spindle Speed
Frame Size	K.W.	H.P.	Fenner Ref.	Wadkin Code	Bore M.M.	Fenner Ref.	Wadkin Code	Fenner Ref.	Wadkin Code	Quan.	Wadkin Number	R.P.M.
D112	4.0	5.5	031Z 0222	K30 78 237	28	2012	K30 77 114	SPZ 850	K30 78 213	2	GA 109	6000
D132	5.5 7.5	7.5 10.0	031Z 0223	K30 78 218	38	2012	K30 77 113	SPZ 850	K30 78 213	3	GA 410	6000

Belts and pulleys for spindle drive to FIRST TOP HEAD Frequency 60 Hertz												
Motor			Motor Pulley		Taper Lock Bush			Belts			Spindle Pulley	Spindle Speed
Frame Size	K.W.	H.P.	Fenner Ref.	Wadkin Code	Bore M.M.	Fenner Ref.	Wadkin Code	Fenner Ref.	Wadkin Code	Quan.	Wadkin Number	R.P.M.
D112	4.0	5.5	031Z 0202	K30 78 294	28	1610	K30 77 184	SPZ 800	K30 78 208	2	GA 109	6000
D132	5.5 7.5	7.5 10.0	031Z 0203	K30 78 272	38	2012	K30 77 113	SPZ 800	K30 78 208	3	GA 410	6000



SECTION 4

MAINTENANCE

Belts and pulleys for spindle drive to			UNIVERSAL HEAD					Frequency 50 Hertz				
Motor			Motor Pulley		Taper Lock Bush			Belts			Spindle Pulley	Spindle Speed
Frame Size	K.W.	H.P.	Fenner Ref.	Wadkin Code	Bore M.M.	Fenner Ref.	Wadkin Code	Fenner Ref.	Wadkin Code	Quan.	Wadkin Number	R.P.M.
D132	5.5	7.5	031Z 0223	K30 78 218	38	2012		SPZ 940	K30 77 156	3	GA 410	6000

Belts and pulleys for spindle drive to			UNIVERSAL HEAD					Frequency 60 Hertz				
Motor			Motor Pulley		Taper Lock Bush			Belts			Spindle Pulley	Spindle Speed
Frame Size	K.W.	H.P.	Fenner Ref.	Wadkin Code	Bore M.M.	Fenner Ref.	Wadkin Code	Fenner Ref.	Wadkin Code	Quan.	Wadkin Number	R.P.M.
D132	5.5 7.5	7.5 10.0	031Z 0203	K30 78 272	38	2012	K30 77 113	SPZ 900	K30 78 351	3	GA 410	6000

SECTION 5 ILLUSTRATED PARTS LIST

CONTENTS

- 1 Bedplate Charts
- 2 Bottom Heads
- 3 Fence and Near Side Head Carriage Unit Adjusting Mechanism
- 4 Top Head — including Power Rise and Fall
- 5 Bottom (excluding first) and Top Heads axial adjustment
- 6 Universal Head Adjusting Mechanism
- 7 Bottom Top and Universal Head Spindle Unit
- 8 Fence and Near Side Head Spindle Unit
- 9 Top Head Chipbreaker Pressure Pad and extraction hood
- 10 Near Side Head Chipbreaker and extraction hood
- 11 Simplabelt Variable Speed Drive Unit
- 12 Drive to Chain Driven Feedworks
- 13 Feed Rolls Drive Chains Tensioning Mechanism
- 14 Feed Roll Unit Chain Drive (double swing)
- 15 Shaft Drives
- 16 Drive Gearboxes and Bottom Roll Drive
- 17 Fences Guides and Guards — Standard Machine
- 17a Fences
- 18 Bedplates, Fences and Guides — Universal Head Attachment
- 19 Single Side Roller Pressure Unit
- 20 Double Side Roller Pressure Unit
- 21 Top Roller Pressure Unit
- 22 Mounting for Top Pad or Roller Pressure Unit before Top Head

IMPORTANT: WHEN ORDERING SPARES ALWAYS QUOTE MODEL AND MACHINE NUMBER




FIG 1 BEDPLATE CHARTS

ITEMS 1-4 ON FIRST BOTTOM HEAD ONLY




FIG 2 BOTTOM HEADS

2. BOTTOM HEADS

Ref. No.	Description	No. Off
1	Handwheel, standard, black plastic moulding, M12 blind hole	1
2	Locking screw for guard, First Bottom Head cutterblock	1
3	Locking pad for cutterblock guard	1
4	Top sliding guard, First Bottom Head	1
5	Slide strip	1
6	Bottom Head spindle housing, vertical slide	1
7	Pulley belt housing, horizontal heads	1
8	Spindle pulley, Bottom and Top Heads	1
9	Fenner vee belt, SPZ 850	2 or 3
10	Fenner vee belt pulley	1
11	Fenner Taper-Lock bush	1
12	Hexagon head screw, M10 x 30mm long	4
13	Spring washer, 10mm diameter, single coil	4
14	Bracket nut, Bottom Head vertical adjustment	1
15	Vertical adjustment screw, First Bottom Head	1
16	Hexagon socket capscrews, M6 x 75mm long	4
17	Bevel box, Bottom Head vertical adjustment	1
18	Bevel gear wheel	1
19	Bearing washer, top and bottom	2
20	Thrust washer	1
21	M16 hexagonal nut	2
22	Parallel key 5mm x 5mm x 20mm long	1
22a	Parallel key 8mm x 7mm x 20mm long	1
23	Bevel gear pinion	1
24	Circlip, 16mm external, pinion shaft (not shown)	1
25	Thrust washer	1
26	Bronze bush, 25mm ID x 30mm OD x 25mm long	1
27	End cap, bevel box	1
28	Hexagon socket capscrews, M6 x 20mm long	3
29	Collar	1
30	Extension shaft, bevel gear	1
31	Bearing bracket, extension shaft	1
32	Bronze bush, 20mm ID x 25mm OD x 25mm long	2
33	Hexagon socket capscrews, M6 x 20mm long	2
34	Digital readout	1
35	Square end shaft extension	1
36	Taper pin, No. 1	1
37	Extension shaft, vertical lock	1
38	Locking handle, M12 x 25mm, male	1
39	Main Frame	1
40	Cover, bevel box	1
41	Front guard, First Bottom Head spindle	1
42	Top cover, bevel gear	1

SECTION 5

ILLUSTRATED PARTS LIST

DIGITAL READOUT (OPTIONAL)




FIG 3 FENCE AND NEAR SIDE HEAD CARRIAGE UNIT ADJUSTING MECHANISM

**3. FENCE AND NEAR SIDE HEAD CARRIAGE UNIT ADJUSTING MECHANISM
(INCLUDING RISE AND FALL WHEN FITTED)**

Ref. No.	Description	No. Off
1	Exhaust hood (Fence Side illustrated)	1
2	Fence or Near Side Head spindle carriage	1
3	Nut for lateral movement	1
4	Calibrated dial	2
5	Horizontal shaft for lateral movement	1
6	Front horizontal shaft for vertical movement	1
7	Nut for vertical adjustment	1
8	Hexagon head screw, m10.dia. x 80mm long	1
9	Bright mild steel washer size M10	2
10	Hexagon nut, M10	1
11+	Rear horizontal shaft for vertical adjustment	1
12	Mitre gear bracket for side head vertical adjustment	1
13	Collar for horizontal shaft for vertical adjustment	1
14	Straight mitre bevel gear (16T 2.5 MOD)	2
15+	Hexagon socket screw-cup point, M6 dia. x 6mm long	2
16	M12, self locking nut	1
17	'INA' bearing AXK 2542	2
18	'INA' bearing AS 2542	2
19	'INA' bearing LS 2542	2
20	Chamfered notch nut, M24 x 1.5	2
21	Vertical screw for side head vertical adjustment	1
22	Large dia. Mild steel washer size, M10	1
23	Hexagon head screw, M10 x 20mm long	1
24	Locking shaft for fence or near side head spindle barrel	1
25	Clamping block for side head horizontal movement	1
26	Legend plate	1
27+	Collar, M20 dia.	2
28+	'O' Ring	2
29	Locking handle, M12 x 25mm, male	1
30+	Mitre gear bracket guard	1
31+	Key, 5 x 5 x 20	3
32+	'INA' Bearing thrust washer	1
33+	Grease nipple	4
34	Locking handle, M10 x 25mm, male	1
35+	Brass pad, dia. 6 x 5mm	1
36	Bearing plate	1
37+	'INA' Bearing AXK 2035	2
38+	'INA' Thrust washer AS 2035	3
39+	'INA' Shaft washer WS 81104	1
40	Digital readout	1
+	Not illustrated	
+	Not illustrated	

SECTION 5

ILLUSTRATED PARTS LIST




FIG 4 TOP HEAD INCLUDING POWER RISE AND FALL

4. TOP HEAD INCLUDING POWER RISE AND FALL

Ref. No.	Description	No. Off
1	Fenner vee belt pulley	1
2	Fenner vee belt, SPZ 850	2 or 3
3	Slide strip	1
4	Top Head vertical slide	1
5	Vertical screw, Top Head rise and fall	1
6	Bracket nut, Top Head rise and fall	1
7	Hexagon head screws, M8 x 25mm long	2
8	Top cover, gearbox/clutch housing	1
9	Socket head capscrews, M6 x 10mm long	4
10	Bevel gear wheel	1
11	Worm gear, rise and fall top beam/head	1
12	Bearing, 6204 RS	2
13	Dogclutch, Top Head rise and fall	1
14	Circlip, 16mm external (not shown)	1
15	Spacer washer	1
16	Tension pin, 6mm x 32mm long	1
16a	Hexagon socket screw cup point, M6 x 6mm long	1
17	Gearbox/clutch housing	1
17a	Socket head capscrews, M12 x 30mm long	4
18	Spacer washer	2
19	Circlip, 30mm external	2
20	Bottom cover, gearbox/clutch housing	1
20a	Securing screws, M8 x 16mm hex. socket	4
21	Thrust washer	2
22	Plain washer, 16mm	1
23	M16 hexagon nut	2
24	Bronze bush, 25mm ID x 30mm OD x 20mm long	1
25	Hexagon socket screw, cup point, M6 x 10mm long	1
26	Clutch location arm	1
27	Clutch shaft	1
28	Spring, clutch location arm lock	1
29	Steel ball, 10mm diameter	1
30	Locking handle, M10 x 25mm, male	1
31	Clutch yoke, top head rise and fall	1
32	Hexagon socket capscrews, M6 x 10mm long	2
33	Parallel key, 8mm x 7mm x 32mm long	1
34	Worm wheel, Top Head rise and fall	1
35	Parallel key, 8mm x 7mm x 14mm long	1
36	Bronze bush, 30mm ID x 35mm OD x 20mm long	1
37	Circlip, 16mm external (not shown)	1
38	Parallel key, 5mm x 5mm x 20mm long	1
39	Spacer washer	2
40	Bevel gear, pinion	1

SECTION 5

ILLUSTRATED PARTS LIST




FIG4 TOP HEAD INCLUDING POWER RISE AND FALL

4. TOP HEAD INCLUDING POWER RISE AND FALL (cont.)

Ref. No.	Description	No. Off
41	End cap, bevel box	1
42	Socket head capscrew, M6 × 20mm long	3
43	Bronze bush, 20mm ID × 25mm OD × 25 long	1
44	Collar	
45	Hex. socket screw - cup point, M6 × 6mm long	1
46	Extension shaft	1
47	Bearing bracket, extension shaft	1
48	Bronze bush, 20mm ID × 25mm OD × 25mm long	1
49	Hex. socket capscrews, M6 × 20mm long	2
50	Digital readout	1
51	Square end shaft extension	1
52	Taper pin, No. 1	1
53	Main frame	1
54	Locking handle	1
55	Extension shaft, vertical lock	1
56+	Hex. head screw, M12 × 30mm	4
57+	Circlip	1
58+	Spring Safety feature	1

+ Not illustrated. Attachment of gearbox/clutch housing to mainframe.

SECTION 5

ILLUSTRATED PARTS LIST




FIG 5 BOTTOM (EXCLUDING FIRST) AND TOP HEADS AXIAL ADJUSTMENT

5. BOTTOM (EXCLUDING FIRST) AND TOP HEADS AXIAL ADJUSTMENT

Ref. No.	Description	No. Off
1	Nut for horizontal head adjustment	1
2	Shaft for horizontal head adjustment	1
3	M24. x 1.5 chamfered notch nuts	2
4	Bearing bracket for horizontal adjustment	1
5	'INA' bearings AXK 2542	2
6	'INA' bearings AS 2542	4
7	Sprocket for horizontal head axial adjustment	2
8	'RENOLD' Roller chain No. 111046 12.9mm (1/2in.) pitch, 40 pitches including connecting link	1
9	No. 4. taper pin	2
10	Shaft	1
11	20mm. I.D. x 25mm. O.D. x 20mm. long bronze brush	2
12	Extension for vertical lock to horizontal heads	1
13	Locking handle M12. x 25mm. male	1
14	Universal coupling and square tube assembly for horizontal head adjustment	1
15	Universal coupling and square tube assembly for horizontal head cross adjustment	1
16	6mm. dia. x 32mm. long tension pin	1
17	Shaft for horizontal head cross adjustment	2
18	Bearing block	1
19	Digital readout	1
20	Square shaft extension	1
21	Taper pin. No. 1	1

SECTION 5

ILLUSTRATED PARTS LIST




FIG 6 UNIVERSAL HEAD ADJUSTING MECHANISM

6. UNIVERSAL HEAD ADJUSTING MECHANISM

Ref. No.	Description	No. Off
1	Universal Head spindle, 40mm dia.sq.shoulder	1
2	Locking nut	1
3	Locking collar assembly	1
4	Vertical traverse screw	1
5	Digital readout	1
6	Vertical slide stand	1
7	Locking handle, M10×50mm, male	1
8	Saddle, Universal Head	1
9	Locking handle	1
10	Digital readout	1
11	Horizontal traverse screw	1
12	Cross slide, Universal Head	1
13	Worm gear shaft	1
14	Electric motor, frame D132	1
15	Drive pulley	1
16	Drive belt, Fenner, SPZ 940	3
17	Pulley/belt housing	1
18	Pulley/belt housing cover	1
19	Spindle carriage, Universal head	1
20	Bolt, spindle carriage	2
21	Wormwheel, Universal Head	1

SECTION 5

ILLUSTRATED PARTS LIST

7. BOTTOM TOP & UNIVERSAL HEAD SPINDLE UNIT – 40MM DIAMETER SQUARE SHOULDER

Ref. No.	Description	No. Off
1	Locking nut, Bottom Head and Near Side head spindles	1
1a	Locking nut Fence side head. Top head Universal	1
2	Bottom Head spindle, 40mm. dia. square shoulder	1
2a	Top Head spindle, 40mm square shoulder	1
2b	Universal Head spindle, 40mm square shoulder	1
3	Bearing nut, Bottom Head and Near Side spindles	1
3a	Bearing nut Fence side head. Top head and Universal spindles	1
4	Bearing nut, spindle housing	1
** 5	Bearing, RHP or SKF 6009	1
6	Barrel, Horizontal and Near Side spindle	1
** 7	Bearing, RHP or SKF 6306	1
8	Parallel key, 8mm×7mm, 40mm long	1
9	Pulley spigot for spindle	1
10	Hexagonal head screw, M12×45mm long	1
11	'BELLEVILLE' series 'K' disc spring, for bearing 6306, 71.5mm OD×45.5mm OD×0.7mm	6
**	'KLUBER' Grease packed	




FIG 7. BOTTOM TOP AND UNIVERSAL HEAD SPINDLE UNIT

SECTION 5

ILLUSTRATED PARTS LIST




FIG 9 TOP HEAD CHIPBREAKER, PRESSURE PAD AND EXTRACTION HOOD

8. FENCE AND NEAR SIDE HEAD SPINDLE UNIT – 40MM DIAMETER SQUARE SHOULDER

Ref. No.	Description	No. Off
1	Locking nut Fence Side Head, Top Head and Universal Head spindles	1
1a	Locking nut, Bottom Head and Near Side Head spindles	1
2	Fence Side Head spindle, 40mm, dia. square shoulder	1
2a	Near Side Head spindle, 40mm, dia. square shoulder	1
3	Bearing nut, Fence Side Head, Top Head and Universal Head spindles	1
3a	Bearing nut, Bottom Head and Near Side Head spindle	1
4	Bearing nut, spindle housing	1
** 5	Bearing, RHP or SKF 6009	1
6	Barrel, Horizontal and Side Head spindles	1
** 7	Bearing, RHP or SKF 6306	1
8	Pulley spigot for spindle	1
9	Hexagon head screw, M12 x 35mm	1
10	Parallel key, 8mm x 7mm x 40mm long	1
11	'BELLEVILLE' series 'K' disc spring, for bearing 6306, 71.5mm OD x 45.5mm ID x 0.7mm	6
**	'KLUBER' Grease packed	




FIG. 8 FENCE AND NEAR SIDE HEAD SPINDLE UNIT – 40MM DIAMETER SQUARE SHOULDER

9. TOP HEAD CHIPBREAKER, PRESSURE PAD AND EXTRACTION HOOD

Ref. No.	Description	No. Off
1	Tee-nut, M10, ref. WDS 664 203	2
2	Screwed stud, M10 x 45mm long	2
3	Washer 10mm, bright mild steel	2
4	Hexagon nut, M10	2
5	Hexagon socket screws, half dog point, M6 x 35mm long	3
6	Hexagon nut, M6	3
7	Gib strip, rise and fall bracket, Top Head pressure pad	1
8	Slide, rise and fall, for shoe Top Head pressure pad	1
9	Bracket, rise and fall, Top Head pressure	1
10	Screw, raise/lower, Top head pressure pad	1
11	Compression spring, Top Head pressure pad	1
12	Top plate, Top Head pressure pad	1
13	Hexagon socket screw, M8 x 20mm long	2
14	Handwheel, M12 blind hole	1
15	Taper pin. No.0	1
16	Hexagon nut, thin, M12	2
17	Washer, 12mm, bright mild steel	1
18	Exhaust hood, Top Head	1
19	Hexagon head screw, M12 x 40mm long	1
20	Plug, spring loaded Top Head chipbreaker	1
21	Cap, Top Head chipbreaker spring	1
22	Spring, Top head chipbreaker	1
23	Washer, 10mm, bright mild steel	2
24	Hexagon nut, M10	2
25	Screwed stud, M10 x 50mm long	2
26	Pivot bracket, Top Head chipbreaker	1
27	Plunger, spring loaded Top Head chipbreaker	1
28	Pivot shaft, Top Head chipbreaker	1
29	Parallel key, 8mm x 6mm x 32mm long	1
30	Holder, Top Head chipbreaker shoe	1
31	Washer, chipbreaker pivot shaft	1
32	Nut, M12, self locking	1
33	Shoe, Top Head, 70mm long	1
—	Shoe, Top Head, 82mm long	1
—	Shoe, Top head, 105mm long	1
34	Chip deflector, Top Head chipbreaker	1
35	Cross tenon for shoe, top head pressure	1
36	Shoe, Top Head pressure	1
37	Cover, Top Head pressure pad	1

SECTION 5

ILLUSTRATED PARTS LIST




FIG 9 TOP HEAD CHIPBREAKER, PRESSURE PAD AND EXTRACTION HOOD

SECTION 5

ILLUSTRATED PARTS LIST

10. NEAR SIDE HEAD CHIPBREAKER AND EXTRACTION HOOD

Ref. No.	Description	No. Off
1	Spring clip	2
2	Shoulder pin, M16 dia.	2
3	Spacer, M20 dia.	2
4	Top cover for Near Side Head hood	1
5	Exhaust Hood for Near Side Head	1
6	Post	2
7	Near Side head chip deflector	1
8	Spring	2
9	Hexagon socket capscrew, M8 × 10mm	4
10+	Hexagon socket countersunk screw, M8 × 10mm	2
11	Pivot pin for Near Side head chipbreaker	1
12	Near Side head and chipbreaker shoe pivot bracket	1
13+	Cup point grub screw, M8 × 12mm	4
14	Hexagon full nut, M8	1
15	Hexagon head screw, M8 × 40mm	1
16	Near Side head chipbreaker shoe	1
17+	Screw stud, 10mm × 60mm, M10	1
18	Washer, 10mm	3
19	Locking handle, M10 female	1
20	Adjusting bar for Near Side head chipbreaker	1
21	Hexagon head screw, M10 × 25mm	2
22	Shoe chipbreaker bracket	1
23+	Side Cover for Near Side Head Hood	1
24+	Screw Stud, 6mm × 25mm, M6	2
25+	Washer, 6mm	2
26	Wing Nut M6	2
+	Not illustrated	




FIG 10 NEAR-SIDE HEAD CHIPBREAKER AND EXTRACTION HOOD

11. SIMPLABELT VARIABLE SPEED DRIVE UNIT

Ref. No.	Description	No.Off
1	Helical gear transmission (shaft drive)	1
1a	Worm gear transmission (chain drive)	1
2	Housing	1
3	Standard 3 phase motor	1
4	Lock washer, spring	4
5	Screw, hexagon head	4
6	Screw, cheese head	1
7	Washer disc, or nut	1
8	Locking plate	1
9	Pulley, spring loaded (gearbox)	1
10	Pin	1
11	Screw, hexagon head	8
12	Lock washer, spring	8
13	Pulley, mechanically adjustable (motor)	1
14	Locking plate	1
15	Washer disc, or nut	1
16	Screw, hexagon head	1
17	Vee belt, wide	1
18	Cover	1
19	Lock washer, spring	4
20	Screw, cheese head	4
21	(Item not fitted)	
22	Lock washer, spring	4
23	Screw, cheese head	4
24	Hand adjustment	1
25	Cover plate	1
26	Screw, hexagon head	8
27	Lock washer, spring	8




FIG 11 SIMPLABELT VARIABLE SPEED DRIVE UNIT

SECTION 5

ILLUSTRATED PARTS LIST

12. DRIVE TO CHAIN DRIVEN FEEDWORKS

Ref. No.	Description	No. Off
1	Chain guard and cover, feed roll drive unit	1
2	'Duplex' chain sprocket	1
3	'Renold-Duplex' roller chain, No. 114056 — 15.8mm (5/8in.) pitch × 54p	1
4	Connecting link, No. 26, doe No. 114056	1
4a	Cranked link, No. 30, for No. 114056	
5	'Duplex' chain sprocket	1
6	Parallel key, 8mm × 7mm × 40mm	1
7	Chain tension wheel	1
8	Spindle chain tension wheel	1
9	Hex. head screw, M12 × 60 mm long	1
10	Washer, 12mm	1
11	Sliding bar, chain tensioning	1
12	Screw, Hexagon head, M 10 × 30mm long	2
13	Washer, 12mm, large	2
14	Washer, 12mm	2
15	Screw, hexagon head, M6 × 12mm long	5
16	Washer, lock 6mm	5




FIG 12 DRIVE TO CHAIN DRIVEN FEEDWORKS

13. FEED ROLLS DRIVING CHAIN TENSIONING MECHANISM

Ref. No.	Description	No. Off
1	'Nylatron' runner, chain tensioner	4
2	Support plate, chain tensioner	4
3	Screw, hexagon head, M10 x 60	8
4	Nut, hexagon, M10	8
5	Roller chain	1
6	Roller chain	1
7	Roller chain	1
8	Roller chain	1




FIG 13 FEED ROLL DRIVE CHAINS TENSIONING MECHANISM

SECTION 5

ILLUSTRATED PARTS LIST





FIG. 14 FEEDROLL UNIT CHAIN DRIVE (DOUBLE SWING)

14. FEEDROLL UNIT CHAIN DRIVE (DOUBLE SWING)

Ref. No.	Description	No. Off
1	'Seeger' circlip, 30mm external, No.V118	8
2	Parallel key, 8mm x 7mm x 63mm long	1
3	Chain sprocket, single lane, rear chain drive	2
4	'Duplex' chain sprocket, rear chain drive	1
5	Bearing, 6206 2RS	2
6	Shaft, top intermediate drive to feed rolls	1
7	Parallel key, 8mm x 7mm x 20mm long	1
8	Sprocket, top intermediate, rear chain drive	1
9	'Renold' roller chain, No. 110056, 15.8mm (5/8in.) pitch x 43 pitches	1
9a	Connecting link, No. 26, for 110056 chain	1
10	Vertical slide, feed roll beam	1
11	Eccentric bush, feed roll drive chain tensioner	1
12	Pivot shaft for swings	1
13	Feed roll swing, right hand	1
14	Bronze bush, 25mm ID x 30mm OD x 25mm long	4
15	Flange, feed roll mount	2
16	Feed roll, top spiral, saw tooth narrow	2
17	Feed roll, top spiral	2
18	Spacer, feed roll	2
19	Draw bolt	2
20	Washer, 'C' type	2
21	Bearing, 6006 2RS	2
22	Feed roll shaft	1
23	Feed roll swing, left hand	1
24	Bearing, 6205 2Z	2
25	Circlip, internal, 52mm, No. 5000/206	2
26	Spacer, feed roll shaft drive sprocket	2
27	'Renold' roller chain, No. 110046, 12.7mm (1/2in) x 31 pitches	2
27a	Connecting link, No. 26, for 110046 chain	2
28	Chain sprocket, for feed roll shaft	2
29	Parallel key, 8mm x 7mm x 20mm long	2
30	Screw, hexagon head, M8 x 20mm long	2
31	Washer, end locking, feed roll shaft drive sprocket	2
32	Chain sprocket, feed rolls drive	1
33	Circlip, 42mm, internal	2
34	Bearing, 6004 Z	1
35	Screw, hexagon head, M8 x 16mm long	1
36	Washer, retaining, feed roll drive sprocket	1
37	Bearing, 'INA' NA 6905	1
38	Grease retainer, feed roll swings	1
39	Circlip, internal, bore size 62mm	1

SECTION 5

ILLUSTRATED PARTS LIST



SEE FIG. 16




FIG. 15 SHAFT DRIVES



15. SHAFT DRIVES

Ref. No.	Description	No. Off
1	Coupling	5
2	Gear box assembly (See Fig 16)	3
3	Drive shaft	1
4	Drive shaft	1
5	Cardan shaft	5
6	Cover, flexible	5
7	Clip	10
8	Cardan shaft, outfeed bedroll	1
9	Cover, flexible	1
10	Clip	2

www.DaltonsWadkin.com

SECTION 5

ILLUSTRATED PARTS LIST




FIG 16 GEARBOXES AND BOTTOM ROLL DRIVE

16. GEARBOXES AND BOTTOM ROLL DRIVE

Ref. No.	Description	No. Off
1	Gearbox assembly, single or double roller	1
2	Gearbox assembly, double roller	1
3	Gearbox assembly, double roller plus drive to bed roll	1
4	Cover, bottom roll drive	1
5	Hex, head screw M8 × 20mm	2
6	Drive sprocket 22T, c/w socket head set screw	1
7	Parallel key, 6mm × 6mm × 32mm	1
8	Chain, No. 110056 – 15.8mm (5/8in.) pitch × 56p	1
9	Connecting link, No. 26, for No. 110056 chain	1
9a	Cranked link, No. 30, for No. 110056 chain	1
10	Driven sprocket, 25T c/w socket head set screw	1
11	Parallel key, 8mm × 7mm × 32mm	1
12	Drive shaft, bottom	1
13	Drive support plate.	1
14	Bearing housing	1
15	Hex. head set screws, M8 × 25mm	3
16	Washers, M8	3
17	Parallel key, 8mm × 7mm × 20mm	1
18	Nyloc socket screw M8	2
19+	Circlip, external, 30mm	2
20+	Ball bearing, SKF 6206 – 2RS	2
21+	Circlip, internal, 62mm	2
22	Drive shaft, universal joint	1
23	Jubilee clip, K30 09 429	2
24	Cover, GA 8307	1

Note: Item 2 is final box on Universal Head machines

Item 3 is final box on Non-Universal Head machines

SECTION 5

ILLUSTRATED PARTS LIST




FIG 17 FENCES GUIDES AND GUARDS — STANDARD MACHINE



17. FENCES GUIDES AND GUARDS STANDARD MACHINE

Ref. No.	Description	No. Off
	Fences — See Fig. 17A	
1+	Guard, first bottom head	See Fig 2
2+	Attachment bracket	
3+	Starwheel	
4	Guide, Top and Near side Heads	1
5	Attachment bracket	1
6	Hex. socket capscrew, M10 x 25mm long	3
7	Locking handle	1
8	Washer, 12mm, bright mild steel	1
9	Screwed stud, M12 x 25mm long	1
10	Hexagon nut, M12	1
11	Washer, 12mm, bright mild steel	1
12	Guide, Second Bottom Head	1
13	Attachment bracket	2
14	Screw, hexagon head, M10 x 20mm long	2
15	Washer, 10mm, bright mild steel	2
16	Screw, socket head	2
17	Guard, Second Bottom Head	1
+	Not illustrated	

SECTION 5

ILLUSTRATED PARTS LIST

17A. FENCES

Ref. No.	Description	No. Off
1	Infeed fence	1
2	Shallow fence after Bottom Head	1
3	Fence before Top head	1
* 4	Fence after Top head	1
* 5	Filling in piece	1 or 2
* 6	Fence after Universal head	1
	or	
** 4	Fence after Top head	—

*With Universal head
 **Without Universal head




FIG 17a FENCES

18. BEDPLATES FENCES AND GUIDES UNIVERSAL HEAD ATTACHMENT

Ref. No.	Description	No. Off
1	Bedplate	2
2	Bed rail	2
3	Guide	1
4	Attachment bracket	2
5	Screw, hexagon head, M10×25mm long	2
6	Washer, 10mm, bright mild steel	2




FIG 18 BEDPLATES FENCES AND GUIDES — UNIVERSAL HEAD ATTACHMENT

SECTION 5

ILLUSTRATED PARTS LIST

19. SINGLE SIDE ROLLER PRESSURE UNIT OPPOSITE FENCE SIDE HEAD

Ref. No.	Description	No. Off
1	Bracket, single roller side pressure unit	1
2	Pin, side pressure roller	1
3	Pressure roller	1
4	Sliding shaft, pressure roller	1
5	Infeed pressure spring	1
6	Hexagon head screw, M12 x 35mm long, for GA128	2
7	Washer 12mm, bright mild steel, for GA128	2
8	'Heyco' nylon domed plug, black, 8mm hole, DP312 for GA128	1
9	Circlip, 20mm external, for GA 110	1
10	Bearing, SKF 6004 2RS, for GA 110	1
11	Tension pin, 8mm dia x 30mm long, for GA111	1
12	Tension pin, 5mm dia x 30mm long, for GA111	1




FIG 19 SINGLE SIDE ROLLER PRESSURE UNIT OPPOSITE FENCE SIDE HEAD

20. DOUBLE SIDE ROLLER PRESSURE UNIT

Ref. No.	Description	No. Off
1	Bracket, double roller side pressure unit	1
2	Pin, side pressure roller	2
3	Pressure roller	2
4	Sliding shaft, pressure roller	2
5	Infeed pressure spring	2
6	Casing, spring, pressure roller	2
7	Pressure adjusting screw	2
8	Nylon domed plug, black, 8mm hole	2
9	Hexagon head screw, M 12 x 35mm long	2
10	Washer, 12mm, bright mild steel	2
11	Circlip, 20mm external	2
12	Bearing, SKF 6004 2RS	2
13	Tension pin, 8mm x 30mm long	2
14	Tension pin, 5mm x 30mm long	2




FIG 20 DOUBLE SIDE ROLLER PRESSURE UNIT

20. DOUBLE SIDE ROLLER PRESSURE UNIT

Ref. No.	Description	No. Off
1	Bracket, double roller side pressure unit	1
2	Pin, side pressure roller	2
3	Pressure roller	2
4	Sliding shaft, pressure roller	2
5	Infeed pressure spring	2
6	Casing, spring, pressure roller	2
7	Pressure adjusting screw	2
8	Nylon domed plug, black, 8mm hole	2
9	Hexagon head screw, M 12 x 35mm long	2
10	Washer, 12mm, bright mild steel	2
11	Circlip, 20mm external	2
12	Bearing, SKF 6004 2RS	2
13	Tension pin, 8mm x 30mm long	2
14	Tension pin, 5mm x 30mm long	2




FIG 20 DOUBLE SIDE ROLLER PRESSURE UNIT

SECTION 5

ILLUSTRATED PARTS LIST

21. TOP ROLLER PRESSURE UNIT

Ref. No.	Description	No. Off
1	Barrel, top pressure roller	1
2	Spring tensioner, top pressure	1
3	Split clamp, top pressure barrel	1
4	Roller arm, top pressure	1
5	Roller, top pressure	1
6	Roller pin, top pressure <i>✓ 3069202</i>	1
7	Spring, infeed pressure	1
8	Tension pin, 8mm dia. x 24mm long	1
9	Tension pin, 5mm dia. x 24mm long	1
10	Hexagon head screw, M12 x 45mm long	2
11	Circlip, 20mm external	1
12	Bearing, SKF 6004 2RS	1




FIG 21 TOP ROLLER PRESSURE UNIT

22. MOUNTING FOR TOP PAD OR ROLLER PRESSURE UNIT BEFORE TOP HEAD

Ref. No.	Description	No. Off
1	Bracket, top pressure	1
2	Horizontal bar, longitudinal adjustment	1
3	Horizontal bar, transverse adjustment	1
4	Split clamp, top pressure horizontal bars	1
5	Screwed stud, M10 x 55mm long	1
6	Hexagon nut, M10	1
7	Washer, 10mm, bright mild steel	1
8	Hexagon socket screw, M10 x 25mm long	2
9	Hexagon head screws, M12 x 40mm long	2




FIG 22 MOUNTING FOR TOP PAD OR ROLLER PRESSURE UNIT BEFORE TOP HEAD



SECTION 6 APPENDICES

Appendix A
Appendix B

Dial-a-Size Electronic Positioning
99 Setting Programable Memory Positioning

www.DaltonsWadkin.com

APPENDIX A

DIAL-A-SIZE ELECTRONIC POSITIONING

Near Side Head and Top Head

The powered traverse movement to the near side head is by a 'KEMO' geared motor.

The traverse movements of the heads are each connected to an 'encoder' which sends pulse signals to its respective 'Elgo' digital read out controller situated in the electrical control panel (see Fig 1).

The traverse of the heads reacts to data put into the 'Elgo' controller which displays the cutterblock position in relation to its datum face. The datum face for the near side head is the fence. Datum for the top head is the bedplate.

The head traverse movements may be hand or power operated and a switch is provided for this purpose.

Setting Up

All setting parameters are available via the front keypad. Programming is inhibited until a link at the back of the unit is opened.

The programming link is in the form of a two terminal plug-in block, with a shorting wire. Unplug to set in parameters. Re insert plug to operate.

NOTE: The controller will not run with the link open.

Setting of the parameters is achieved as follows:

- (1) Press T, top display extinguishes and 'CH' is displayed. This ensures that the operator knows when the T button has been depressed (even by accident).
- (2) Enter functions [1][5], 'CH' is extinguished. Title name is displayed in top window; value of parameter is displayed in bottom window.
- (3) Press C to clear existing value, enter required value.
- (4) Press T again to revert to operating mode.

The [T] functions/parameters are as follows:

[1] This sets the slowdown point during approach to position. 'SLSP' is displayed.

[2] This sets the stop correction offset. 'COR' is displayed.

[3] Saw width compensation is entered. 'SABL' is displayed.

[4] Time at standstill during backlash over-run and delay in drop-off of 'In Position' relay after drive stop is initiated.

'Ti' is displayed. Time can be set from 00.0 to 15.9 seconds. Also sets the auto retract time (ie; distance).

[5] This sets the decimal point position in the displays.

'DP' is displayed.

1 means units only, (ie; no decimal point).

2 means tenths displayed, (ie; one decimal place 0.0).

3 means hundreds displayed, (ie; two decimal places 0.00).

One [T] function is available with programme link either open or closed. That is Inch/Metric selection. This is used as follows:

- (1) Press [T], 'CH' appears in display.
- (2) Press [O], 'INCH' or 'MM' appears in display.
- (3) Press [C] to changeover.
- (4) Press [T] to revert to operation.

The decimal point is automatically moved and any actual value correctly recalculated. The set up parameters are also in the chosen units.

When [T] is pressed inadvertently, 'CH' is displayed to warn operator that he has pressed the button. Simply pressing [T] again returns controller to operating mode.

NOTE: All these parameters will be preset by Wadkin during the setting-up of the machine.

APPENDIX A

Method of Operation

To Set Datum

- (1) Switch to 'Hand' operation (see Fig 1).
- (2) Determine the distance between the cutterblock and either the fence or bedplate, by use of a known thickness setting block or piece of timber; by hand winding the spindle up to the setting block.
- (3) Enter this figure using the keypad.
- (4) Press Datum pushbutton (Blue) on control panel.

These figures will be displayed on the demand value display (bottom window). The Datum figure is now set.

NOTE: (a) These Datum figures need only be re-set at machine switch-on, or if the cutterblocks are changed.

NOTE: (b) To hand set the height of the top horizontal spindle independently of the beam, disengage clutch (ie; operate changeover lever (see Fig 1/2 Section 3).

To move the heads to a pre-determined position

- (1) Switch to 'Elgo' operation (see Fig 1).
- (2) Enter the required position using the keypad.
- (3) Press 'Start' push button.

The head selected will now move automatically to the set position and the figures will be displayed in the actual value display (top window).

- (4) To move to a new position, repeat steps (2) and (3).

NOTE: The feed can only be inched in this mode.

To run the machine

- (1) Switch to 'Auto' position.
- (2) The feed can now be run continuously, or inched.




FIG 1 DIAL-A-SIZE CONTROL PANEL

REFER ALSO TO
FIG 1/1 CONTROL PANEL

APPENDIX B

99 SETTING PROGRAMABLE MEMORY POSITIONING

Near Side Head and Top Head

This unit has the capacity to be programmable for ninety-nine positional head settings.

The powered traverse movement to the near side head is by a geared motor.

The traverse movements of the heads are each connected to an 'encoder' which sends pulse signals to its respective digital read out controller situated in the electrical control panel.

The traverse of the heads reacts to data put into the controller which displays the cutter-block position in relation to its datum face. The datum face for the near side head is the fence. Datum for the top head is the bedplate.

The head traverse movements may be hand or power operated and a switch is provided for this purpose.




FIG 2 CONTROL PANEL



SECTION 6

APPENDICES

The illustrations (buttons) on the left hand side of each page show the buttons to be pressed, and in what order.

If buttons are shown with an '&' sign between them, they must then be pressed simultaneously.

POSITIONING

PST 218


SWITCH ON MACHINE

CALIBRATION (Manual)

Each axis must be datumed before production is started.


The calibrating procedure is as follows:

The PST 218 unit can control 2 axes, both of which must be independently datumed.



Push the button until the axis to be datumed (either axis 1 or axis 2) is shown as a number in the LED display.

AXIS



&



The mode and calibration buttons must be pressed simultaneously.

Enter new value.




Press enter.

The axis should now be datumed. Repeat the same operation for the second axis. When both axes have been datumed, the unit is ready for use.

Confirmation is in the top right of the unit where there are LED lights for each axis which represent the calibration.


MANUAL POSITIONING

The axis to be moved must be selected first.




Push the button until the axis to be moved (either axis 1 or axis 2) is shown as a number in the LED display.

AXIS



For manual positioning of the unit, the mode key and the direction of travel must be pressed simultaneously.



Move to a higher value than the position.

Move to a lower value than the position.

When manual positioning is finished, the stop button must be pressed to put the unit back into the automatic mode.


DIAL-A-SIZE POSITIONING (SET POINTS)

The axis to be moved must be selected first.



Push the button until the axis to be moved (either axis 1 or axis 2) is shown as a number in the LED display.

AXIS



To use the Dial-A-Size option, this is simply a case of pressing the set point button and then the dimension.



Pressing the 'start' button will send the axis to the position.

When in position, an LED in the top right of the unit will be lit.

Whilst positioning is taking place, the 'started' LED will be lit.


SECTION 6

APPENDICES



PROGRAM POSITIONING (For programming of,
see later
instructions)

CALLING UP PROGRAM



By press the 'program' button, the display will change to the program mode.


Pushing either of the two button will increase or decrease the program number to the one required.

Pushing the 'start' button will drive the axis to the position stated in the program.

NOTE: To escape from the program mode of the unit, press the 'program' button.

When the axis is in position, the 'in position' LED will be illuminated in the top right of the unit.

PROGRAMMING OF THE UNIT



By pressing the 'program' button, the display will change to the program mode.

Push either of the two buttons until the program number required to be programmed is found.

The buttons 'mode' and 'enter' when pressed simultaneously will enable you to have the access to the program number that is illustrated in the display.

You will now have access to the axis.

Enter the required figures if a new number or an alteration.

NOTE: If the figures for axis 1 are correct and it is only axis 2 which has to be altered, you can press 'ENTER' without altering any figures will give you access to axis 2.



Pushing the 'enter' button will enter the figures into the memory and give you access to axis 2.

Enter the required figures.



Pressing the 'enter' button will enter the new figures into the memory.

The unit is now ready for use as 'calling up program'.



NOTE: Program P O is only for test purposes.


To clear existing information, press 'CL Qty' before entering new figures.

TO USE THE RADIUS OFF-SET FEATURE

CALIBRATION (MANUAL)

The centre of both the left hand and top head spindle must be calibrated to use the off-set feature

Each axis must be datumed before production is started. **NOTE:** Maximum travel limit parameters may require changing. Calibration for using radius off-set is as follows:



Push button until the axis to be datumed (either axis 1 of axis 2) is shown as a number in the LED display.


AXIS





SECTION 6

APPENDICES



&



The mode and calibration buttons must be pressed simultaneously.


Enter the distance from the centre of the spindle to the bed, or fence, depending which axis is being calibrated.



Press Enter


The axis should now be datumed, repeat the same operation for the second axis. When both axis have been datumed, the unit is ready for use.

Confirmation is in the top right hand of the unit where there are LED lights for each axis, which represents the calibration.




To enter the radius off-set


Measure and record the radius of the cutterheads to be used.



Push the button until the axis to be off-set (either axis 1 or axis 2) is shown as a number in the Led display.



&



The 'Mode' and 'Correct' buttons must be pressed simultaneously.

Enter radius value of the cutterhead for that particular axis.



Press 'Enter' twice.

Repeat the same procedure for the second axis.

When both axis have had the radius off-sets entered, the unit can be used as "calling up a program."

When the heads are moving into their programmed positions and, when they are in position, the display will show the relevant position of the centre of the spindle.



To display the actual "finished" size positions, of the cutterheads, push the 'program' button.



FAULT FINDING

FAULT

Axis will not
position accurately.

SOLUTION/CHECK

Check that unit is
calibrated (LED top
right if unit),
recalibrate if
necessary.

Physical object causing
an obstruction. Remove
object and check overload.
Try again.

Movement is greater than
the axis limits. Insert
new figures.

Negative value in
positioning memory.

PARAMETER SECTION - To enable the E.S.P System to function in either Metric (MM) or Imperial (inches)

PARAMETERS - This section should only be entered into by a competent person, who fully understands their function.

To enter into the parameter section, press 'mode' and '1', then '2' '0' '5'.

	<u>Imperial</u>		<u>Metric</u>	
	<u>Axis 1</u>	<u>Axis 2</u>	<u>Axis 1</u>	<u>Axis 2</u>
<u>Decimal Point</u> Display = PA. Pres '0' to change Press Enter				
<u>Calibration Method</u> Display = PAD Press Enter				
<u>Pre-Switch off Value/Over Run</u> Display = PA Press Enter This parameter to correct any positioning error due to "over run"				
<u>Tolerance Value</u> Display - PA Press Enter				
<u>Loop Mode</u> Positioning Direction Display = PAb Press Enter				
<u>Loop Value</u> Display = PAb Press Enter				



SECTION 6

APPENDICES

<u>Delay Time</u> Display - PAde Press Enter		
<u>Minimum Travel Limit</u> Display = PA= Press Enter		
<u>Maximum Travel Limit</u> Display = PA Press Enter Note: If the radius off-set feature is used then the maximum travel limit should be		
<u>Spindle Factor Counter</u> For Generator Matching Display = PA Press Enter		
4. <u>Spindle Factor Denominator</u> Display - PA Press Enter		
<u>Conversion (mm - Inch)</u> Display = PA		

Press mode and then Enter to switch from Axis 1 to Axis 2, and go through the same parameters

When finished with both Axis 1 and Axis 2, press Mode and 1 to exit parameter section.