




Flexible Automation

CC 100 M

User Handbook

P.-Nr. 3809 / E4 – 04/89



**Numerische Steuerungen
Computer Numerical Control**

Schulungszentrum Flexible Automation

Kurse
für:

- Bediener, Einrichter
- Projektoren, Programmierer
- Inbetriebnehmer, Instandhalter

Kurs-
themen:

- Numerische Steuerungen (CNC) für Werkzeugmaschinen
- Speicherprogrammierbare Steuerungen (SPS)
- Elektrische Servoantriebe
- Robotersteuerungen für Roboter und Handhabungstechnik
- Widerstands-Schweißsteuerungen

Kurs-
bezeichnung:

GL = Grundlagen

B = Bedienen

P = Programmieren

C = CPL/CPC

I = Inbetriebnahme

Instandhalten

Ausbildungsvorschlag Numerische Steuerungen

Für Einsteiger
ohne
Erfahrung
(alle Bereiche)

CC-GL
Basiskurs
mit CC 100M

Für Bediener
und Einrichter
mit allg. NC-
Erfahrung

CC 100M-B
"Fräsen"
Bedienen

CC 100T-B
"Drehen"
Bedienen

CC 200T-B
"Drehen"
Bedienen

CC 300-B
Für CC 200M
CC 300M
Bedienen

Für Program-
mierer
mit allg. NC-
Erfahrung

Programmieren

Programmieren

grafisches
Programmieren

CC 200M-P
grafisches
Programmieren

CC 300-P
für CC 200M
CC 300M
DIN-Program-
mieren

Für Program-
mierer: Aufbau-
kurs für para-
metrisches
Programmieren

CC 100-C
für CC 100M
CC 100T
CPC-Program-
mieren

CC 300-C
für CC 200M
CC 300M
CPL-Program-
mieren

Für Inbetrieb-
nehmer, Projektoren,
Instandhalter
mit produktspez.
Kenntnissen

CC 100M-I
Instandhaltung
Inbetriebnahme

CC 100T-I
Instandhaltung
Inbetriebnahme

CC 200T-I
Instandhaltung
Inbetriebnahme

CC 300-I2
für CC 200M
CC 300M
Inbetriebnahme
Projektieren

CC 300-I1
für CC 200M
CC 300M
Inbetriebnahme
Instandhaltung

CC 100 M

User Handbook

P.-Nr. 3809 / E4 - 04/89

(S32)

© 1989

All rights reserved by ROBERT BOSCH GMBH,
also for the event of registration of industrial property rights.
All rights of disposal, such as rights of copying and passing on, reserved by us.

No liability assumed for errors. Subject to technical modifications.
Nominal charge DM 23,--

1 DESCRIPTION	Page
Component parts	
General	1-1
Survey of modules	1-2
Operating panel	1-3
Manual panel	1-4
CP/MEM module	1-5
Interfaces	
Data interfaces, general	1-6
Data format	1-7
V.24 cable	1-8
20 mA cable	1-9
20 mA terminal	1-10
Peripherals	
Cassette unit DCR terminal	1-11
Mini cassette unit	1-14
Program Header	
External program production	1-16
General header format	1-17
Program header - example	1-18
Program header in DFS format	1-19
Position, calculation, input and output of the checksum	1-22
2 OPERATING	
Main Modes	
Survey	2-1
Subdivision of VDU display; reset conditions	2-2
Edit	
General	2-3
Program editor and cycles	2-4
Machine	
Manual machine operation	2-5
MDI	2-6
Teach In	2-7
Automatic	
Operating procedure before program/cycle start	2-9
Interruption/re-entry	2-10
Operating procedure after cycle start	2-11
Accessing tables	2-12

Information	Page
General, machine status	2-13
Axes display, PIC/PLC display	2-15
Inch/metric switching	2-18

Data Handling

General, load/save	2-20
Load programs/cycles	2-21
Save programs/cycles	2-22
Delete programs/cycles	2-23
Load tools, zero shifts, variables	2-25
Save tools, zero shifts, variables	2-26
Load machine parameters, texts, graphics	2-26
Output logbook data	2-27

3 PROGRAMMING**General**

Program production, memory allocation	3-1
Memory allocation - programs/cycles	3-2
Part programs and cycles	3-3
Subprograms	3-4
Jump instructions	3-5
Subprogram call-ups	3-5
Parallel programming	3-7
Drip feeding	3-9

Addresses

F-address, T-address	3-14
M-address	3-15
S-address, gear ranges	3-16
H-address	3-17
Operator instruction programming	3-18

Tables

Tools, zero shifts, variables	3-19
-------------------------------	------

G-Functions

Linear interpolation in rapid G0	3-20
Linear interpolation in feed G1	3-21
Circular interpolation G2, G3, G5	3-22
Dwell G4	3-27
Linear interpolation in rapid with extended in position range G6	3-28
Plane selection G17/18/19	3-29
Setting a pole G20	3-30
Conditional subprogram call-up G21	3-32
Subprogram call-up G22	3-33
Conditional jump G23	3-34

	Page
Unconditional jump G24	3-35
Field limitation G25/26/27	3-36
Scale factor switching G36	3-37
Programmable mirroring G38/39	3-39
Tool radius compensation G40/41/42	3-41
Zero shift G53, G54 - G59	3-42
In position logic ON/OFF G61/G62	3-43
Feedrate and spindle speed G63/G66	3-44
Effect of feedrate G64/G65	3-45
Contour transitions G68/G69	3-46
Referencing G74	3-47
Measuring probe input G75	3-48
Machining of bores G80 , G81 - G87	3-49
Survey of fixed machining cycle	3-51
Fixed machining cycles G80 - G87	3-52
Drilling G81	3-55
Boring/end facing G82	3-56
Deep hole drilling	3-57
Tapping	3-59
Boring G85	3-61
Reaming G86	3-63
Thread milling G87	3-65
Dimensioning G90/G91	3-67
Setting position stores G92	3-68
Feedrates G93/ G94	3-70
Automatic calculation of cutting speed G96	3-72
Spindle speed, direct G97	3-73
Subprogram end G99	3-74
Three-digit G-codes G800 - G869	3-75
General G890 - G898	3-76
Intersection circle/circle G890	3-78
Intersection line/circle G891	3-79
Rounding corners (3 points) G892	3-80
Rounding corners (2 angles) G893	3-81
Chamfering G894	3-82
Calculate end point of an arc G895	3-83
Transition point arc/arc tangential G896	3-84
Calculate end point of a straight line G897	3-85
Intersection of two straight lines G898	3-86
Survey of firmly allocated cycles	3-87

4 PARAMETRIC FUNCTIONS	Page
General	
Range, programming	4-1
Program planning, aims, use of forms	4-2
Memory allocation form	4-3
Program planning form	4-4
Variable (global) form	4-5
Load function	4-6
Arithmetic functions	4-7
Trigonometric functions	4-9
Tools	
Load tool store	4-10
Copy tool data	4-10
Load/copy zero shifts	4-11
Unconditional branching	4-12
Conditional branching, setting condition register	4-13
Conditional branching/condition register (CR)	4-13
Conditional branching after mathematical comparison	4-15
Branching condition: NC instruction	4-17
Axis information	4-18
Positioning POS	4-19
STV function	4-20
CPC programming examples	
Ellipse	4-22
Row of holes	4-23
Bolt hole circle	4-24
5 TECHNOLOGY	
Internal processing of tool technology data	5-1
Tool compensation, general	5-2
Tool length compensation T-address	5-3
Tool radius compensation G40/41/42	5-5
Starting point, beginning of contour	5-6
Entry into contour from different starting points	5-7
Contour transitions with G68 (auxiliary arcs)	5-8
Contour transitions with G69 (intersections)	5-9
Examples for G41/42	5-10
End point, cancelling the compensation	5-11
Special Cases - Tool Compensation	
Change of compensation, switching between G41/G42	5-12
Examples	5-13
Suppression of contour elements	5-14
Cancelling compensation at inside corners	5-14
Outside corners	5-15

6 APPENDIX	Page
Programming Code	
G-codes, 2-digit	6-1
G-codes, 3-digit	6-2
M-codes	6-3
Parametric functions	6-4
Axis information, auxiliary functions, subprograms and jumps, special characters, control characters	6-6
ASCII character set	6-7
Output of Error Messages	
Definition, operating	6-8
Error message group 0	6-9
Error message group 1	6-11
Error message group 2	6-13


SUBJECT INDEX

1. DESCRIPTION

CC 100 M

Full CNC continuous path
control for up to 4 numerically controlled
axes plus controlled main spindle.

Programming based on DIN 66025,
extended by graphic and arithmetic functions.



This manual is intended for the use
by the enduser of the control.

Component parts of the control, operating
elements, maintenance, working with the
data interface are described in chapter 1.

Reset conditions, the reference system, operation
of the operating panel and the manual panel, and
the technology stores are described in chapter 2.

Chapter 3 describes the conventional
programming to DIN, 3-digit G-codes and
contour cycles.

Parametric functions, user graphic, operation
of the tool compensation and special applications
are described in chapters 4 - 7.

DESCRIPTION COMPONENT PARTS


BOSCH CC 100 M User Handbook

COMPONENT PARTS




Operating Panel

graphic screen, 10" green
soft keys
main mode
input keyboard



Manual Panel

handwheel, jog buttons, override switches
customer keyboard
reentry / display distance to go
start / stop / emergency stop button



Logic Modules:

CP/MEM module:

connections for 2 serial
data I/O devices, operating
panel, external VDU, battery
and software module

Module PS 75:

Displays for
- Ready (green)
- 24 V (green),
- internal voltage
levels ok (green)
reset button

connections for:

- ready 2
- 24V

SERVO module:

connections for
5 incremental
measuring systems,
analogue outputs
time-critical signals


P I C module or
P L C connection

DESCRIPTION COMPONENT PARTS

BOSCH CC 100 M
User Handbook

OPERATING PANEL


Operating panel in main mode AUTOMATIC



DESCRIPTION COMPONENT PARTS

BOSCH CC 100 M
User Handbook

MANUAL PANEL



Functions

Override potentiometers:

The feedrate value is set on the potentiometer in %.

The button deactivates the potentiometer (sets value to 100% when the potentiometer is set between 80 and 120%).

The potentiometers can be used in MACHINE and AUTOMATIC modes.

Customer keys:

Effective in MACHINE mode;

Depression of one of the keys in the top two rows triggers an MDI function, which is stored in memory.

Bottom row for direct switching of PLC input signals.

DESCRIPTION COMPONENT PARTS

BOSCH CC 100 M
User Handbook

CP/MEM

battery


X11
25-pole

X12
25-pole

X21

X22
20-pole

X10
4-pole



Overwrite protection switch for machine parameter area.
I = protected

"Start up" test during the runup phase;
switch position 1 = test active

Buffer battery for data in RAM.

The battery must be replaced yearly.

The battery voltage is checked automatically in a 24 hr cycle and each time the control is switched on. If undervoltage is detected an error is signalled.

With normal battery discharge (no defect on PCB) a further buffer period of at least 14 days is guaranteed after the first error signal.

The CP/MEM incorporates a capacitor for the temporary buffering of the RAM data. If the battery is changed with the control switched off the period for which the supply is interrupted must not exceed 5 min.

To change the battery the battery cover must be opened; the battery is fastened to the cover by means of a mounting.

Battery: 4.5 V alkali battery, part no. 107 - 913 572.

The executive system software is contained on a plug-in PCB (soft-board) under the cover.

To change the software remove the battery cover and withdraw the soft-board. (POWER OFF first!)

Serial Data Interfaces

Interface 1

V.24 or 20 mA

Desired characteristics selected by pin allocation.

Connector: sub-miniature D-type socket.

Interface 2

V.24

Second voltage interface; can be connected in addition to X 11.

Connector: sub-miniature D-type socket.

Ext. VDU monitor (BAS signals)

Connection for an additional VDU with 75 Ohm.

Connector: BNC socket.

Operating panel connection.

Connection between control system and CC operating panel.

Connector: sub-miniature D-type socket with integral coaxial connector.

External 24 V logic DC supply (to supply the VDU in the operating panel)

Connector: Weidmüller terminal strip.

Max. cable size 1.5 mm²


DESCRIPTION

INTERFACES

BOSCH CC 100 M
User Handbook

INTERFACES

INTERFACES, general



The user can connect up to 2 external data terminals at the CP/MEM.

20 mA

1 device of this type can be connected to X11 (see page 1-5).

This interface is particularly suitable for use where long distances are involved and/or where there is a high level of interference in the surroundings.

With this type of interface one side is active (serves as source of current), the other must be made passive. This is achieved by specific pin allocations in the connections (see page 1-10, 1-11).

V.24

1 device of this type can be connected to X11 or X12.

This interface allows higher transfer speeds than the TTY interface but is more susceptible to interference.

Control Signals

DTR Data Terminal Ready: Status of readiness to receive data is output (output signal).

DSR Data Set Ready: Status of permission to send is recognized (input signal).

Note: Switch off handshake by means of a bridge, Pins 4 and 6 at the control side.

Data Lines

TX Data output at the device sending the data.

RX Receipt of data at the receiving device.

Make sure not to confuse the plugs when connecting the devices!
Only connect one device per interface (V.24/20mA) !

DESCRIPTION

INTERFACES

BOSCH CC 100 M

User Handbook

DATA FORMAT

1 start bit, 7 data bits, 1 stop bit, "even" parity bit
(1 start bit, 7 data bits, 2 stop bits, "even" parity bit for 110 Bd)


Control Characters (ASCII)

DC1 Tape reader ON or input START.
DC2 Punch ON or output START. Output comes from the controlling device.
It starts the transmission.

DC3 Tape reader OFF or input STOP.
DC4 Punch OFF or output STOP. Output comes from the controlling device.
It interrupts (stops) the transmission.


STX Start of text.
ETX End of text.
EOT End of transmission.

Sub-miniature D-type connector
25-pole
socket on device
plug on cable




Plug: side for soldering

Reading in Data



Data output



DESCRIPTION


INTERFACES

BOSCH CC 100 M

User Handbook

V.24 CABLE

Cable length	max. 15 m
transfer rate	max. 9600 Baud, always with handshake
Signal levels	high +3 V to +12 V low -3 V to -12 V



Note: X12 interface does not use handshake signals.

DESCRIPTION

INTERFACES

BOSCH CC 100 M

User Handbook

20 mA CABLE

Cable lengths:	CC active	max. 15 m
	CC passive	max. 100 m

Baudrates:
 max. 4800 Bd with handshake
 max. 300 Bd without handshake


Signal levels:	high	approx. 20 mA
	low	approx. 0 mA

max. external voltage drop 2 V

CC active

The CC serves as source of current:

Pin Allocation



DESCRIPTION

INTERFACES

BOSCH CC 100 M

User Handbook

20 mA TERMINAL


CC passive

The peripheral device serves as source of current.

Max. admissible voltage drop in the control 2V.

The supply to the driving device can be up to 24V.

Pin Allocation



DESCRIPTION


PERIPHERALS

BOSCH CC 100 M

User Handbook

PERIPHERALS

CASSETTE UNIT DCR-TERMINAL



GENERAL


- recording process:
ECMA 34
- storage capacity:
256 KB, unformatted
- data format and baudrate
set on back
- parallel and serial
interface

DISPLAYS

- device not ready
- bad cassette
- beginning of recording
- end of recording
- mains and DCR
switched on

OPERATING ELEMENTS

- Read (DCR → serial) -
- Write (serial → DCR) -
- Search backwards -





- Read (DCR → parallel)
- fast rewind
- Search forwards

DESCRIPTION

PERIPHERALS

BOSCH CC 100 M

User Handbook




DESCRIPTION

PERIPHERALS

BOSCH CC 100 M

User Handbook

DCR Rear Panel



Settings:

- CODE:** BIN
- BAUDRATE:** C (= 4800 Bd)
- PARITY:** EVEN
- STOP BIT:** 1 (as in control)
- Connector for use with CC 100 M is **SERIAL**
- Cable used: 046266

Explanations:

NETZ EIN/AUS - MAINS ON/OFF

Schalterst. - switch position

Vor Öffnen des Gehäuses Netzstecker ziehen!

- Unplug mains cable before opening the housing !


DESCRIPTION

PERIPHERALS

BOSCH CC 100 M

User Handbook

MINI CASSETTE UNIT



GENERAL


- recording process:
ECMA 34
- storage capacity:
20 KB each side
- data format and baudrate
set on back
- automatic self-diagnosis
after switch-on with
"Ready" indicator
- serial interface with
V24 or 20 mA

DISPLAYS

- Error ☐ error indicator
- Test ☐ ready indicator

OPERATING ELEMENTS

Write button
(data transfer
CC 100 → Mini-Cass)



Reset button

Read button
(data transfer
Mini-Cass → CC 100)


DESCRIPTION

PERIPHERALS

BOSCH CC 100 M

User Handbook

Rear Panel of MINI CASS



Settings:

1. code: BIN
2. **MODE:** 4
3. **BAUDRATE:** 7 (= 1200 Baud)
4. cable used: 20 mA - 2.5 m part no. 046266

Data carrier:

Digital mini-cassette LDB 400 part no. 910749

Control	Mode	Number of data bits	Parity bit	Start bit	Stop bit	Operating buttons active	Binary data
micro 5/8 CC 100/200/300	4	7	even	1	1	yes	no

PROGRAM HEADER**EXTERNAL PROGRAM PRODUCTION**

The following text explains the methods by which part programs and part program type subprograms (or cycles) are produced.

Such programs are constructed from program language elements to DIN 66025 and can be produced by one of the following methods:

1. via keyboard input, using the program editor in the NC
2. via the manual panel with 'Teach In', in the NC
3. via a programming unit onto a data carrier (paper tape, for instance), outside the NC
4. by computer, outside the NC

Programs produced outside the NC must conform to the NC machine code and the NC syntax.

In addition programs which are input from a data carrier (tape or digital cassette) or via an interface (V24/20 mA) must have a leader (header) and a trailer. Leader and trailer, the beginning of the individual program lines, as well as the program identifications of the header lines of data blocks must be provided in the correct format.

Note:

When data needs to be transmitted the external data carrier must be activated before the control.

DESCRIPTION

PROGRAM HEADER

BOSCH CC 100 M

User Handbook

PROGRAM HEADER IN DFS FORMAT

The CC 100 program header in DFS format has been designed on the basis of the header format of the cc 200/300, in order to create uniformity in this area for the future. Specific types of files can be loaded and output.

The uniform DFS program header has the following (basic) format:

(DFS * , * file type * file number [, * [file *] suffix*] , * access level)

At the positions indicated by an asterisk it is possible to insert one, several or no space character (s).

Different possibilities

(DFS, Pxx)
 (DFS, Pxx, . suffix)
 (DFS, Pxx, name . suffix)
 (DFS, Pxx, . suffix, RWED)
 (DFS, Pxx, name . suffix, RWED)

Explanations

- DFS

Identification of the program header in DFS format (defined storage).

- File type

Specific letters identify the file type:

P = program
 C = cycle
 E = text
 K = compensation table (K0)
 V = zero shift table (V0)
 X = variables (X0)
 L = machine parameters

File number

- Program numbers can contain up to 9 digits, cycle numbers up to 2 digits.

File name

The file name can contain up to 15 characters, which can be letters as well as numbers. Tables are transferred without name. The file type to be transferred is simply identified as X0, V0 or K0.

DESCRIPTION

PROGRAM HEADER

BOSCH CC 100 M

User Handbook

- Suffix

The suffix consists of one letter and determines the dimensioning method (I = inch/M = metric).

It is separated from the file name by a decimal point.

- Access level

The access level is defined by a 2-character code.

2-char.: RE (read, execute)

4-char.: RWED (read, write, execute, delete)

Note

Input of file name, suffix and access level is not compulsory.

They are purely optional.

If no file name is programmed the suffix can be omitted. The control will then automatically assume the dimensioning to be metric (= suffix M).

If a file name is stated in the program header the suffix must be entered too.

Examples of DFS program header for different file types

(DFS, P12)	- transfer of a single program, program number 12
(DFS, P10.M)	- transfer of a metric program, program number 10
(DFS, C 4, TOOL CHANGE . I)	- transfer of the tool change cycle in inch format
(DFS, P1, TEST RAPID.M,RWED)	- transfer of program P1 with metric dimensions under access level RWED
(DFS, X0)	- transfer of the variable table
(DFS, K0)	" compensation table
(DFS, V0)	" zero shift table

DESCRIPTION

PROGRAM HEADER

BOSCH CC 100 M

User Handbook

Exemples:

(DFS,P 1,TEST RAPID.H,RWED)

(DFS,C 79,.H,RWED)

(DFS,K 0)

(DFS,X 0)

(DFS,V 0)

OPERATING SEQUENCES FOR OUTPUT AND INPUT

The files to be **output** are determined via soft key and marked on the screen in reverse video:

SELECTED FILE ONLY

- Output if specific file had previously been selected.

PROGRAMS OR CYCLES

- Output if no specific file had previously been selected. Whether programs or cycles are output depends on the file type active at the time.

PROGRAMS AND CYCLES

- Selection via soft key.

FILE + TOOLS

FILE + ZERO SHIFT

FILE + VARIABLES

- Output of a specific file, as well as tool, zero shift or variable file.

Files to be **loaded** can be transferred several at a time in any sequence.

If loading via interface is selected in main mode MEMORY a specific number of files can be selected by soft key operation:

ALL FILES	START	PORT NO	BAUDRATE	CONTROL
YES NO				YES NO

How many? (1...99)

DESCRIPTION

PROGRAM HEADER

BOSCH CC 100 M

User Handbook

CHECKSUM

- Whatever the tape format, programs can be output with or without checksum.
- The DFS program header is output without checksum.
- In each program block the checksum is inserted directly before the CR LF control character.

Position, calculation, input/output of the checksum

1) Position of the checksum

At the end of the data and before CR LF, a space, the character ":" and then the checksum value (a 2-digit number) are written.

e.g. N-11- - - G1 CR LF becomes
N-11- - - G1-:nn CR LF

- = space
- nn = 2-digit number for the checksum

2) How to calculate the checksum

Every character between the LF of the previous line and the ":" is included into the checksum calculation. The ASCII value of each character is added up and multiples of 256 are removed until 255 or less remain, and this remainder is converted into a hexadecimal number.

e.g. N-11- - -G1-:nn CR

CODE	ASCII VALUE
N	78
-	32
1	49
1	49
-	32
-	32
-	32
G	71
1	49
-	32

$$456 - 256 = 200 = C8$$

The block will now read: N-11- - -G1-:C8 CR LF

3) Input/output of the checksum

INPUT

- SK "CONTROL YES" active - control checks syntax
- SK "CONTROL NO" active - control checks the checksum, if it exists, otherwise it checks the syntax

OUTPUT

- SK "CHECKSUM YES/NO" is called up via SK "FORMAT".
- SK "CHECKSUM YES" active - programs are stored **with** checksum
- SK "CHECKSUM NO" active - programs are stored **without** checksum





2. OPERATING

OPERATING MAIN MODES

BOSCH CC 100 M User Handbook

MAIN MODES

SURVEY The operation of the control is subdivided into the following main modes, which are directly selectable by pushbuttons:

EDIT	MACHINE	AUTOMATIC	INFO
			
working with stored data	manual operation	execution of programs	additional information
display input, modification of: programs, subprograms, cycles, tools zero shifts variables	direct execution without storage execution of cycles reference axes, reference cycle, MDI, manual machine, operation, teach in	execution of stored programs, cycles execution continuous/ block by block, variable step size, block selection, break points, reentry	status displays, NC/IO, axis displays, error list deletion of: programs, variables, tool/zero shift tables control reset
input and output via data interfaces V.24/20 mA	customer keys handwheel jog buttons	with/without path compensation tool length compensation	MTB SERVICE only for machine tool builder
baudrates	distance to go display	CPC test distance to go display	SERVICE load M-parameters
automatic generation of header lines for PROGRAM/ CYCLE etc.		milling conditions	logbook set clock mode read in text

The active main mode is displayed continuously in the top right corner of the screen.

To come out of the current main mode altogether:

Use the page back button to revert through the levels until the 1st soft key level is reached, then select new mode. Exception: For change-over MEMORY/EDIT to AUTOMATIC no paging back required.

To come out of the current main mode temporarily:

Select a different main mode directly. The old main mode is retained in the background (display flashes) and can be reactivated by pressing the relevant mode key once more.

OPERATING MAIN MODES

BOSCH CC 100 M User Handbook

Subdivision of VDU Display

active data block		active main mode		
data depending on main mode				
command line				
SK1	SK2	SK3	SK4	SK5

data blocks:

program
cycle
variable table
zero shift table
tool table

Reset Conditions

Immediately after switch-on the following modal conditions are active:

G1 linear interpolation
 G17 plane X/Y
 G39 programmed mirror image off
 G40 radius compensation off
 G53 no zero offset
 G62 in position operation off
 G65 programmed feedrate applies to cutter centre path
 G66 feedrate and spindle speed can be modified
 G68/ G69 contour transition as arc/intersection (dependent on machine parameter)
 G80 no fixed cycle active
 G90 absolute dimensions
 G94 feedrate in mm/min
 G97 direct spindle speed programming
 scale for factor 1
 no feedrate effective

These modal conditions are active in all main modes.

The G-codes which become active on switch-on are denoted with an "A" in the following descriptions, i.e. G39A.

Note

When working in AUTOMATIC or MACHINE mode the control will output the following types of messages, as and when appropriate:

MESSAGE xxx - further operation possible

ERROR xxx - further operation is inhibited

The content of the message can be displayed in INFO mode.

OPERATING MAIN MODES

BOSCH CC 100 M User Handbook

EDIT



Access to Data

In this main mode all user data can be handled (see EDITOR).

Selectable data blocks:

- tool table
- zero shift table
- variable table
- programs
- cycles

The menu for part programs and cycles can be paged forwards with soft key "NEXT PAGE".

Access Levels

Unauthorized accessing of the data can be prevented via softkey operation. Execution is always permitted.

The access levels are expressed as follows:

- RWED read, write, execute and delete are possible
- RE only reading and executing are possible
- E only executing is possible (cycles only)

Dimensioning

The dimensions can be selected by soft key to be in metric or inch.

Display in index and in "active datablock" line:

- M metric
- I inch

Commands

Under this SK the following functions are available in 2 levels:

- | | |
|-------------------------------|-------------------|
| - resequence block numbers | - copy file |
| - transfer program to a cycle | - file protection |
| - rename a file | - delete file |
| - inch/metric | |

Data Interfaces


See chapter on "Data Handling"

Copy

Programs stored in the memory can be duplicated with SK function "COPY". The user must enter a new file name and the control will select the file number.

OPERATING MAIN MODES

BOSCH CC 100 M
User Handbook



Cursor Functions


Switch-over between MODIFY/INSERT

MODIFY
INSERT

Scrolling blocks up/down by simultaneous actuation of



Moving cursor sideways



Block Selection

The cursor is placed to the right of the position at which a letter is to be inserted/modified.

Search Functions

A characteristic string (sequence of letters, numbers and characters) from the required line is entered, i.e. G41.

ENTER


Delete

- individual character to the left of the cursor



Line Delete

- content of the line to the right of the cursor is deleted



Modify

- First delete individual character,
- then key in new character(s)



ENTER

Insert

- enter new character(s)

INSERT

ENTER

OPERATING MAIN MODES


BOSCH CC 100 M User Handbook

MACHINE



MANUAL MACHINE OPERATION

The manual panel is always activated in MACHINE mode.



MDI

After SK selection of MDI one block can be executed after the relevant data has been entered. The execution is initiated with the start button.

Under the SK HELP the permanently stored drilling and milling cycles can be selected, parameterized and executed, as well as the user-definable cycles.

REFERENCE AXES	REFERENCE CYCLE	MDI	TEACH IN	INCH METRIC
-------------------	--------------------	-----	----------	----------------

HELP	←		→	CLEAR BLOCK
------	---	--	---	----------------


			BORING CYCLES	CONTOUR CYCLES
--	--	--	------------------	-------------------

MTB-specific soft keys (cycles)

Note:

- It is not possible to return to previous SK levels while a block/cycle is being executed.
- G41/G42 are not permitted.
- MTB cycle PRIOTITY ROUTINE can not be called up.
- Axes which have been driven onto the software limit switches can only be moved by means of the JOG

buttons



in reverse direction.

When working in manual mode the type of traversing movement needs to be defined:

- With the jog buttons the axes can be traversed individually in incremental steps (of 1, 10, 100, 1000 or 10,000 increments). The max. feedrate corresponds to the limit determined by the machine parameter for manual feed (1 - 120,000 mm/min).
- The electronic handwheel can be activated for individual axes.
- Change-over between feed and rapid.

OPERATING MAIN MODES

BOSCH CC 100 M User Handbook

TEACH IN

Definition

By tracking the outline of a sample contour with the machine the specific contour features are recorded by key actuation (soft key RECORD). During this procedure the control stores the position values of all axes. A circular movement is generated by positioning to three points of the circle (soft key CIRCLE COMPUTE).

MDI function

As in MDI mode blocks can be keyed in. The data is transferred into memory with SK "RECORD".

Operating

Main mode MACHINE



REFERENCE AXES	REFERENCE CYCLE	MDI	TEACH IN	INCH METRIC
-------------------	--------------------	-----	----------	----------------

RECORD	←	CIRCLE COMPUTE	→	CLEAR BLOCK
--------	---	-------------------	---	----------------

Function Keys

RECORD

- Storing positions of moved axes
- Storing entered blocks
- Storing positions of blocks generated internally

CIRCLE COMPUTE

- Automatic calculation of circles
- The CC 100 calculates circle data from 3 scanned points (SK 'RECORD POINT 1', 'RECORD POINT 2' and 'RECORD POINT 3')
- Circular interpolation G2/G3 is also modal in TEACH IN mode.
If a linear movement is to follow G0/G1 must be programmed:
Key in G0/G1 before the linear movement and transfer into memory with SK RECORD.

CLEAR BLOCK

- Clearing blocks which have not yet been stored from the edit line.

**OPERATING
MAIN MODES****BOSCH CC 100 M**
User Handbook**TEACH IN****Calculation of
Circles with
Parameter R**

The control calculates the radius R from the 3 recorded axis positions and generates the circular contour.

The current axis position is the 1st point for the calculation of the circle.

The display will show the last axis position with the calculated radius.

Display

G2/3 X... Y... R...

The block is stored with soft key RECORD.

Note

- The CC 100 automatically generates a program with the name "TEACH IN".
If a program with this name is already stored in the memory, this program has the newly entered TEACH IN functions added to it.
If several independent programs are to be generated via TEACH IN, the old program must first be renamed in EDIT mode with SK RENAME.
- Switching of the dimensioning unit INCH/METRIC during TEACH IN operation is not permitted.
Should it be attempted an error message will be displayed:
"inch/metric selection incorrect".

OPERATING MAIN MODES

BOSCH CC 100 M User Handbook

AUTOMATIC



Execution of programs and/or cycles from memory.

PROGRAM / CYCLE - Selection

The stored cycles and programs are listed in ascending numerical order. The selection is made by entering the name or the number.

OPERATING PROCEDURE BEFORE START OF PROGRAM/CYCLE

NORMAL step: no

DRY RUN RAPID	STEP	SELECT BREAKPOINT	MILLING CONDITIONS	SELECT STARTPOINT
------------------	------	----------------------	-----------------------	----------------------

setting a
break point
in the program

setting a
program start
point

Selection of:

DRY RUN - test without movement
RAPID - test in rapid
NORMAL - execution as per program
active mode displayed in the
prompt line.

selection of step size (1-9):

1 : single block
2 : double block

9 : ninefold block
(= stop every 9 blocks)

Note:

If a start point has
been selected and
the program is restarted
after M30 the execution
will begin at the set
start point.

COLL TEST ON/OFF	WITH STOP YES/NO	LENGTH COMP ON/OFF	CUT. COMP ON/OFF	CPC TEST
---------------------	---------------------	-----------------------	---------------------	-------------

when executing
programs with
path compensation
the tool coll.
monitoring can
be switched off
(shortening of
block cycle
time)

during dry run,
if YES the
program stops
at error found;
if NO the
program runs
to the end;
errors are
displayed in
INFO mode

switching off tool
compensation for
test purposes

CPC test facilitates
the DEBUGGING of
parametric programs

OPERATING MAIN MODES

BOSCH CC 100 M User Handbook

AUTOMATIC

INTERRUPTION / RE-ENTRY during program execution

Possibility of external intervention by the operator with tool compensation active / not active, after at least one block has been executed completely:

Sequence

a) Cycle stop



Response of machine
and possible actions:

feed hold is effective

b) Press



manual mode/MDI are activated

c) Manual intervention

manual panel is active, spindle
can be stopped or oriented


movement away from contour for
measuring purposes, for instance

d) Tool change with

- replacement by identical tool
- replacement by a different tool

old values are retained,
input of new tool data is
possible (tool wear is set to 0)

Tool Change



it is also possible to
modify the active block;
re-entry onto linear and
circular contour elements

e) Drive to suitable position S to
start re-entry


**This position must allow
direct traversing onto the
contour.** (no automatic evasion
of obstacles)

f) Press



control drives back onto the
contour, with the tool centre
vertical above the beginning of
the unfinished contour-program
execution is resumed

g)




Note:

- G92 must not be active (see chapter 3)
- If main mode AUTOMATIC is selected between exit and reentry the reentry operation is abandoned and the basic display for main mode AUTOMATIC is displayed. Continuation is possible via reselection of the program and CYCLE START.

OPERATING MAIN MODES

BOSCH CC 100 M User Handbook

OPERATING PROCEDURE AFTER CYCLE START



After selection of block or a jump target the previous SK line will appear once more. The breakpoint should then be set.

OPERATING MAIN MODES

BOSCH CC 100 M User Handbook

TABLES

DRY RUN RAPID	STEP	SELECT BREAKPOINT	BREAKPOINT	TABLE
------------------	------	----------------------	------------	-------

TOOLS	ZERO SHIFTS	VARIABLES	-	
-------	----------------	-----------	---	--

Zero shifts and variables can be checked, tools can be checked and edited.

TOOLS

TOOLS	ZERO SHIFTS	VARIABLES		
-------	----------------	-----------	--	--

Tool data appears in the edit line.

TOOL NUMBER	↓	SCROLL		
----------------	---	--------	--	--

Tool data can be selected directly via their number (+ ENTER) or by cursor control. The cursor is positioned on the DR value (wear). The wear value compensation value can now be updated by an incremental input. Conclude with ENTER (see p. 4 - 1).

ZERO SHIFTS

TOOLS	ZERO SHIFTS	VARIABLES		
-------	----------------	-----------	--	--

Zero shift data appears in the edit line.

ZERO SHIFT NUMBER	↓	SCROLL	↑	
----------------------	---	--------	---	--

Direct selection via number (+ ENTER) or by cursor control (+ SCROLL).

VARIABLES

TOOLS	ZERO SHIFTS	VARIABLES		
-------	----------------	-----------	--	--


VARIABLE NUMBER	↓	SCROLL	↑	
--------------------	---	--------	---	--

Operating and function as for zero shifts.

OPERATING MAIN MODES

BOSCH CC 100 M User Handbook


INFO



The **INFO** mode is subdivided into two separate sections:

- the machine tool builder section, protected by the MTB code
- the user section.

Within the user section additional information is made available to the operator.



CC 100M STATUS - Display of the set modal functions, potentiometers, zero shifts, scale factors, SW limit switches

I/O STATUS - Status of the CNC-PIC interface

MESSAGE LIST - Display of the last 10 error texts with error number and error location (program, block)

**OPERATING
MAIN MODES****BOSCH CC 100 M**
User Handbook

selection

CC 100M STATUS	EXTERNAL STATUS	MESSAGE LIST	AXES DISPLAY	PIC/PLC DISPLAY
-------------------	--------------------	-----------------	-----------------	--------------------

TABLE	LIST			
-------	------	--	--	--

TABLE	LIST	PAGE +	PAGE -	
-------	------	--------	--------	--

Display of machine status conditions, defined by MTB

(Seperate DNC description in preparation)

OPERATING MAIN MODES

BOSCH CC 100 M User Handbook

AXES DISPLAY

THE FOLLOWING SOFT KEYS APPEAR:

COMMAND POSITION	LAG	MACHINE POSITION	DISTANCE TO GO	INCH METRIC
---------------------	-----	---------------------	-------------------	----------------

COMMAND POSITION

- The programmed position is displayed.

LAG

- The lag, (also called following error), is displayed.

MACHINE POSITION

- The actual position is displayed as long as there are neither zero shifts nor G92 active.
The MACHINE POSITION results from the COMMAND POSITION minus the lag.

DISTANCE TO GO

- The difference between the programmed command position and the actual position, i.e. the distance to go, is displayed.

INCH METRIC

- The default setting is metric. The dimensioning system selected with this soft key determines the display in the other main modes; a change-over is however also possible in these modes.

PIC/PLC DISPLAY

The PIC program is displayed and the following soft keys are offered:

SEARCH	↑	↑	TABLES	TRIGGER
--------	---	---	--------	---------

SEARCH

With this soft key

- addresses
- instructions (command + operator)
- commands (CMD)
- operators

can be searched for and displayed, entered either with the full number or part of the number or without the number.

If a string is not found the message STRING NOT FOUND appears in the edit line.
If an instruction, a command etc. is not found the NC gives the message NOT FOUND in the edit line.


SOFT KEYS

- The program display can be scrolled up and down line by line (no repeat function)



TABLES

- makes the following soft keys available:



soft keys

INPUT

OUTPUT

TEMP.STORE

- These soft keys are used to select the corresponding data or clear them from the screen. Selected data is marked by highlighting of the corresponding soft key. Data used in the NC-PLC interface are highlighted in the display. Several or all sets of data can be selected simultaneously.


soft keys



- The selected data displayed on the screen can be scrolled up or down line by line (no repeat function).

TRIGGER

- makes the following soft keys available:



soft keys

LOW, HIGH

- The trigger function responds to a low signal or a high signal.

soft keys



- The trigger function responds to a rising or falling edge.

If one of these soft keys is actuated the following soft keys appear:



The selected trigger condition is displayed in the highlighted line at the top of the screen.

OPERATING MAIN MODES

BOSCH CC 100 M User Handbook

The highlighted line at the top of the screen contains the following information:

STATUS	SIGNAL TYPE	INSTRUCTION	ADDRESS
--------	-------------	-------------	---------

STATUS

- waiting for
(signal has not occurred yet)
- triggered
(signal has occurred)

SIGNAL TYPE as selected by soft key

- low level
- high level
- rising edge
- falling edge

INSTRUCTION - instruction marked by the cursor in the displayed program

ADDRESS - address of the displayed instruction

While the trigger function is switched on it is possible to page through the program. Soft key TRIGGER OFF switches the trigger function off. The purpose of the trigger function is the monitoring of signals which occur intermittently; it is an important aid for fault finding.

LINES SERVICE SOFTKEY LINE FOR DNC OPERATION

Lines service

PORT SET UP		DNC RESET	STATUS MASK	DNC ON OFF

(separate DNC description in preparation)

OPERATING MAIN MODES

BOSCH CC 100 M
User Handbook

DIMENSIONING - SWITCHING BETWEEN INCH/METRIC

MEMORY mode

TOOLS	ZERO SHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	----------------	-----------	----------	--------

ACCESS ON/OFF		EDIT		SAVE
------------------	--	------	--	------

ACCESS ON/OFF	INCH METRIC	EDIT	LOAD	SAVE
------------------	----------------	------	------	------

TOOLS	ZERO	VARIABLES	PROGRAMS	CYCLES
-------	------	-----------	----------	--------

	NEXT PAGE		LOAD	SAVE
--	--------------	--	------	------

e.g. 1 **ENTER**

COMMAND	NEXT PAGE	EDIT	LOAD	SAVE
---------	--------------	------	------	------

		INCH METRIC		RENAME
--	--	----------------	--	--------

VARIABLES can not be switched to INCH/METRIC.
Whether the file types, tools and zero shifts are to be
effective in metric or inch is determined by soft key.

Effect:

The file types program and cycles are stored with the
dimensioning index I/M. Metric is preset for new files.

OPERATING MAIN MODES

BOSCH CC 100 M User Handbook

MACHINE mode

In main mode MACHINE the INCH/METRIC switching is effected in the first soft key line:

REFERENCE AXES	REFERENCE CYCLE	MDI	TEACH IN	INCH METRIC
-------------------	--------------------	-----	----------	----------------

Effect:

The selection is effective for all functions in MACHINE mode.
The selection is retained even after a hardware reset and it also applies after a switch into INFO mode.

AUTOMATIC mode

File types such as programs and cycles are already defined with respect to the dimensioning during the generation process. The chosen dimensioning method also applies for the execution.

INFO mode

The axis measurement format (INCH/METRIC) selected in INFO mode sets the priority for the axis display in machine mode.

MACHINE STATUS	SERVICE	MTB SERVICE	LINES SERVICE	RESET DELETE
-------------------	---------	----------------	------------------	-----------------

CC 100M STATUS	I/O STATUS	MESSAGE LIST	OTHER SELECTION	PIC/PLC DISPLAY
-------------------	---------------	-----------------	--------------------	--------------------

CC 100M STATUS	EXTERNAL STATUS	MESSAGE LIST	AXES DISPLAY	PIC/PLC DISPLAY
-------------------	--------------------	-----------------	-----------------	--------------------

COMMAND POSITION	LAG	MACHINE POSITION	DISTANCE DISPLAY	INCH METRIC
---------------------	-----	---------------------	---------------------	----------------

- The desired dimensioning method is selected for the particular axis display (command/position, machine position, lag, distance to go).
- On switch-on the dimensioning method last active is reactivated.


DATA HANDLING

GENERAL

LOAD / SAVE

The CC100M has two serial data interfaces, the sockets of which are located on the CP/MEM board.

The first interface, which is identified by the control as "Port No. 1", is connected to socket X11. The second interface, identified as "Port No. 2", is connected to socket X12.



Input and output of data is possible in main modes INFO and EDIT. Interface selection and parameterisation are made via soft keys.

In main mode "EDIT" the following types of data can be loaded and saved:

(soft keys:)

TOOLS	ZERO SHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	----------------	-----------	----------	--------

In "INFO" mode it is possible load machine parameters, M-functions, texts and graphics.

Programs, tools, zero shifts and variables can only be cleared.

OPERATING DATA HANDLING

BOSCH CC 100 M User Handbook

LOAD

Operating procedure:

- Select main mode EDIT



- Actuate soft keys as shown below:

TOOLS	ZERO SHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	----------------	-----------	----------	--------

	NEXT PAGE		LOAD	SAVE
--	-----------	--	------	------

- Optional: Key in program number or name and press "ENTER".

COMMAND	NEXT PAGE	EDIT	LOAD	SAVE
---------	-----------	------	------	------

ALL FILES	START	PORT NO	BAUDRATE	CONTROL
YES NO				YES NO

- Soft key "ALL FILES"

"YES" selected: All files on the data carrier are loaded.

"NO" selected: Only the specified number of successive files (number is requested) are loaded.

- Soft key "START": The loading operation is started; the control waits for data. After the initial actuation the soft key changes to "STOP" and can be used to stop the data transfer.

- Soft key "PORT NO": Enter port number 1 or 2. The corresponding interface (X11 or X12) will be activated.

- Soft key "BAUDRATE": Set baudrate. A list of the code numbers for the baudrates appears on the screen. The baudrate set on the control must be the same as the one set on the peripheral.

- Soft key "CONTROL YES/NO":
With CONTROL YES the syntax is checked.

With CONTROL NO only the checksum is checked, if it exists.

If the program or cycle does not contain checksums the control will carry out a syntax check.

Note

Under SK "PROGRAMS" it is also possible to load cycles, tool compensations, zero shifts and variables; the same applies for SK "CYCLES". Cycles are loaded in succession, like the programs. When the last program or cycle has been loaded the load operation is stopped. If there are tool, zero shift and variable files on the data carrier loading is stopped after each file, if an EOT signal separates the files. If the subsequent files are to be loaded too SK "START" must be actuated for each one.

Protection

When loading data via serial interfaces programs are automatically protected against overwriting. If a program is loaded which is already stored in the memory the control will ask whether to

- overwrite the existing program (input 1)
- store the program under a new number (input 2)
- abort the loading operation (SK "STOP")


A program with overwrite protection can not be overwritten.

Error message: "file protected".

SAVE

Operating procedure:

- Select main mode EDIT



- Actuate soft keys as shown below:

TOOLS	ZERO SHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	----------------	-----------	----------	--------

	NEXT PAGE	LOAD		SAVE
--	-----------	------	--	------

- Optional: Key in program or cycle name or number and actuate "ENTER".

ANOTHER SELECTION	START	PORT NO	BAUDRATE	CHECKSUM YES/NO
----------------------	-------	---------	----------	--------------------

The screen displays the message "SELECTED FILE ONLY" (highlighted characters)

- Soft keys "START", "PORT NO" and "BAUDRATE" are operated as for loading.
- Soft key "CHECKSUM" switches the generating of a checksum, which is to be output, on and off.

PROGRAMS + CYCLES	START	FILE + TOOLS	FILE + ZEROSHIFTS	FILE + VARIABLES
----------------------	-------	-----------------	----------------------	---------------------

OPERATING DATA HANDLING

BOSCH CC 100 M User Handbook

- Soft key "PROGRAMS + CYCLES" determines whether only either programs or cycles are to be saved, depending on the selection in the first SK line, or whether programs and cycles are to be output. (Display with highlighted characters.)
The page back button resets the display to "SELECTED FILE ONLY".
- Soft keys "FILE + TOOLS", "FILE + ZEROSHIFTS" and "FILE + VARIABLES". When one of these is selected the corresponding term will be displayed in highlighted characters.

Note

If one of these soft keys is selected the parameters "from" and "to" must be defined. Unless this is done no page back or other selection is possible.

The parameter ranges are as follows:

tools 1 - 48; input e.g.: 1, 7, 14, 15, 16, 23, 44
zero shifts 54 - 59; input e.g.: 54, 57, 58
variables 1 - 99, A - Z; input e.g. 7, 9, 10, 25, 49, A, C, L, X

Only the numbers should be entered, not the associated letter codes. The sequence for the variables is numbers first, then letters.

Output without file selection:

TOOLS	ZERO SHIFTS	VARIABLES	PROGRAMS	CYCLES
	NEXT PAGE		LOAD	SAVE
PROGRAMS + CYCLES	START	PORT NO	BAUDRATE	FORMAT
		CHECKSUM YES NO	FORMAT DFS CC100	

Soft key "PROGRAMS + CYCLES" offers the choice of outputting programs or cycles. Either programs or cycles are preselected, depending on the choice made in the first soft key line.

Comment

During the output of programs and cycles the selection of the dimensioning unit "INCH" or "METRIC" is output in the program header.

Delete

Main mode INFO



Operating procedure:

- Activate main mode "INFO"
- Continue with soft key operation

MACHINE STATUS	SERVICE	MTB SERVICE	LINES SERVICE	RESET + DELETE
-------------------	---------	----------------	------------------	-------------------

OPERATING DATA HANDLING

BOSCH CC 100 M User Handbook

DELETE TOOLS	DELETE ZEROSHIFTS	DELETE VARIABLES	DELETE PROGRAMS	CONTROL RESET
-----------------	----------------------	---------------------	--------------------	------------------

The selected soft key is highlighted on the display.

The delete operation can be aborted with the page back button.

Caution

When the "ENTER" key is pressed all programs will be deleted, even those with write protection.

Delete function in main mode EDIT



In main mode "EDIT" programs are deleted individually (or cycles, depending on the soft key selection), and only those without read/write protection can be deleted in this mode.

Operating procedure:

- Select main mode "EDIT"
- Continue with soft key operation:

TOOLS	ZERO SHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	----------------	-----------	----------	--------

	NEXT PAGE		LOAD	SAVE
--	-----------	--	------	------

Select program or cycle by name or number.

COMMAND	NEXT PAGE	EDIT	LOAD	SAVE
---------	-----------	------	------	------

COMMAND	PROTECTION ON OFF	INCH	DELETE	RENAME
---------	----------------------	------	--------	--------

Note

If an attempt is made to delete a program or cycle with read/write protection the message "file protected" will appear on the screen.

In "EDIT" mode it is not possible to delete tool data, variable data and zero shifts.

OPERATING DATA HANDLING

BOSCH CC 100 M User Handbook

TOOLS, ZERO SHIFTS, VARIABLES

These types of data can be loaded and saved in "EDIT" mode;
they can only be deleted in "INFO" mode.

Load

Main mode EDIT



Soft keys:

TOOLS	ZEROSHIFTS	VARIABLE	PROGRAMS	CYCLES
-------	------------	----------	----------	--------

ACCESS ON/OFF		EDIT		SAVE
------------------	--	------	--	------

ACCESS ON/OFF	INCH METRIC	EDIT	LOAD	SAVE
------------------	----------------	------	------	------

The soft key "INCH/METRIC" does not appear for variables.

	START	PORT NO	BAUDRATE	
--	-------	---------	----------	--

Note

Data can also be loaded under "PROGRAMS" or "CYCLES"

Write protection is then not effective. The selection of inch or metric made in this way
is not stored on the data carrier and must be made at the control.

OPERATING DATA HANDLING

BOSCH CC 100 M User Handbook

Save

TOOLS	ZEROSHIFTS	VARIABLES	PROGRAMS	CYCLES
-------	------------	-----------	----------	--------

ACCESS ON/OFF		EDIT		SAVE
------------------	--	------	--	------

	START	PORT NO	BAUDRATE	FORMAT
--	-------	---------	----------	--------

		CHECKSUM YES NO	FORMAT DFS CC100	
--	--	--------------------	---------------------	--

The delete function in "INFO" mode works as described in chapter "Load and save programs and cycles".

Machine Parameters, Text Strings and Graphics

In "INFO" mode these types of data can only be loaded.

Operating procedure:

- Select "INFO" mode with  key.

- Continue with soft key operation:

	SERVICE	MTB SERVICE	LINES SERVICE	RESET DELETE
--	---------	----------------	------------------	-----------------

LOAD MACH. PARAMETER	LOGBOOK	SET CLOCK	MODE	LOAD TEXT
-------------------------	---------	--------------	------	--------------

	START	PORT NO	BAUDRATE	
--	-------	---------	----------	--

Note

During the loading operation the data previously in the memory is overwritten. Enter only the appropriate data under the selected type of data, i.e. do not select soft key "LOAD TEXT" if you have previously selected LOAD MACHINE PARAMETERS.


OPERATING DATA HANDLING

BOSCH CC 100 M User Handbook

Logbook

If a logbook exists the data can be output in "INFO" mode.

Operating procedure:

- Select main mode "INFO" with  key.
- Continue with soft key operation:

MACHINE STATUS	SERVICE	MTB SERVICE	LINES SERVICE	RESET DELETE
-------------------	---------	----------------	------------------	-----------------

LOAD MACH. PARAMETER	LOGBOOK	SET CLOCK	MODE	LOAD TEXT
-------------------------	---------	--------------	------	--------------

ACTIVATE LOGBOOK	LOGBOOK DISPLAY	CLEAR LOGBOOK	SAVE LOGBOOK	
---------------------	--------------------	------------------	-----------------	--

	START	PORT NO	BAUDRATE	
--	-------	---------	----------	--

Note

If no logbook has been generated the soft key "LOGBOOK DISPLAY" will not be displayed.

3. PROGRAMMING

GENERAL

Program Production

Part programs can be produced by the following methods:

- directly at the control via panel input in modes EDIT or MACHINE (TEACH IN) or
- at programming stations For transmissions please note the instructions in sections:
DATA INTERFACES (chapter 1)
Data handling (chapter 2)

Memory Allocation

The following types of user data are stored in the control:


Memory areas	Contents
part program memory	part programs and cycles, with the relevant subprograms
technology table	tool geometry and tool wear data, cutting speeds
zero shift table	zero shifts G54 to G59
variable table	CPC variables VI-V99 and VA-VZ
machine parameter memory	machine specific data

Basic Conditions

Descriptions in the programming instructions relate to the control as used on a machine tool (milling machine) with a Cartesian axis configuration within a clockwise coordinate system. Unless otherwise stated the following G-functions are assumed to be active:

G17	plane XY
G27	no field limitation
G40/T00	no tool compensation
G53	no zero shift active
G62	in position function off
G90	absolute dimensions

The reset status or the status after switching to automatic mode is indicated by 'A'.



Up to 99 suprograms can be assigned to a program or cycle.

Main programs and their subprograms can call up cycles.

From within cycles and their subprograms other cycles and subprograms can be called up, up to a 10-fold total nesting depth.

● call-up source

PART PROGRAMS AND CYCLES

A program or a cycle describes a sequence of machining operations and is subdivided into blocks. The blocks contain preparatory functions, axis information, miscellaneous and auxiliary functions.

Block

A block is made up of the block number and one or several words.

Example: N120 G0 X100 Z100 M3 S1000

The block length is variable. During external programming the words can be written in any order. The block number must be at the beginning of the block. No space characters required between blocks. But note the gap between the block number and the first word (see transmission protocol, p. 3-4).

Word

A word consists of an address letter and a sequence of figures, which represent the address contents.

Only those figures which contain information need be written.

N10 G0 X5.100 Z0.500 M3 T01 or
 N10 G0 X5.1 Z.5 M3 T01

Blocks are built up from individual words which begin with an address letter.

Example: N 120 X 125 Z 160

With DIN programming an address may only be programmed once in each block.

Block Numbers

The first word of a program block is the block number. It is made up of the address letter "N" (ISO format) and a 1 to 4-digit sequence of figures.

- sequence

During **external** program production no block numbers need to be programmed. The control will store data in ascending order.

During **panel input** the control generates the block numbers automatically in the course of the input dialogue.

- steps

Block numbers are programmed or generated in steps of 1. If additional blocks are entered via "INSERT" the control will mark these blocks with a "+". The jump addresses remain valid after insertions or deletions since they are marked with symbolic "labels".

PROGRAMMING

General

BOSCH CC 100 M

User Handbook

The control can store 1 or several user programs. During the programming these programs can be marked as main programs, or subprograms (SBP), or cycles.

Program A program is defined by the

- HEADER in the first line and
- PROGRAM END instruction in the last line.

data type 'part program'

Header

PROGRAM.....1.....Name M RWED4

program metric access soft key no.
number and name for "PROGRAMS"
(4th from left)

The header line is generated automatically by the control after call-up of the program or input of the program name.

Program end

M2 program end

M30 program end - renewed execution with CYCLE START

Subprogram Subprograms are of local character: i.e. they are always assigned to a specific program. Subprogram numbers may be used repeatedly as long as they are assigned to different programs.

A subprogram (SBP) is defined by

\$.. up to 2-digit subprogram number in first line

G99 subprogram end in the last line

The subprogram and the main program are stored in the same file.

Cycle Cycles are of global character.

In other words: Each cycle number may only be used once in the program memory, but can be called up from each program/subprogram or with a direct call-up.

data type 'cycle'

Header

....CYCLE.....n..... xxx M RWED5

cycle number and name metric access soft key no. for "CYCLES"

Cycle end

M2 cycle end

During panel input the headers are generated by soft key selection.

PROGRAMMING**General****BOSCH CC 100 M****User Handbook****Jump
Instructions**

Program jumps can be used for a more efficient usage of the individual program segments.

The jump instructions relate to jump addresses (labels) which are to be previously defined. These symbolic addresses are retained even when program alterations are carried out by inserting or deleting blocks.

Programming of

G24 P x x (unconditional jump)

or

G23 P x x (conditional jump)

P = jump address number

effects branching to a program line

which is marked as a jump address:

\$ x x.

Example

N10

N11 \$ 2

N12 X..... Y...

N13

N20 G23 P2

N21 N...

N22 Y...

N24 X...

N25 G24 P2



sequence if

signal **OPTIONAL JUMP** = high:

N10 to N20 / N11 to N20

sequence if

signal **OPTIONAL JUMP** = low:

N10 to N25 / N11 to N25.

SBP Call-ups

The calling up of subprograms must only be possible by programming

G22 P .. L.. unconditional SBP call-up or


G21 P... L.. conditional SBP call-up

P = SBP number 1 to 99

L = repetition 0 99

For this reason the subprogram call-ups G21/G22 in the main program must be separated from the subprograms themselves by M2/M30.

One SBP can be called up repeatedly and from different places within the relevant main program.

Example

Decisions

Subprogram calls or jumps can be linked to a condition, which can be

- the logic state of interface contacts or
- the result of a mathematical comparison (parametric functions)


The jumps or calls are carried out if the stated condition is fulfilled. They are not carried out (and the program is continued at the next line) if the condition is not fulfilled.

PARALLEL PROGRAMMING

Definition

Parallel programming allows the control to be used in EDIT mode while an active program is being executed.
 In edit mode tool data, zero shift tables, variables and part programs can be entered, edited and output.
 Active programs and cycles can not be edited in parallel operation.


PARALLEL PROGRAMMING



Functions available in Parallel Operation

Tables

TOOL, ZERO SHIFT and VARIABLE tables can be edited, entered and output. Contents of tables which need to be accessed by the active program can not be edited in parallel operation.
 A possibility does, however, exist to edit table contents during program execution. After the program has been completed the existing table is overwritten with the modifications (updated). The control generates a passive table for this purpose.



CYCLES

Cycles can not be edited in parallel operation. But they can be input and output via the serial interface.

PROGRAMS

Programs can be edited in parallel operation and can also be input from and output to external data carriers.

The **active** program can **not** be edited.

There is, however, the possibility of copying the active program in the memory before starting program execution.

The copied program can then be edited.

**Soft key
TABLES**

During AUTOMATIC execution of a program while in parallel operation the soft key TABLES appears.

Under this soft key it is possible to look at the tables TOOLS, ZERO SHIFTS and VARIABLES without having to come out of main mode AUTOMATIC.

DRIP FEEDING

DEFINITION Long programs which do not fit into the program memory can be loaded via interface for direct execution.

DRIP FEEDING - SINGLE ACTIVATION

Single drip feeding operation is activated via soft key

DRIP FEEDING

IN AUTOMATIC mode (direct selection).

DRIP FEEDING - CONTINUOUSLY ACTIVE

If drip feeding is to be activated automatically when AUTOMATIC mode is selected the operator must switch to

ACTIVE ON POWER ON

(reverse video) in the 3rd soft key level (INFO mode).

DRIP FEEDING - USER INTERFACE

In AUTOMATIC mode the preset parameters for DRIP FEEDING will appear on the display once it is activated.

Example

AUTOMATIC			
PORT NO : 1			
BAUD RATE : 2400			
OFFSET: 12			
SIZE OF BUFFER : 512			
START BLOCK? 1			
NEXT PAGE	PROGRAMS	CYCLES	DRIP FEEDING


PROGRAMMING

General

BOSCH CC 100 M

User Handbook

The DRIP FEEDING parameters are preset in INFO mode.
The parameters do not affect the program which is to be executed.



Main mode INFO

MACHINE STATUS	SERVICE	MTB SERVICE	LINES- SERVICE	RESET DELETE
-------------------	---------	----------------	-------------------	-----------------

	DRIP FEEDING		DNC	
--	-----------------	--	-----	--

ACTIVE ON POWER ON	BUFFER SIZE	PORT NO.	BAUDRATE	BLOCK OFFSET
-----------------------	----------------	----------	----------	-----------------

Meaning of the DRIP FEEDING parameters

ACTIVE ON POWER ON

If this parameter is active (reverse video) the control defaults to DRIP FEEDING mode when AUTOMATIC is selected.

BUFFER SIZE

The BUFFER SIZE parameter determines the buffer size in 0.5 kBytes, which is to be kept free for DRIP FEEDING in the part program memory of the control.

Input format: 512 bytes

Min. buffer size: 1 (= 512 bytes)

Max. buffer size: ≤ max. available memory capacity (see Drip Feeding and main memory)

PORT NO.

Selection of the interface on the CP/MEM

Port 1 - V.24/20 mA (with handshake)

Port 2 - V.24 (with or without handshake)

BAUDRATE

Setting of the baudrate.

The following baudrates are recommended (- 1800 Bd):

- 8 = 1800Bd
- 9 = 2000Bd
- 10 = 2400Bd
- 11 = 3600Bd
- 12 = 4800Bd
- 13 = 7200Bd
- 14 = 9600Bd

**BLOCK
OFFSET**

This parameter is originally preset so that the program execution begins after 12 program blocks have been loaded (min.).

The setting "n" determines after how many loaded blocks the execution is to begin.

Possibilities: n = -1	execution begins when the buffer is full or when M30/M2 is transferred from the DRIP FEEDING program.
n = 0	Execution begins when 12 program blocks are loaded.
n > 12	Execution begins when the specified number (n) of program blocks are loaded.

START POINT? Input of the block number at which DRIP FEEDING is to start (1 = beginning of the program).
NC blocks before the start point are ignored.

Note: The DRIP FEEDING parameters can only be changed in INFO mode. Port no. and baudrate are independent of the parameters as described in chapter "Data Handling".

Recommendations for achieving fast data input with drip feeding

- When the control has "some time" (e.g. long traversing path, G4 active, or FEED HOLD active) it loads data into the buffer. It is therefore advantageous to choose the buffer to be as large as possible. The control is then able to "live" on data from the buffer for those program parts where the block cycle time is critical. In this case the loading of new blocks is inhibited until only the minimum number of blocks are in the buffer. The block cycle time will then be the same as when working from memory.
- Drip feeding and checksum:

Drip feeding programs should be transferred to the control with checksum in order to increase the speed of the transmission. Also the baudrate should not be below 1800.

Position and calculation of the checksum

(see program header in DFS format, page 1-22)

Restrictions

- Jumps, subprograms and the setting of stop points are not permitted in DRIP FEEDING programs;
- Parallel programming is not possible since there are several functions active simultaneously during DRIP FEEDING:
 - automatic program execution
 - block processing
 - transfer function from external data carrier (LOAD, SAVE)
- The REENTRY function is not possible.

ADDRESSES

ADDRESS F

G1 F.. F defines the path feedrate in mm/min.
 G2 F..
 G3 F..
 G5 F..

G04 F.. F takes effect as dwell in seconds.

G93 F.. F takes effect as execution time for the programmed path section in seconds.

G94 F.. F takes effect as feedrate in mm/min. G94 is active on switch-on.


Programmable range: F0.001 to F 50 000

G95 F.. F takes effect as feedrate in mm/rev.
 The programmed path feedrate is derived from the actual speed of the main spindle.
 G95 is used for tapping and finishing.

CONTROL RESET clears any programmed F-address.

ADDRESS T

T determines the tool number, which is to be output, and/or the tool length compensation, which is to be applied internally. T is programmed with 2 or 4 digits.



If T is programmed with only 2 digits these are always interpreted as the compensation group.

The operation of the tool length and tool radius compensation is described in detail under TOOL COMPENSATION, chapter 5.

PROGRAMMING ADDRESSES

BOSCH CC 100 M User Handbook

ADDRESS M

Definition Output signals can be generated by means of the program.

Range of M-Functions The control itself allows all M-codes from M0 to M99 to be used. The user can utilize all M-functions which have a machine function assigned to them.

Internal Listed below are a number of codes which have fixed internal functions:

Functions	Code	Internal function	
	M0	Program stop after execution of the block. All other conditions unchanged; does not cause spindle stop. New start with next block number via CYCLE START.	
	M2	Main program end, cycle end, programmed separately system then switches into program selection level Irrespective of the start point selection a new program will start at the beginning.	
	M3	Spindle rotation, clockwise. A direction of rotation must be active when spindle speeds or gear ranges are programmed.	machine specific effect
	M4	Spindle rotation, counter-clockwise, otherwise as M3.	
	M5	Spindle stop, programmed separately, spindle speed and gear range remain stored internally.	
	M6	Call-up of automatic tool change cycle (cycle 77)	
	M13	Spindle CW coolant on	
	M14	Spindle CCW coolant on	
	M19	Orientation of main spindle to fixed position in degrees. M19 S . . . : positioning to programmable position. M19 is output at the interface; address S is not	
	M21	Call-up of MTB cycle 76. No output at interface.	
	M22	Call-up of MTB cycle 75. No output at interface.	
	M30	Program end. Mode of operation and other conditions are retained. Change of mode after reset. Dependent on the start point selection a restarted program after M30 will be executed from the selected start point onwards.	
	M40	Automatic gear range selection (Active on switch-on, machine specific operation).	
	M41–	Selection of fixed gear ranges 1 to 4	
	M44	(machine specific operation).	
	M98	SINGLE BLOCK command is not allowed for as long as M98 is active. Programmed in a block of its own.	
	M99	SINGLE BLOCK is possible, i.e. M98 is cancelled. M99 is active on switch-on. Programmed in a block of its own	

External effects and further M-functions are particular to each machine and details must be provided by the machine tool builder; for instance: coolant on/off, delivery and removal of workpieces.

PROGRAMMING ADDRESSES

BOSCH CC 100 M User Handbook

ADDRESS S

- Definition** Programmed on its own the S-address determines the spindle speed, or the position for spindle orientation.
- G92 S . .** When programmed in conjunction with G92 the S-address limits the maximum speed of the main spindle.
- M19 S . .** The spindle is oriented onto the position programmed with S (degrees). If M 19 is programmed on its own the value defined by machine parameter 111 will apply as orientation point (range 00 - 359.999°).
- S** Spindle speed in rpm. The direction of rotation (M3/M4) must have been defined.

SPINDLE SPEEDS

- Definition** Inputs are evaluated as follows:
 With G 97 S = spindle speed directly in rpm format 4.3
 The direction of rotation must be determined together with the programming of S or beforehand.
 Minimum and maximum speeds are predetermined for the particular machine (M-parameters).

ADDRESS M GEAR RANGES

Machines with a gearbox which can be controlled via the CNC can operate in two ways:

- Fixed Selection M41-44** One particular gear range is programmed in the user program with M41 to 44, corresponding to gear ranges 1 to 4:
 The control assists with the change-over between gear ranges by the output of idling speeds, by the processing of signals relating to the gear ranges etc.
 If a speed is programmed which is not achievable within the selected gear range, the control outputs the max. or min. speed possible within that range.
- Automatic Selection M40** When M40 is active the control itself selects the appropriate gear range on the basis of the following criteria:
- up to 4 gear ranges with min. and max. speed values can be controlled
 - output range for the speed:
 1 to 9999 rpm (MTB can restrict the range for the particular machine)
 - when S is programmed the appropriate gear range is automatically selected, on the basis of the current program data
 - where gear ranges overlap the control selects the lower of any two possible gear ranges (higher motor speed).
- G96 + M40** A new gear range is only selected for the following block if the required speed can not be achieved in the active gear range. Idling speed is output for as long as the activation of the correct gear range has not been acknowledged.

**PROGRAMMING
ADDRESSES****BOSCH CC 100 M**
User Handbook**H-ADDRESS**Hxx
Hxxxx**Definition**

H-address = "FLYING OUTPUT"

As opposed to the M-address, which is output before each traversing movement, the H-address is output simultaneously with the traversing movement.

This simultaneous output prevents drops in the command value.

Use

This function can be used in programs for machining operations during which any momentary stopping of the axes would result in damage to the workpiece (for instance during laser cutting). This 4-digit auxiliary function permits additional control and switching functions for time-critical applications.

Programming

- The H-address should be regarded as an additional auxiliary function; it should not be programmed with other auxiliary functions in the same block.
- The programming format is up to 4-digit.
- Variables can be allocated to the H-address (V1 = 1212; H = V1).

Output

The H-address is output to the interface in BCD code. If the address has 4 digits the last two are output first.

Note

H-addresses can also be used for the extension of certain functions (e.g. speed programming in dual spindle operation: S1 = 1000 rpm; H = 500 rpm).

OPERATOR INSTRUCTION PROGRAMMING

Definition The operator instruction programming facility allows the display of texts during the program execution. These texts can be purely informative or they can give instructions to the operator. The contents of the texts do not affect the program sequence or machine functions in any way.

Programming The text is programmed in brackets and must be written in a separate block.

Usage This facility can be used to provide documentation for the program. Since the display always shows the next block to be execution while the program is being actioned it is possible to put message up on the screen by programming M0 beforehand.

If a program block is programmed in brackets, i.e. as an operator instruction, it will not be actioned. In this way blocks can be blanked out in a program.

Example:

```
.
.
.
N5
N6
N7 M0
N8 (NOTE - SWITCH ON COOLANT
N9 X... Y...
N10 X... Y...
```

The program sequence stops in block 7 (due to M0).
The operator instruction will then be displayed.

PROGRAMMING TABLES

BOSCH CC 100 M
User Handbook

TABLES

Tools

Up to 48 tool compensation stores are available.
Each tool compensation store comprises the following:

<u>T1</u>	<u>R = uuu.uuu</u>	<u>DR = u.uuu</u>	<u>L = uuu.uuu</u>	<u>S = uuu</u>
no.	tool radius (mm or inch)	tool wear max.10% of radius, max. 1 mm, increm. input	tool length (mm or inch)	cutting speed m/min or inch/min

Input dimension defined as metric or inch via soft key.

Example:

```
*****TOOL*****1*****
T1    R= 16.0    DR= 0.9    L= 25.0    S= 10.0
```

* = space character

Zero Shifts

6 zero shifts are available (G54-G59). See under section "G-Functions"
G53, G54-G59 for definition.

Each zero shift comprises the following:

<u>G54</u>	<u>X = uuuu.uuu</u>	<u>Y = uuuu.uuu</u>	<u>Z = uuuu.uuu</u>	<u>E = uuuu.uuu</u>
no. of zero shift offset	amount of			

The dimension is defined as metric or inch via soft key.

Example:

```
**ZERO*SHIFT*****2*****
G54  X= 10.0    Y= 20.0    Z= 30.0    E= 40.0
```

Variables

A maximum of 125 variables are available for the writing of
variable programs (V1...V99 and VA...VZ).
Variables represent numbers of up to 7 digits.

Example:

```
***VARIABLE*****3*****
V1 = 116.0    V2 = 8.0    V3 = 0.6    V4 = -1.0
```

Header

line:

When programming tool data, zero shifts, variables, programs, cycles
and (M) parameters externally, identifying HEADERS
as shown above must be provided. These **must** be written in
a specific format which is explained on page 1-17.

G - FUNCTIONS

LINEAR INTERPOLATION IN RAPID


G0

- Definition** The axes travel to the programmed position with linear interpolation. The speed is determined by machine parameter.
- Feedrate** No feedrate should be programmed (address F). The machine parameter values for rapid will become effective.
- Interaction** This mode remains modal until a different mode of motion is selected. G0 cancels modes G1, 2, 3 and 5.
- Execution of the next block is not started until all axes are "IN POSITION". THE IN POSITION range is defined by machine parameter.
- Positioning with G0 is possible when the main spindle is stopped.
- Programming** **G0 X..... Y..... Z..... E.....**
 Programmable with or without axis addresses.
- Path** The traversing movement is linear even if the distances for the individual axes are different, or if the axes have different rapid speeds. The override potentiometer can be deactivated for G0 and AUTOMATIC by machine parameter.

- Example**
- ```

N1 G0
N2 X 100 Y 100 (starting position A)
N3 G0 X500 Y 300 (end position B)
N4 M30

```
- Resulting movement with different distances in two axes:



- Speeds** The axis which has the longest distance to cover traverses at maximum speed. The speeds of other axes are regulated in such a way that all axes reach the programmed position simultaneously.

**Note - G0 slope:** Axis acceleration and deceleration during rapid traverse are controlled by means of a command ramp. The constant acceleration parameters are programmed for the different axes via machine parameters (see Connections manual, Chapter 4). This does not apply to the 4th axis if it is defined as a Hirth axis.



# PROGRAMMING

## G - FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

### LINEAR INTERPOLATION IN FEED

**G1 A** (A = active on switch-on)

**Definition** The axes traverse to the programmed point in a straight line at the active feedrate (F-word).  
The movement is coordinated in such a way that all involved axes (up to 4 axes: X, Y, Z, E) reach the programmed point simultaneously.

**Feedrate** The programmed feedrate value (F) takes effect as the path feedrate; this means that if several axes are involved in the movement the portion of each individual axis is smaller than F.

The speed can be influenced via the feedrate override potentiometer. If X, Y, Z and a rotary axis (E) are to traverse together, an angular velocity is calculated for E. It is therefore advisable to use time programming G93 for movements involving both linear and rotary axes (see G2, G3, G5).

**Interactions** G1 cancels G0, 2, 3, 5 and is modal, as is the programmed feedrate (main address F).

**Programming** G1 X.... Y.... Z.... E.... (F....)


G1 can be programmed with or without axis information. It must be programmed together with an F-word if no F-word is active yet. Once a feedrate is programmed it remains effective until it is overwritten by a new value.  
(Servo Error or switching off cancels the modal feedrate).  
The programming of "F0" is not admissible.

**Example**

```

N1 G1 X50 Y30 F1000 (feedrate 1000 mm/min)
N2 X30 Y20
N3 M30

```



**CIRCULAR INTERPOLATION**
**G2, G3, G5**
**Definition**

The axes traverse to the programmed point at the active feedrate on a circular or helical path.

The movement is coordinated in such a way that all involved axes reach the programmed point simultaneously.  
 Circles can only lie in parallel with one of the planes generated by two of the coordinate axes.

**Feedrate**

There must already be a feedrate active, or a feedrate must be programmed in the same block.

The following functions, are possible:

G64 / G65 feedrate applies to the contour / tool centre  
 G93 programming in time segments  
 G94 programming in mm/min  
 G95 programming in mm/rev

The achievable feedrate can be limited by the ratio between the feedrate and the contour radius, as well as the programmed distance. See F-address.

The max. feedrate is determined by machine parameter.

**Interactions**


G0/1/2/3/5 cancel each other.

**Entry into Circle**

**G5** X... Y... tangential entry, automatic calculation of the radius

**G2/G3** X... Y... R... any type of entry with programming of the radius

**G2/G3** X... Y... I... J... any type of entry with programming of the centre of the circle

**Direction of Rotation**


Any size of arc can be defined. Full circles can be programmed using I,J,K. The centre coordinates are always necessary for full circle programming.

**Exit from the Circle**

There are no restrictions regarding the exit from a circular contour

# PROGRAMMING

## G - FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

### CIRCULAR INTERPOLATION WITH ANY TYPE OF ENTRY INTO THE CIRCLE

G2/G3 with R

**Programming** G2 X.... Y.... R.... (X/Y plane)

**Entry into the Arc** If the radius is defined during the programming any entry into the arc can be realized.


**Radius R** The radius is programmed by the R-address with sign.  
Maximum input value: 100 m.  
**Negative sign:** arc smaller than a semicircle.  
**No sign:** arc larger than a semicircle.  
(see examples)

**Definition of the Arc** Given the same starting and end points and radius 4 different arcs are possible.

These are distinguished by determining the direction of rotation and the sign of the radius as follows:

#### Examples


##### G2 clockwise



Programming:

```
N1 G0 X0 Y0 (point P1)
N2 G2 X0 Y-20 R22 F1000
 (broken line circle)
or
N2 G2 X0 Y-20 R-22 F1000
 (continuous line circle)
N3 M30
```

##### G3 counter-clockwise



Programming:

```
N1 G0 X0 Y0
N2 G3 X0 Y-20 R22 F 1000
 (broken line circle)
or
N2 G3 X0 Y-20 R-22 F1000
 (continuous line circle)
N3 M 30
```

#### Note

No programming of full circles possible with R.

# PROGRAMMING

## G - FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

### CIRCULAR INTERPOLATION WITH ANY TYPE OF ENTRY INTO THE CIRCLE

G2/G3 with I, J, K

|             |                |            |             |
|-------------|----------------|------------|-------------|
| Programming | G2 X.... Y.... | I....J.... | (X/Y plane) |
|             | G2 X.... Z.... | I....K.... | (X/Z plane) |
|             | G2 Y.... Z.... | J....K.... | (Y/Z plane) |


**Entry into the Arc** If the position of the centre of the circle is defined with I, J, (K) any type of entry onto the circular contour can be realized, as well as full circles.  
NOTE: If I, J or K = 0 then this value need not be entered into the program.

**Parameters of the Centre of the Circle** The position of the centre of the circle is determined by I, J and K.  
I, J and K are modal in effect.  
X/Y,Z, as well as I, J and K are programmed in absolute or incremental dimensions.

|   | G90 absolute dimensions        | G91 distances to existing position         |
|---|--------------------------------|--------------------------------------------|
| I | X position of centre, absolute | distance in X-direction<br>( $X_M - X_A$ ) |
| J | Y position of centre, absolute | distance in Y-direction<br>( $Y_M - Y_A$ ) |
| K | Z position of centre, absolute | distance in Z-direction<br>( $Z_M - Z_A$ ) |

**Example** starting point = A, end point B, centre of circle M

G2, G90



Calculation of centre:

$$I = X_M - X_A = 0$$

$$J = Y_M - Y_A = -100 - 0 = -100$$

Programming with G90:

```
N1 G1 X-40 Y-20 F1000 (S)
N2 X0 Y0 (A)
N3 G2 X100 Y-100 J-100 (B)
N4 G1 X100 Y-120 (E)
N5 M30
(G90 active on switch-on)
```

Programming with G91:

```
N1 G1 X-40 Y-20 F 1000 (S)
N2 G91 (A)
N3 X40 Y20 (B)
N4 G2 X100 Y-100 J-100 (E)
N5 G1 X0 Y-20
N6 M30
```

# PROGRAMMING G - FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

## CIRCULAR INTERPOLATION

**G2/G3**

### Examples

#### G90

Starting point X40 Y60.


Radius: 40 mm.

A = starting point

B = end point

M = centre of circle

#### G2



Calculations:

#### Programming with R


```
N1 G1 X40 Y60 F1000 (A)
N2 G2 X80 Y20 R40 (B)
N3 M30
```

#### Programming with I, J

```
N1 G1 X40 Y60 F1000 (A)
N2 G2 X80 Y20 I80 J60 (B)
N3 M30
```

#### G3

Full circle with a radius of 50 mm



A and B are identical  
for a full circle.

The circle must be subdivided  
into 2 parts when programming with R.

#### Programming with R

```
N1 G0 X30 Y100 (A)
N2 G3 X80 Y150 R50 (A)
N3 X30 Y100 R-50 (B)
N4 M30
```


#### Full circle programming with I, J

```
N1 G1 X30 Y100 (A)
N2 G3 X30 Y100 I80 J100 (B)
N3 M30
```


**CIRCULAR INTERPOLATION WITH TANGENTIAL ENTRY**
**G5**
**Programming**     **G5**   **X....**   **Y....**
**Entry into the Arc**

When G5 is programmed the control will calculate a tangential entry into the circular contour. No radius is programmed. Only those contour transitions are considered tangential which do not involve a reversal of direction. The control calculates the size and the position of the arc as illustrated in the following examples:


When several G5 movements follow one another the 1st entry tangent influences all subsequent contour elements with G5.

**Different End Points**





```
N1 G1 X0 Y70 F200
N2 X50
N3 G5 X110 Y 10
N4 M30
```



```
N1 G1 X0 Y70 F200
N2 X50
N3 G5 Y130 Y100
N4 M30
```



```
N1 G1 X-15 Y40 F200
N2 G2 X50 Y70 R-60
N3 G5 X90 Y120
N4 M30
```

**Different Tangents**

**Restriction**

G5 can not be programmed in MDI or as the first block in a part program, since it would not be possible to calculate a tangent.

 $T_n$  = tangent

 $A$  = starting point of arc

 $M_n$  = centre of circle

 $E$  = end point of arc

# PROGRAMMING

## G - FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

### DWELL

### G4

**Definition** The execution of the subsequent blocks is not started until the programmed time has elapsed.

**Operation** G4 only becomes effective in the block in which it is programmed and must be programmed on its own.

Modal conditions are retained.

**Programming** **G4 F . . . .** F in seconds  
input range 0.01 to 9 999 999.

### Example

|                 |               |                 |
|-----------------|---------------|-----------------|
| N12 G1 X10 Y100 | F150          |                 |
| N13 <b>G4</b>   | <b>F2</b>     | 2 sec.dwell     |
| N14 Z-60        |               |                 |
| N15 <b>G4</b>   | <b>F 1.78</b> | 1.78 sec. dwell |
| N16 Z0          |               |                 |
| N17 M30         |               |                 |

LINEAR INTERPOLATION IN RAPID WITH  
EXTENDED IN POSITION RANGE

G6

**Definition**

In interpolation mode the control waits until an In Position range is reached before starting the interpolation for the next block.

G6 corresponds to the G0 function, but with a larger In position range (as a rule).

As opposed to the G0 IN-POS range, which is determined as a constant value in the machine parameters (see MP 49, 69, 89, 109) the IN-POS range of the G6 function is related to the max. rapid feedrate (see MP 35, 55, 75, 95):

$$\text{IN-POS range} = \frac{\text{max.rapid feedrate}}{1000}$$

The **smaller** the max. rapid feedrate determined by the machine parameters the more precise (smaller) is the IN-POS range.

After this range is reached the control stops for a short time before the interpolation for the next block is started. The length of this stop time is determined in a separate machine parameter (MP 23) and applies for all axes.

Reactivation of the "normal" IN-POS range by programming G0, G1, G2, G3 or G5.



# PROGRAMMING

## G - FUNCTIONS


**BOSCH CC 100 M**  
User Handbook

### PLANE SELECTION

**G17 A** X/Y plane  
**G18** Z/X plane  
**G19** Y/Z plane

**Definition** These G-codes are used to determine the working plane. They also influence the operation of functions G2, G3 and G5, of the tool radius compensation and of the tool length compensation.

**Interactions** G17, 18, 19 are modal functions and cancel each other. The definition of a pole with G20 also effectively makes a plane selection.



**Programming** A change in the working plane must be programmed before the first circular movement (G2, G3).

A change in the working plane must not be programmed while tool radius or tool length compensation (G41, G42, Txx) is active.

### Plane Selection

| G-code | circular interpolation<br>tool radius comp.<br>positioning plane for<br>standard boring cycles | tool length comp.<br>feed-in axis for<br>standard boring cycles |
|--------|------------------------------------------------------------------------------------------------|-----------------------------------------------------------------|
| G17    | X/Y plane                                                                                      | Z-axis                                                          |
| G18    | Z/X plane                                                                                      | Y-axis                                                          |
| G19    | Y/Z plane                                                                                      | X-axis                                                          |


**SETTING A POLE**
**G20**

**Definition** The pole and the associated plane G17/18/19 are determined by 2 axis addresses, which are programmed together with G20. The pole relates to the active zero point. The setting of the pole does not produce any axis movement.

**Programming with Contour points** are defined by the radius and an angle. The data relates to a pole, **Polar Coordinates** which is to be defined, and a plane. Positions described in this way are converted within the control into command values for standard axes in a Cartesian system.

|              |                                   |                                                                                                                                                                     |
|--------------|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Terms</b> | <b>Polar plane</b>                | Plane defined by 2 cartesian axes within which the polar coordinates lie.                                                                                           |
|              | <b>Pole</b>                       | Centre of the polar coordinate system.<br>Position of the pole:<br>Without/before G20: on the active program zero point<br>After G20: on the point defined with G20 |
|              | <b>Radius D</b>                   | Program address assigned to the vector length.                                                                                                                      |
|              | <b>Angle A</b>                    | Program address assigned to the vector angle. In mathematical terms the angle relates to the active reference plane..                                               |
|              | <b>Reference axis for angle A</b> | The axis in <b>bold print</b> written first in the plane selection.<br><b>G17 XY G18 ZX G19 YZ</b>                                                                  |
|              |                                   |                                                                                                                                                                     |

**Operation** The interpolation modes G0, 1, 2, 3, 5 etc. are not affected by this function.



P = pole

X<sub>p</sub> = distance of the pole from the Cartesian zero point in X

Y<sub>p</sub> = distance of the pole from the Cartesian zero point in Y

A = angle

D = vector length

Programming:  
G20 X100 Y200

**Example G17** Setting a pole in plane XY (polar plane) at position X = 100 Y = 200 .

**Effect with G91** Angle A absolute, vector length D incremental.

# PROGRAMMING G - FUNCTIONS


# BOSCH CC 100 M User Handbook

## POLAR COORDINATES

## G 20

### Example

Machining a row of holes with G81




Program:

|    |       |         |         |                   |
|----|-------|---------|---------|-------------------|
| N1 | F1000 | S500    | M3      | T01               |
| N2 | G81   | VI = 80 | V2 = 30 |                   |
| N3 | G20   | X100    | Y200    |                   |
| N4 | X100  | Y200    |         |                   |
| N5 | A30   | D200    |         | (D <sub>1</sub> ) |
| N6 | D400  |         |         | (D <sub>2</sub> ) |
| N7 | D600  |         |         | (D <sub>3</sub> ) |
| N8 | D800  |         |         | (D <sub>4</sub> ) |
| N9 | M30   |         |         |                   |

P = position of the pole

### Example

Machining a bolt hole pattern with G81



Programm:

|     |       |         |         |     |
|-----|-------|---------|---------|-----|
| N1  | F1000 | S500    | M3      | T01 |
| N2  | G81   | VI = 80 | V2 = 30 |     |
| N3  | G20   | X400    | Y500    |     |
| N4  | X700  | Y500    |         | (A) |
| N5  | A45   | D300    |         | (B) |
| N6  | X400  | Y800    |         | (C) |
| N7  | A135  |         |         | (D) |
| N8  | A180  |         |         | (E) |
| N9  | A225  |         |         | (F) |
| N10 | A270  |         |         | (G) |
| N11 | A315  |         |         | (H) |
| N12 | M30   |         |         |     |

**CONDITIONAL SUBPROGRAM CALL-UP**
**G21**

**Definition** The subprogram call-up is dependent on the status of I/F signal "CONDITIONAL SUBPROGRAM CALL-UP"  
 Any program label (marked with "\$") can be used.

**Operation** The interface signal "CONDITIONAL SUBPROGRAM CALL-UP" must be present at least 3 blocks before the block in which G21 is programmed.


Status of signal "CONDITIONAL SUBPROGRAM CALL-UP":

High The subprogram is carried out.

Low The subprogram is not carried out.  
 (Next block is executed.)

By using backwards jumps it is possible to produce endless program repetitions, for series production for instance.

Subprogram nesting up to 10 programs deep is possible  
 (nesting: one SBP calls up other subprograms)



MP = main program

SBP = subprogram

Explanation of above example:

All the subprograms are only carried out if signal "CONDITIONAL SUBPROGRAM CALL-UP" is high when block 8 is read in.

**General Format G21 P... L...**

P = subprogram number ranging from 0 to 99

L = repetition factor (in addition to 1st execution)  
 ranging from 1 to 99  
 input of L is dispensable

**Programming Example: G21 P10 L1**

SBP 10 is executed  $(1 + 1) = 2$  times, if the signal is at high level.

G21 must not be used if tool radius compensation is active.

G21 must be programmed on its own.

# PROGRAMMING

## G - FUNCTIONS

# BOSCH CC 100 M

## User Handbook

### SUBPROGRAM CALL-UP

### G22

#### Definition

Programs which are marked as subprograms are called up with G22  
Any program label (marked "\$") can be used.


#### Operation

Subprograms called up with G22 P... (L...) are carried out unconditionally.  
The subprograms of the CC 100 are of local character,  
in other words they are always assigned to a particular main program or cycle.

#### Programming

Example: G22 P5 Subprogram 5 is carried out once.

Subprogram nesting up to 10 programs deep is possible  
(nesting: one SBP calls up other subprograms).



MP = main program

SBP = subprogram

Explanation of the above example:

On its own the call-up of SBP 8 in block 44 will produce  
4 program runs (1.execution + 3 repetitions).

The preceding call-up of SBP 7 in block 32, on its own,  
will produce 2 runs of SBP 7.

|                 |    |      |      |           |               |
|-----------------|----|------|------|-----------|---------------|
| Total number of | MP | SBP5 | SBP2 | SBP7      | SBP8          |
| program runs:   | 1  | 1    | 1    | 1 + 1 = 2 | 2x(1 + 3) = 8 |

#### General Format G22 P... L...

P = subprogram number ranging from 0 to 99

L = repetition factor (in addition to first execution)  
ranging from 1 to 99  
input of L is dispensable

G22 must be programmed on its own.

**CONDITIONAL JUMP**
**G23**

**Definition** The jump is only carried out if the interface signal "OPTIONAL JUMP" is present. If this condition is not fulfilled, the subsequent block will be executed.

**Operation** Any programmed label can be used as jump address.  
 Program labels are marked with \$.  
The interface signal "OPTIONAL JUMP" must be present at least three blocks before the block in which the jump is programmed.

**Programming** **G23 P . . .** P = 1 to 99 for the program label

G23 must always be programmed on its own.

G23 must not be used while tool radius compensation is active.

**Example** Drilling holes at different positions, depending on the workpiece, if its identification triggers the I/F signal "OPTIONAL JUMP".  
 Signal = high Blocks 10-12, 19-24, 16-18 are executed.  
 Signal = low Blocks 10 to 18 are executed.

N1 G0 X800 Y500 Z100

N2 G23 P15

N3 G1 Z0 F500

N4 Z100

N5 G0 X0 Y0

N6 X100

N7 \$15

N8 G0 Y400


N9 G1 Z-20 F400

N10 Z100

N11 G0 X0 Y0

N12 M30

optional jump  
dependent on I/F signal



**UNCONDITIONAL JUMP**
**G24**

**Definition** During the execution the program is not continued at the next block but at the program label defined in the jump instruction. The program label is marked with \$.

**Operation** The jump is carried out unconditionally. By programming backwards jumps it is possible to produce endless program repetitions, for series production for instance.

**Programming** General format:


**G24 P . .** P for the program label

The programming range for P is 1 - 99.

A jump must not be programmed together with other instructions in the same block.

**Example**

Backwards jump from the main program to the second block.



Explanation of above program:

Program 2 is repeated continually for as long as input "OPTIONAL JUMP" is low. As soon as this signal goes high machining is concluded with blocks 23 and 24.

**FIELD LIMITATION**

|                               |              |
|-------------------------------|--------------|
| <b>SETTING MINIMUM VALUES</b> | <b>G25</b>   |
| <b>SETTING MAXIMUM VALUES</b> | <b>G26</b>   |
| <b>CANCELLING LIMITATION</b>  | <b>G27 A</b> |

**Definition** The field limitation prevents the axes from being driven into areas where collisions might occur.  
 Unlike the limit switches these limitations must be determined separately for each program.

The axes can not position to any point with values  
 - **under** those programmed with **G25**  
 - **above** those programmed with **G26**

The input of the axis values does not produce any axis movement.


The limitation values relate to the active program zero point.  
 Any offset programmed with G92 X... Y... is not considered.

**Operation** The limitation function is modal for all machining modes.  
 It takes into account tool radius compensation as well as tool wear.

The field limitation does not become activated until the software limit switches are set and the axes have been referenced.

**Programming** **G25 X... Y... Z... E...**  
 The axes must already be positioned within the field of operation.

**Cancelling** The limitations set with G25 and G26 are cancelled by programming  
**G27 X Y Z** without numerical values as well as by **CONTROL RESET**.  
 The software limit switches remain valid.



**Example**

|     |              |                   |                                          |
|-----|--------------|-------------------|------------------------------------------|
| N10 | G0           | X750 Y400 Z300    | axes position above workpiece zero point |
| N11 | G92          | X0 Y0             | clamping position is taken into account  |
| N12 | G25          | X-550 Y-300 Z-280 | lower limit is determined                |
| N13 | G26          | X150 Y100 Z200    | upper limit is determined.               |
| :   | part program |                   |                                          |
| N80 | G27          | X Y Z             | limitation is cancelled                  |

**Note** The traversing field limitation set in the machine parameters  
 can not be extended, but only be limited further with G25/G26.





**SCALING FACTOR SWITCHING**
**G 36**
**Definition**

Modification of the scaling factor of the coordinate system.

The contour lines of a workpiece are enlarged or reduced in the specified factor area, without having to change the programming of the actual contour lines.

The scaling factor always relates to a particular plane (see next page); the two axes of a plane can not be modified separately.


**Modification  
range of scaling  
factor**

**Format**

X.xxxxx (5 digits behind decimal point)

Scaling factor data is accepted in decimal format, for instance:

X0.2 = 5-fold reduction (corresponds to reciprocal value of 5)

X5.0 = 5-fold enlargement

# PROGRAMMING

## G - FUNCTIONS

# BOSCH CC 100 M


## User Handbook

|                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |          |                                                                 |
|-------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|-----------------------------------------------------------------|
| <b>Display</b>    | The defined scaling factors for the different axes can be displayed in main mode INFO under the CC 100M STATUS display.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |          |                                                                 |
| <b>Operation</b>  | <ul style="list-style-type: none"> <li>- G36 always relates to a particular plane.<br/>Example: The programming of the scaling factor for X automatically influences X and Y in plane G17.</li> <li>- G36 is modal and can be reset with CONTROL RESET, G36 X1 (Y, Z, E) to factor 1.<br/>A change in plane (G17/18/19) also resets a defined scaling factor. This means that the scaling factor needs to be redefined after each plane selection.</li> <li>- G36 also operates in the E-axis, if this is defined as a linear axis, whatever working plane is selected.</li> <li>- Any variables called up in the program are subject to modification according to the scaling factor. The scaled values are, however, not transferred into the variable table or tool table.</li> <li>- G36 does affect the contents of the zero shift table if it precedes G54-59 in the program.<br/>G36 does not affect any preceding zero shifts.</li> <li>- If G36 is programmed in several blocks they overwrite each other. The block last programmed has highest priority and the programmed scaling factor remains effective until the next change in scaling factor. The scaling by means of the scaling factor is switched off by programming the scaling factor 1.</li> </ul> |          |                                                                 |
| <b>Programing</b> | <ul style="list-style-type: none"> <li>- G36 can be programmed together with main addresses F, S, T, H, but not with any other G-codes or with M-codes 6, 19, 21, 22 in one block.</li> <li>- G36 is to be programmed with only one axis of the working plane; for working plane G17 this is either X or Y; axes Z and E can be programmed independently in the same block with a different scaling factor.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |          |                                                                 |
| <b>Example</b>    | N1 G0                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | X0 Y0 Z0 |                                                                 |
|                   | N2 G17                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |          | selection of X/Y plane, clearing all programmed scaling factors |
|                   | N3 G36                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | X2       | scaling factor for X and Y-axis, 2-fold magnification           |
|                   | N4 G0                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | Y50      | traversing to Y100 mm                                           |
|                   | N5 G36                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | X1       | switch off scaling                                              |
|                   | N6 M30                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |          |                                                                 |

**PROGRAMMABLE MIRRORING**
**G38** switch on  
**G39A** switch off

**Definition** 1 or 2 specified axis(es) is (are) mirrored within the selected plane.

**The axes are programmed together with G38.**
**Operation** The programmed workpiece positions are interpreted with inverted sign in the relevant axis. The position values are mirrored around the active zero point. This is the zero point which resulted after any possible setting of the position stores with G92, presets or zero shifts.

**Reference Points**


M = machine zero point  
 W = workpiece zero point  
 A = clamping zero point (G92)

X' = axis values after zero shift  
 Y' = axis values after zero shift

X = X-axis values are mirrored  
 Y = Y-axis values are mirrored

**Programming**

|     |     |             |                                                      |
|-----|-----|-------------|------------------------------------------------------|
| N10 | G17 | (G18/G19)   | plane selection                                      |
| N11 | G38 | X or Y or Z | (max. 3 axes)                                        |
| N10 | G39 |             | to cancel all mirroring                              |
| N11 | G39 | X (Y) (Z)   | selective cancelling of mirroring in particular axes |

The axis addresses are always programmed without axis values.


# PROGRAMMING

## G - FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

### PROGRAMMABLE MIRRORING

Example  
Original  
Contour  
G17



### G38 / G39

subprogram "contour":

```

N21 $1
N22 G0 X500 Y300 Start (S)
N23 G1 X450 F200
N24 X250 F500
N25 G3 X100 Y150 R-150
N26 G1 Y50
N27 X450
N28 Y360 End (E)
N29 G99

```

N10 (G17)

execution in 1st quadrant (I)

N11 (G39)

**no mirroring**

N12 G22 P1  
Y400

program call-up

N13 G38 X

execution in 2nd quadrant (II)

**X-values mirrored**

N14 G22 P1  
X500

program call-up

N15 G38 XY

execution in 3rd quadrant (III)

**X and Y-values mirrored**

N16 G22 P1  
Y400

program call-up

N17 G38 Y

execution in 4th quadrant (IV)

N18 G22 P1


**Y-values mirrored**

N19 G39

mirroring cancelled in both axes

N20 M30

Operating  
Sequence  
during  
Mirroring



→ tool path  
for mirroring  
operations

• auxiliary points


### Note

When the values are mirrored for just one axis the control converts G41 into G42 and G3 into G2 etc. internally. See also examples II and IV.

This is not the case when the values for 2 axes are mirrored. See example III.

**TOOL RADIUS COMPENSATION**
**G40 A / G41 / G42**
**Definition**

When carrying out a part program with tool radius compensation the tool is guided along an equidistant parallel to the programmed path. Equidistant = path with a constant distance to the programmed contour. The tool length is taken into account by the call-up of the T-address.


**Interactions**

**G40** **Cancelling radius compensation.**  
Active on switch-on, also automatically active when switching into AUTOMATIC mode. G40 must be active at the end of each program.

**G41** **Call-up of tool radius compensation to the left of the programmed contour,** viewed in the direction of the path.

**G42** **Call-up of tool radius compensation to the right of the programmed contour,** viewed in the direction of the path.

G40/41/42 are modal, exclude one another, and become active with the subsequent traversing movement. G41/G42 can not be used in manual operation.

**Programming**

|            |                                   |             |                                                                                             |
|------------|-----------------------------------|-------------|---------------------------------------------------------------------------------------------|
| <b>G41</b> | X...                              | Y... (T...) | During the phasing in of the compensation, T must either already be active or be programmed |
| <b>G1</b>  | X...                              | Y... F...   |                                                                                             |
| .          | .                                 | .           |                                                                                             |
| .          | .                                 | .           |                                                                                             |
|            | contour                           |             | feedrate, compensation group                                                                |
| .          |                                   |             | call-up and cancellation with                                                               |
| .          |                                   |             | a positioning movement in the                                                               |
|            | involved axes (XY for G17), which |             | is suitable for phasing in/out                                                              |
|            | the compensation.                 |             |                                                                                             |
| <b>G40</b> | X...                              | Y...        |                                                                                             |

For detailed description see TOOL RADIUS COMPENSATION, Chapter 5.

**Note:**

- A block with axis address without traversing movement, because the axes have already positioned, is not allowed with G41/42.

**Safety**
**Consideration**

- During the exit from the contour a reversal of direction of the cutter movement must be prevented. The angle under which the cutter moves away must therefore always be smaller than 90°.


**ZERO SHIFT**
**G53 A cancel zero shift**  
**G54 to G59**  
**activate zero shift**

**Definition** By using zero shifts programs can be carried out in different places without any modification. While a zero shift is active the machine parameters are temporarily overwritten. They can be reactivated simply by programming G53.

**Operation** Up to 6 zero shifts can be stored in the zero shift table.  
 For each zero shift up to 1 value each can be stored for X, Y, Z and E.

If G54 is then called up, for instance, the control will shift the zero point to the machine coordinates which were stored under G54. In order to use a zero shift (for instance G54) the zero shift table must already have been loaded with the respective offset data.

**Programming** **G54** on its own this does not produce any axis movement (display changes to programmed position)  
 or  
**G54 X... Y... Z...** the zero shift already applies to the position programmed in this block

**Example:**


Corresponding zero shift table:

```

G54 X100 Y100 Z70
G55 X300 Y100 Z70
G56 X500 Y100 Z70
G57 X100 Y450 Z70
G58 X300 Y450 Z70
G59 X500 Y450 Z70

```

This table can be loaded by manual input at the control, via parametric functions, via the serial interface, or via the BCD data bus.

```

N10 G54 1st zero shift active
N11 G22 P5 call-up of part program

.

N20 G59 6th zero shift active
N21 G22 P5 call-up of part program
N22 G53 machine coordinates apply one more

```

- Condition**
- No circular interpolation (G2, G3, G5) must follow immediately after an active zero shift. Operation must start or continue with linear interpolation.
  - G36 modifies the contents of the zero shift table if it is written **in front of** G54-59 in the program. G36 only affects subsequent zero shifts.
  - When G92 is cancelled any active zero shifts G54-59 are also reset.

**'IN POSITION' LOGIC ON**  
**'IN POSITION' LOGIC OFF**


**G61**  
**G62 A**

**Definition G61** In interpolation modes G1, 2, 3, 5 the control waits for each block until the 'In Position' window has been reached before it starts with the interpolation for the next block. The width of this window is determined by machine parameter. Once the window has been reached the control stops for a short time before interpolating the next block. The duration of this stop time is determined by a machine parameter.

**Definition G62** When the 'In Position' function is switched off the control starts with the interpolation of the next block while the last path section from the previous block is being actioned. This results in a "cutting of corners", but saves time.

**Operation** Functions G61/G62 are modal and cancel one another.

**G62** G62 is effective on switch-on



**Programming** G61, G62 must be programmed at the latest in the block for which they are to be effective.

#### Influence of machine parameters

|              |   |                   |
|--------------|---|-------------------|
| IN POS time  | - | MP23              |
| IN POS range | - | MP49, 69, 89, 109 |

(see Connections manual for CC100M)

**Example**

|     |     |      |      |                                         |
|-----|-----|------|------|-----------------------------------------|
| N10 | G61 |      |      | no movement                             |
| N11 | G1  | Y500 | F200 | interpolation with IN POS               |
| or  |     |      |      |                                         |
| N10 | G62 |      |      | 'IN POS' function off                   |
| N11 | G1  | Y500 | F200 |                                         |
| :   |     |      |      |                                         |
| N50 | G61 | X200 |      | interpolation with IN POS in this block |

**PROGRAMMING**  
**G-FUNCTIONS****BOSCH CC 100 M**  
User Handbook**FEEDRATE AND SPINDLE SPEED (S) 100%****G63****FEEDRATE AND SPINDLE SPEED OVERRIDE VIA POT****G66 A**

- Definition**      **G66** The position of the relevant override potentiometers on the manual panel affects the commanded values.
- Definition**      **G63** Feedrate and spindle speed are set to 100% of the programmed/entered value, whatever the position of the potentiometers.
- Operation**
- G66 is active on switch-on.  
Both functions are modal and exclude one another.
- Override ranges:
- feedrate      0 to 120% of the programmed value
  - spindle speed 50 to 150% of the programmed value
- Programming**      Can be programmed with other instructions in the same block.
- Application**      The override potentiometers for feedrate and spindle speed can be deactivated by means of programming.
- Note re.**            **G66** The potentiometers take effect even when the maximum feedrate is programmed. If the potentiometer is set to between 100% and 120% the maximum feedrate will be exceeded.




**EFFECT OF FEEDRATE**
**G64** cutting path  
**G65 A** cutter centre path

**Definition** The feedrate determined with F relates to the cutting path of the cutter or to the cutter centre path when machining circular contour sections.

**Interactions** G64/65 are modal and exclude one another.


**G65** The control keeps the feedrate along the cutter centre path constant. G65 is active on switch-on and is used for roughing.

**Examples**


In the example the feedrate effective on the actual contour is lower than the programmed value.

**G64** The control keeps the feedrate along the cutting path constant. These calculations can only be carried out for arcs G2/3/5 if G41/G42 is active.

Since the speed can increase considerably on circular contours this function should only be used during finish milling.



The effective axis feedrate is higher than the programmed one in the above example.


**CONTOUR TRANSITIONS**
**G69** intersection  
**G68 A\*** arc

**Definition** If tool radius compensation is active the control must create transitions for outside corners. These transitions can either be the intersections of the equidistants or automatically generated arcs. G68/69 are modal and cancel one another.

**Operation**  
**G68**

**Arc**

Only in conjunction with G41/42 with an angle  $\alpha$  of between  $0^\circ$  and  $180^\circ$ . The arc produces a continuous transition, which usually is the best solution technologically and puts less strain on the drives due to the soft transition.




**G69**

**Intersection**

Only in conjunction with G41/42 with an angle  $\alpha < 90^\circ$ .

With angles of  $\geq 90^\circ$  up to  $180^\circ$  the control will produce transitions as if G68 had been selected.



The control can carry out the calculations for intersections much faster than those for arcs; therefore G69 is most suitable for contours which require extremely fast block sequences.

**Programming**

G68/G69 without axis information.

If G68/69 is used while path compensation is active the function must be programmed 3 blocks in advance.

**Function active on switch-on**


Either G68 or G69 can be defined as active on switch-on by machine parameter.

\*dependent upon machine parameter

**REFERENCING**
**G74**
**Definition**

The axes programmed in the block traverse simultaneously onto the reference point(s) at the feedrate determined by m/c parameter.

Once the reference point has been reached the axis position values are set to machine specific values (machine parameters).

**Example**  
**X-axis**

**Interactions**

G74 cancels zero shifts which were activated with G54 to G59 or G92. No tool compensations must be active during G74. While G74 is carried out all modal conditions are temporarily suppressed.

**Programming**     **G 74 X Y Z E**

G74 is programmed in a separate block with just the relevant axis addresses without numerical values.

**Example G74**     X and Z traverse to the reference point.

N7 G74 X Z

**Note**

Further details on interactions with other functions can be found under

|          |                          |
|----------|--------------------------|
| G25, G26 | field limitation         |
| G53-59   | zero shifts              |
| G92      | setting position stores. |

**MEASURING PROBE INPUT**
**G75**
**Definition**

The control drives the measuring axes in the direction of the programmed position with linear interpolation (G1). While the axes are traversing the switching condition of the measuring probe is being monitored.

As soon as the signal becomes 1 (probe touching surface to be measured) the control responds as follows:

- it stores the current position values and
- cancels the distance to go and G75.


Once the G75 operation is completed the control automatically retracts the measuring axis to the position at which contact was made.

**Interactions**

G75 is effective only in the block in which it is programmed and automatically sets linear interpolation G1. The control only responds to the closing of the probe contact, and not to the opening of this contact. If the end point programmed with G75 is reached without the probe contact closing the program is interrupted and the error message "probe not triggered" is output.

**Programming**

**G75 X... (and/or Y.../Z.../E.../F...)**

**Example**


The probe is to be used to measure the distance from the two surfaces on the left hand side of the workpiece to the zero point. The axes have been driven to the starting position in a machining program.

N1 G75 X70 F200

traverse towards workpiece until probe is triggered

N2 M0

programmed stop to read position value

N3 G0 X40

reposition for next measuring operation

N4 Y20

N5 G75 X70

traverse towards workpiece to measure distance to upper surface

N6 G0 X0

N7 M3

**Applications**

The following tasks represent some of the applications:

- part recognition
- checking workpiece accuracy
- setting reference point at surface of workpiece
- tool inspection

**Note**

When working with the measuring probe the tool compensations must be switched off, otherwise the following error message will be displayed: "G-code not allowed with cut. or length comp."  
The feedrate should be kept moderate in order to avoid damage to the probe.

**MACHINING OF BORES**
**G80 A** Fixed Cycles Off  
**G81-87** Fixed Cycles On

**Usage**

The programming of fixed cycles to machine bores is simplified with the cycles described below.

In the course of the programming the user calls up the relevant fixed cycle. Values are entered for the variables; the variables are illustrated in the fixed cycle graphics.

**Conditions**

The fixed cycles can not be used while tool radius compensation is active; if necessary the tool radius compensation must be deactivated with G40.

Further conditions:

- F feedrate in mm/min
- S spindle speed
- M3/4 spindle rotation clockwise/counter-clockwise


Movements in the positioning plane are all performed in rapid with IN POS operation. The spindle is switched on with the first positioning movement. The cycles can be used with G90 or G91 for both axis directions of the feed-in axis.

**OPERATION**

Fixed cycles G81 - G87 are executed in each traversing block once the programmed position has been reached. The selected function is cancelled by programming G80, M2, M30 or by selecting another cycle.


Call-up of fixed cycles and input of variables:

Select main mode EDIT



# PROGRAMMING G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook



The selection of the required fixed cycle graphic is made with the and keys. When the required cycle is reached (cycle name flashing) the selection is confirmed with . The control will then automatically transfer into the selected fixed cycle level.

The inputs for the different variables in a particular cycle can be confirmed with the keys

The cursor will then automatically jump to the next variable.

## Handling of cycles

(RAM cycles, boring cycles, contour cycles)

See CC100M connections manual.

**PROGRAMMING**  
**G-FUNCTIONS**
**BOSCH CC 100 M**  
 User Handbook

**SURVEY OF  
FIXED MACHINING CYCLES**
**G80 - 87**

Machining sequence


| Type of machining                           | CODE | Feed- in movement                                       | At depth                                                    | Retract movement                                  |
|---------------------------------------------|------|---------------------------------------------------------|-------------------------------------------------------------|---------------------------------------------------|
| drilling                                    | G81  | M3<br>feed                                              | -                                                           | rapid<br>M3 active                                |
| boring with<br>dwell                        | G82  | M3<br>feed                                              | dwell                                                       | rapid/<br>feed<br>M3 active                       |
| deep hole<br>drilling with<br>swarf removal | G83  | M3<br>(posit. in rapid<br>+ feed-in strokes<br>in feed) | -<br>-                                                      | swarf removal<br>strokes in<br>rapid<br>M3 active |
| tapping with<br>tap holder                  | G84  | M3 (M4)<br>feed                                         | M4 (M3)<br>dwell                                            | feed<br>M4(M3) active                             |
| boring with<br>spindle<br>orientation       | G85  | M3<br>feed                                              | orient-<br>ation,<br>retract<br>in pos-<br>itioning<br>axis | rapid active                                      |
| reaming                                     | G86  | M3<br>feed                                              | -                                                           | feed with stop<br>for measuring<br>M0<br>M5       |
| thread milling                              | G87  | M3<br>helical<br>interpolation                          | retract<br>in pos-<br>itioning<br>axis<br>M5                | rapid                                             |
| cancelling fixed<br>cycles                  | G80  |                                                         |                                                             |                                                   |

**Note**

When editing fixed cycles the control will display the appropriate graphic for the active plane.

**FIXED MACHINING CYCLES**
**G80 - 87**

**Plane Selection** The fixed cycles can be used in the 3 main planes.  
 The selection of the interpolation plane determines the following:



| Positioning plane | Feed-in axis, positioning level, tool length compensation, workpiece surface, working depth | Code |
|-------------------|---------------------------------------------------------------------------------------------|------|
| X, Y              | Z                                                                                           | G17  |
| Z, X              | Y                                                                                           | G18  |
| Y, Z              | X                                                                                           | G19  |

The setting of a pole with G20 effectively also represents a plane selection.



# PROGRAMMING G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

## FIXED MACHINING CYCLES

**G80 - 87**

### Programming Technique


Fixed cycles simplify programming by their modal character. Programming is rationalized particularly well if the machining can be described by a machining graphic which can be used repeatedly. Only the different bore positions need then be programmed (see example).

### Machining Graphic

The machining graphic contains the coordinates and data which remain constant.

The call-up of the machining graphic is preceded by the selection of the particular fixed cycle with the required feedrate and spindle speed etc.

### Example Machining in Z (G17)



### Call-ups

|     |   |                |                |                |      |                                 |
|-----|---|----------------|----------------|----------------|------|---------------------------------|
|     | : | G0             | M...           | S...           | T... |                                 |
|     |   | TCH            |                |                |      | tool change                     |
|     |   | Z <sub>1</sub> | F <sub>1</sub> | S <sub>1</sub> | M3   | preconditions for drilling      |
| G81 |   | <b>G81</b>     | V1 to          | V4             |      |                                 |
|     |   | G22            | P1             |                |      | call-up of machining graphic    |
|     |   | M5             |                |                |      |                                 |
|     |   | TCH            |                |                |      |                                 |
|     |   | Z <sub>2</sub> | F <sub>2</sub> | S <sub>2</sub> |      | precond. for deep hole drilling |
| G83 |   | <b>G83</b>     | V1 to          | V6             |      |                                 |
|     |   | G22            | P1             |                |      | call-up of machining graphic    |
|     |   | M5             |                |                |      |                                 |
|     |   | TCH            |                |                |      |                                 |
|     |   | Z <sub>3</sub> | F <sub>3</sub> | S <sub>3</sub> |      | precond. for tapping            |
| G84 |   | <b>G84</b>     | V1 to          | V5             |      |                                 |
|     |   | G22            | P1             |                |      | call-up of machining graphic    |
|     |   | M5             |                |                |      |                                 |

**FIXED MACHINING CYCLES****G80 - G87****Variables V**

The program variables V1 to V6 are used by the fixed machining cycles. The fixed cycles use program variables V1 to V6, i.e. the contents of these parameters are modified by the call-up of a fixed cycle. When calling a fixed cycle all the relevant parameters must be defined. The variables must be programmed in one line together with the G-code for the particular fixed cycle.

**Positions**

Position values in the positioning plane relate to

the active zero point with G90

the previous position with G91

The data V1 to V6 for the feed-in axis are independent of G90/91 and are marked individually as

abs. = absolute values or

inc. = incremental values

**Spindle  
Rotation**

Unless otherwise described for the particular cycle, the main spindle is switched on before the start of the movement in the positioning plane, and it is not stopped automatically after the execution of the cycle.

**Safety  
Consideration**

**All fixed cycles operate with METRIC dimensions internally.** If a fixed cycle is called up in an INCH program the variables are converted into metric values. After the execution of the cycle the variables will be processed in the program as INCH values.

# PROGRAMMING G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

## DRILLING

### Definition

Drilling,  
centering

### Input

G0 --> G1 (and vice versa)  
change-over point  
depth of bore

V1 mm abs.  
V2 mm abs.

### Sequence

spindle on

1 positioning axes drive to the centre of the bore  
in rapid; feed- in axis remains at  
traversing height

2 feed-in axis drives to V1  
change-over to feed

3 feed-in axis drives to V2 in feed

4 retract to V1 in rapid

:

N9 T0101

N10 F500 S250 M3

N11 G81 V1=42 V2=7.5


:

N12 X125 Y175

N13 X128 Y204

N19 G80


:



**G 81**


rapid

feed



tool selection  
preconditions  
call-up of cycle G81  
and definition of variables  
machining positions

cancellation of cycle



# PROGRAMMING G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

## BORING

### DEFINITION

Boring or end facing with dwell at the bottom of the bore

### Input


change-over point

|               |       |            |
|---------------|-------|------------|
|               | G0-G1 | V1 mm abs. |
| depth of bore |       | V2 mm abs  |
| dwell         |       | V3 secs.   |
| retract       | G0:   | V4 = 0     |
|               | G1    | V4 = 1     |

### Sequence

spindle on

- 1 positioning axes drive to the centre of the bore in rapid; feed-in axis remains at traversing height
- 2 feed-in axis drives to V1; change-over to feed
- 3 feed-in axis drives to V2 in feed
- 4 dwell at bottom of bore for free-cutting
- 5 retract to V1 in rapid or feed



### Example


```

N9 T0101
N10 F500 S250 M3
N11 G82 V1=42 V2=-5 V3=10 V4=1
N12 X75 Y109
N13 X90 Y122
:
N19 G80
:

```

tool selection  
conditions  
call-up of cycle G82  
machining positions

cancellation of cycle



# PROGRAMMING

## G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

### DEEP HOLE DRILLING

### G83


#### Definition

Deep hole drilling in several feed-in movements with retract movements to remove swarf.

#### Input

change-over point  
final depth of bore  
minimum feed-in  
degression factor  
first feed-in  
safety distance

V1 mm abs.  
V2 mm abs.  
V3 mm inc.  
V4  
V5 mm inc.  
V6 mm inc.



#### Sequence

spindle on  
1 positioning axes drive to the centre of the bore in rapid;  
feed-in axis remains at traversing height

2 feed-in axis drives to V1;  
change-over to feed

3 feed-in axis drives to  
depth 1 ( $V5 \cdot 1$ ) in feed

4 in rapid to V1

5 back to depth 1 + V6


6 in feed to depth 2  
 $V5 \cdot (1 + V4)$

7 in rapid to V1

8 back to depth 2 + V6

9 in feed to depth 3  
 $V5 \cdot (1 + V4 + V4^2)$

ect.



# PROGRAMMING G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

## Degression Factor

The degression factor determines the individual feed-in depths for deep hole drilling. At each stage the previous feed-in depth is multiplied by the control with the degression factor in order to establish the next feed-in depth for the deep hole drilling cycle. The final depth is approached directly during the last feed-in movement.

If the chosen degression factor or the remaining distance would produce a feed-in of less than V3 this is prevented by a corrected input for the feed-in.

## Example

```


:
N4 T0101
N5 F500 S250 M3
N6 G83 V1=42 V2=10 V3=4.5 V4=0.9 V5=15 V6=4

N7 X92 Y17
N8 X88 Y42
:
N19 G80

```

tool selection  
conditions  
cycle call-up  
and definition  
of variables  
machining  
positions

cancellation of cycle



# PROGRAMMING G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

## TAPPING


## G84

### Definition

Tapping with central feed-in.

### Input

|                           |              |
|---------------------------|--------------|
| change-over point         | V1 mm abs.   |
| depth of bore<br>(thread) | V2 mm abs.   |
| rotation: M3/M4           | V3 3 inward  |
| M4/M3                     | V3 4 outward |
| feedrate                  | V4 mm/rev    |
| dwell                     | V5 sec.      |



### Sequence

spindle on, single block  
suppressed

1 positioning axes traverse  
the centre of the bore in  
rapid; feed-in axis remains  
at traversing height


2 feed-in axis drives to  
V1; change-over to feed

3 feed-in axis drives to depth  
V2 at feedrate determined by V4

4 reversal of spindle rotation;  
dwell at bottom of bore

5 retract to V1 in feed

6 spindle stop  
single block possible again



# PROGRAMMING G-FUNCTIONS


**BOSCH CC 100 M**  
User Handbook

## Example

```

:
N9 T0101 tool selection
N10 F500 S250 M3 conditions
N11 G84 V1=40 V2=-10 V3=3 V4=10 V5=5 call-up of cycle
 G84 and definition
 of variables
 machining
N12 X16 Y52 positions
N13 X27 Y48
:
N19 G80 cancellation
 of cycle


```



The following functions are activated:

|     |                                    |
|-----|------------------------------------|
| M3  | spindle rotation clockwise         |
| M4  | spindle rotation counter-clockwise |
| M98 | single block suppressed            |
| M99 | single block possible              |

## Note

- Feed conditions active before the call-up of the cycle are stored and reactivated automatically once the cycle has been completed.
- While G84 is active the reentry functions are not active. 
- Feedrate 100% is set automatically;  
single block is suppressed automatically (M98).



# PROGRAMMING

## G-FUNCTIONS

# BOSCH CC 100 M

## User Handbook

### BORING


### G85

#### Definition

Boring a rough bore with a boring tool. Oriented spindle stop at the bottom of the bore with eccentric retract.


#### Input

change-over point V1 mm abs.  
depth of bore V2 mm abs.  
transverse movement at bottom of bore V3 mm inc.



#### Sequence

- spindle on
- 1 positioning axes drive to the centre of the bore in rapid; feed-in axis remains at traversing height
- 2 feed-in axis drives to V1; change-over to feed
- 3 feed-in axis drives to depth V2 in feed
- 4 oriented spindle stop, M19 at the bottom of the bore, angle = 0°
- 5 transverse movement of abscissa axis by distance V3 (negative axis direction)
- 6 eccentric retract of the feed-in axis to V1



#### Condition

If cycle G85 is to be used an encoder is required to allow spindle orientation (M19); otherwise an error message is displayed.

# PROGRAMMING G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook


## Example

```

:
N9 T0101
N10 F500 S250 M3
N11 G85 V1=40 V2=8 V3=3
:
N12 X59 Y74.5
N13 X47 Y83
:
N19 G80
N20
:

```

tool selection  
conditions  
call-up of cycle G85 and  
definition of variables  
machining positions  
  
cancellation of cycle



The following functions are activated:

M3 spindle rotation clockwise  
F feedrate active before call-up  
M19 spindle stop with orientation,  
remains active after execution of cycle

**THREAD MILLING**
**G87**



**Definition** A thread is cut by the helical motion of the tool.

**Input**

|                         |    |           |
|-------------------------|----|-----------|
| change-over point       | V1 | abs.      |
| machining depth         | V2 | abs.      |
| thread diameter         | V3 | abs.      |
| thread pitch/rev.       | V4 |           |
| right/left-hand thread: | V5 | = 2 right |
|                         | V5 | = 3 left  |

**Sequence**

- spindle on
- 1 positioning axes drive to centre of bore in rapid; feed-in axis remains at traversing height
  - 2 feed-in axis drives to V1; change-over to feed
  - 3 helical interpolation in feed down to the bottom of the thread
  - 4 tool positioned to centre of bore
  - 5 retract in rapid to V1



# PROGRAMMING G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

## Example

```

:
N10 F500 S250 M3 T1212
N11 G87 V1=42 V2=34.5 V3=10 V4=0.35 V5=2

```

conditions  
call-up for  
cycle G87 and  
definition of  
variables

```

N12 X44 Y24
N13 X32 Y26
:

```

```

N19 G80


```

cancellation  
of cycle

```

N20

```



# PROGRAMMING

## G-FUNCTIONS

# BOSCH CC 100 M

## User Handbook

### REAMING

### G86

#### Definition

After the 1st CYCLE START the reaming bit is sunk into the workpiece for a short trial feed-in and then retracted to allow measuring.

From the second CYCLE START onwards the tool is driven to the full depth.

#### Input

|                              |    |      |
|------------------------------|----|------|
| change-over point            | V1 | abs. |
| machining depth              | V2 | abs. |
| 1st feed-in depth            | V3 | inc. |
| retract height for measuring | V4 | abs. |

#### Sequence

spindle on

1 positioning axes drive to the centre of the bore in rapid; feed-in axis remains at traversing height

2 feed-in axis drives to V1: change-over to feed

3 feed-in axis drives down by V3 to first feed-in depth in feed

4 in feed to change-over point V1

5 in rapid to retract height V4; spindle continues to rotate;

program stop, **M0 is active**


diameter of the bore can be measured, and the spindle speed corrected

After 2nd CYCLE START:

6 in rapid to V1

7 in feed to bottom of bore V2

8 in feed to change-over point



# PROGRAMMING G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook


## Example

```

:
N9 T0101 tool selection
N10 F500 S250 M3 conditions
N11 G86 V1=40 V2=10 V3=15 V4=42 call-up of cycle G86
 and definition of
 variables
 machining positions

N12 X97 Y102
N13 X86 Y113
:
N19 G80 cancellation of cycle

```



The following functions are activated:

F = feedrate active call-up

S = old, possibly corrected spindle speed

M3

G0, which remains active after the execution of the cycle

# PROGRAMMING G-FUNCTIONS

# BOSCH CC 100 M User Handbook

## DIMENSIONING

**G90 A** ABSOLUTE DIMENSIONS  
**G91** INCREMENTAL DIMENSIONS

### Definition

Positions on workpiece contours can be defined with:

**G90** absolute dimensions, i.e. all dimensional values relate to the active program zero point

or

**G91** incremental dimensions, i.e. all dimensional values relate to the respective previous positions. It is advisable to use G91 for contours which need to be machined repeatedly in different places.

### Operation


G90/91 are modal and exclude one another.

They can be programmed with or without axis information.

The axis displays are not influenced by these functions.

When G92 is cancelled G90 becomes active.


### Example G90



| program         | points in drawing |
|-----------------|-------------------|
| N1 G90          |                   |
| N2 G0 X120 Y60  | P1                |
| N3 G1 Y20 F300  | P2                |
| N4 G5 X115 Y15  | P3                |
| N5 G1 X80       | P4                |
| N6 X55 Y25      | P5                |
| N7 X30          | P6                |
| N8 Y60          | P7                |
| N9 X60          | P8                |
| N10 Y50         | P9                |
| N11 X80         | P10               |
| N12 Y60         | P11               |
| N13 X110        | P12               |
| N14 G5 X120 Y50 | P13               |
| N15 G5 X160     | P14               |
| N16 M2          |                   |

### Example G91

all pieces of axis information relate to the coordinates of point P1




|                 |     |
|-----------------|-----|
| N1 G90 X120 Y60 | P1  |
| N2 G91          |     |
| N3 G1 Y-40 F300 | P2  |
| N4 G5 X-5 Y-5   | P3  |
| N5 G1 X-35      | P4  |
| N6 X-25 Y10     | P5  |
| N7 X-25         | P6  |
| N8 Y35          | P7  |
| N9 X30          | P8  |
| N10 Y-10        | P9  |
| N11 20          | P10 |
| N12 Y10         | P11 |
| N13 X30         | P12 |
| N14 G5 X10 Y-10 | P13 |
| N15 X40         | P14 |
| N16 G90         |     |
| N17 M2          |     |

**SETTING POSITION STORES**
**G92**

**Definition** G92 is used to assign a new value to the position at which the axis stands, and to display this value. There is no axis movement involved.

**G92 X Y Z E**

**G92** By programming G92 without axis values the machine coordinates are reactivated.

**Example**


**G92 S** Setting of upper spindle speed limit.

**Operation** Values can be set for up to 4 axes.  
 G92 can be used in MDI or in automatic.  
 G92 is active only in the block in which it is programmed.  
 To cancel G92 no other functions must be programmed in the same block as G92.  
 Any values within the input range can be used.  
 The travel limits determined by the hardware and software limit switches are not affected.



# PROGRAMMING


## G-FUNCTIONS

# BOSCH CC 100 M

## User Handbook

|                    |                               |                                |
|--------------------|-------------------------------|--------------------------------|
| <b>Programming</b> | <b>G92 X... Y... Z... E..</b> | assign axis values             |
|                    | <b>G92</b>                    | reactivate machine coordinates |
|                    | <b>G92 S..</b>                | limit spindle speed            |

### Example



| program          | points in drawing |
|------------------|-------------------|
| N1 G90 F200      |                   |
| N2 G1 X140 Y70   | P1                |
| N3 G92 X0        |                   |
| N4 G1 Y30        | P2                |
| N5 G5 X-10 Y20   | P3                |
| N6 G1 X-55       | P4                |
| N7 X-65 Y30      | P5                |
| N8 X-85          | P6                |
| N9 X-95 Y20      | P7                |
| N10 X-100        | P8                |
| N11 G5 X-110 Y30 | P9                |
| N12 G1 Y70       | P10               |
| N13 X0           |                   |
| N14 G92          |                   |
| N15 M30          |                   |

**Application**  
**G92 X to E**  
 G92 X to E is used to adapt a program compiled with dimensions from a drawing for a particular clamping position.

**Comments/ Restrictions**  
 G92 should **not** be used in conjunction with the following:

- active tool radius compensation **G41/42**  
 active tool length compensations address T
- active field limitation **G25/26**  
 (G92 resets any field limitation)

In addition the following points must be taken into consideration:

- G92 does not take any active zero shift into account;  
 when G92 is cancelled **G54 - G59** are reset as well.
- If while **G92 S..** is effective a spindle speed in excess of the limit is programmed elsewhere in the program the set max. value will be output with automatic gear range selection.
- When **G92 is cancelled** (G92 without axis or spindle values) G1 is automatically activated.
- G92 (without axis addresses) sets **G27**, cancelling any field limitation.
- When a **field limitation** is set with **G25, G26** any zero shift with G92 X... Y... is ignored.
- When G92 is cancelled **G90** is activated.

# PROGRAMMING

## G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook


### FEEDRATES

**G94 A feedrate direct**  
**G93 time programming**

**G94** **Direct specification of feedrate F in mm/min.**  
This type of feedrate output is active on switch-on.  
Axis movement is possible with the spindle at standstill.

**G94**  
**Programming** **G94 F... = feedrate in mm/min**

With or without axis information. Feedrate F programmed with G94 is modal.




**G93** **Specification of the execution time for a path section.**

The corresponding feedrate is calculated by the control.

**Possible applications**  
Complex movements involving more than one axis.  
Simultaneous movement of linear axes and rotary axes.  
Polygon contours for which block preparation time is of importance.

**G93**  
**Programming** **G93 F... F = execution time in seconds**

With or without axis information. The execution time F programmed with G93 only applies for the block in which it is programmed.



**Operation** G93/G94/G95 exclude one another.

# PROGRAMMING G-FUNCTIONS

# BOSCH CC 100 M User Handbook

## FEEDRATE MM/REV

## G95

### Definition

Programmed feedrates relate to the speed of the main spindle.  
The axis movements are derived from the actual spindle speed  
and are therefore synchronised with the spindle.  
The spindle speed determines the axis feedrate.

### Programming Example

**G95 F 1.67**

Feedrate 1.67 mm/rev applies.

Feedrates of linear axes = mm/rev.

Feedrate of rotary axis = degrees/rev.


### Resultant

$F_R$  = feedrate in mm/min

### Feedrate $F_R$

$F$  = feedrate in mm/rev.

$S$  = spindle speed



Example:  $F = 2$  mm/rev. and  $S = 500$  rpm produce a resultant feedrate of 1000 mm/min.

Axis movements in feed only if the main spindle is running!

### Note:

- Since the feedrate is derived from the actual spindle speed no axis movements are possible when there is a fault in the main spindle servo loop.
- Spindle speed output in BCD is not permitted.
- With G95 active no S-word is output via the BCD bus.

# PROGRAMMING G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

## AUTOM. CALCULATION OF CUTTING SPEED IN M/MIN


**G96**

**Definition** The control calculates the spindle speed from the data for cutting speed and tool radius stored in the technology store of the programmed tool.

**Operation** With M3 or M4 active, the spindle speed is activated after the programming of a T-word. G96 and G97 cancel one another.

**Programming** On its own or together with other instructions.

**Spindle speed** 
$$n = \frac{S}{2 \cdot \pi \cdot R}$$
 formula for calculating the spindle speed  
R = tool radius (in tool table)  
S = cutting speed "



**Example:** A cutter radius of 20 mm plus a required cutting speed of approx. 25 m/min will result in the output of 200 rpm for the spindle speed.

**Usage** Before the call-up to G96 a starting speed can be selected (with G97). G96 must be cancelled before M5 (G97).

**Note** It is important for the calculations that the tool radius is defined in mm in the tool table.  
The cutting speed is specified in mm/min.  
The tool wear compensation (DR-value in tool table) is not taken into account in the spindle speed calculation.

**SPINDLE SPEED DIRECT**
**G97 A**
**Definition**

The speed of the main spindle is determined with S directly in rpm.  
 The spindle speed does not influence any axis movements.  
 G97 is active on switch-on.

**Programming**

**G97** no change in the spindle speed

**G97 S...** new spindle speed S... is activated

Overriding the programmed spindle speed:

**G66** overriding is possible via the potentiometer on the manual panel

**G63** the override potentiometer is not effective

Effect of gear range selection:


**M40** automatic recognition and output

**M41-44** direct programming of the gear range

see also SPINDLE SPEEDS chapter 3 ADDRESS S  
 GEAR RANGES  
 M-FUNCTIONS

**M40**

Automatic gear range selection and speed ranges for the individual gear ranges:



Selected gear ranges when different speeds are programmed:

A: gear range II

B: gear range III

C: gear range IV

With speeds at which two gear ranges overlap the lower gear range (higher motor speed and higher torque) will be output.

# PROGRAMMING

## G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

### SUBPROGRAM END

### G99

#### Definition

G99 designates the end of a subprogram.  
G99 is the instruction to jump back within the program from which the call-up was made to the position at which the subprogram was called up.  
The next program block will then be executed.

#### Programming

G99 without any other instructions.

#### Example

|             |                                                                                    |
|-------------|------------------------------------------------------------------------------------|
| N1 .        | beginning of main program 5                                                        |
| N2 .        |                                                                                    |
| N3 G22 P15  | call-up of subprogram 15                                                           |
| .           |                                                                                    |
| .           |                                                                                    |
| N20 G22 P12 | call-up of subprogram 12                                                           |
| .           |                                                                                    |
| .           |                                                                                    |
| N37 G22 P20 | call-up of subprogram 20                                                           |
| N38 .       |                                                                                    |
| N39 .       |                                                                                    |
| N40 M2      | main program end                                                                   |
|             | (there must be M2/M30 between the<br>main program and the associated subprograms!) |
| N41 \$15    | beginning of subprogram 15                                                         |
| N78 ...     |                                                                                    |
| N79 G99     | end of subprogram 15                                                               |
| N80 \$12    | beginning of subprogram 12                                                         |
| N115...     |                                                                                    |
| N116 G99    | end of subprogram 12                                                               |
| N117 \$20   | beginning of subprogram 20                                                         |
| N207...     |                                                                                    |
| N208 G99    | end of subprogram 20                                                               |

#### Note

The program from which the call-up is made can be a main program, a subprogram or a cycle.  
Maximum nesting depth is 10 (see under G21, G22).

**THREE-DIGIT G-CODES**
**G800 to G869**

**Definition** The control operates with 3-digit G-codes.  
 The functional content of these codes must be defined by the machine tool builder or the user himself.

**Programming** The machining sequence is programmed as a cycle.  
 Both the standard instructions as well as the parametric functions can be used to program these cycles.

Application examples:

Machine specific operations such as  
 delivery and removal of workpieces  
 measuring, spot checks  
 tool inspection  
 punching/nibbling cycles  
 control of auxiliary machinery

Simplification of programming by the use of cycles for

the firm's own particular methods  
 for the machining of bores,  
 of standard parts, of part families,  
 for calculations,  
 for the adaptation of the CC 100 to  
 special machines.

**Cycle Numbers  
and Call-up**


| Programming | Call-up    |
|-------------|------------|
| cycle       | G-function |
| 1           | G 801      |
| .           | .          |
| .           | .          |
| 69          | G 869      |

**Example** A machining cycle written under cycle 45 is called up by G845.

### CONTOUR CYCLES

#### G890 to G898

These 3-digit G-codes calculate positions which might not be provided on the drawing in all 3 main planes.



The control automatically makes the correct allocation of entered abscissa and ordinate values to the relevant axes, dependent on the plane selection.

#### Axis Allocation

|            | G17 | G18 | G19 |
|------------|-----|-----|-----|
| abscissa A | X   | Z   | Y   |
| ordinate 0 | Y   | X   | Z   |

#### Execution

**Cycles G890 and G891 are pure calculating cycles.** The results obtained by calling them up can then be used in the course of the part program.

**Cycles G892 to G898 process the values** by executing the contour.



# PROGRAMMING G-FUNCTIONS

**BOSCH CC 100 M**  
User Handbook

## Call-up of Contour Cycles in a Program

### Operating Sequence

Main mode EDIT



|       |                |           |          |        |
|-------|----------------|-----------|----------|--------|
| TOOLS | ZERO<br>SHIFTS | VARIABLES | PROGRAMS | CYCLES |
|-------|----------------|-----------|----------|--------|

---> program call, e. g. **[9]** **[ENTER]**

|         |              |      |      |      |
|---------|--------------|------|------|------|
| COMMAND | NEXT<br>PAGE | EDIT | LOAD | SAVE |
|---------|--------------|------|------|------|

|                   |  |        |  |                  |
|-------------------|--|--------|--|------------------|
| SEARCH<br>GRAPHIC |  | SCROLL |  | MODIFY<br>INSERT |
|-------------------|--|--------|--|------------------|

|  |  |  |                  |                   |
|--|--|--|------------------|-------------------|
|  |  |  | BORING<br>CYCLES | CONTOUR<br>CYCLES |
|--|--|--|------------------|-------------------|

↓

CYCLE      3 \*\*\*\*\*      M RWED      MEMORY


|                         |                          |                  |                         |         |
|-------------------------|--------------------------|------------------|-------------------------|---------|
|                         |                          |                  |                         |         |
| Intersect.<br>2 circles | Intersect.<br>Line/circ. | 2 points         | 1 point +<br>2 angles   | Chamfer |
|                         |                          |                  |                         |         |
| point on<br>circle      | tangent<br>circles       | point on<br>line | Intersect.<br>line/line |         |
|                         | ←                        |                  | →                       | OK      |

The required cycle is to be selected with the **←** or the **→** key and confirmed with **[OK]**.

Once the variables have been defined and the cycle input confirmed with **[ENTER]** the contour cycle will be stored in the program.

**INTERSECTION CIRCLE/CIRCLE**
**G890**
**Definition**

This is a pure calculating cycle and will not produce any axis movement.


**Input**
**G890**

|           |        | G17 | G18 | G19 |
|-----------|--------|-----|-----|-----|
| V90 = A   | 1st    | X   | Z   | Y   |
| V91 = 0   | centre | Y   | X   | Z   |
| V92 = 1st | radius |     |     |     |
| V93 = A   | 2nd    | X   | Z   | Y   |
| V94 = 0   | centre | Y   | X   | Z   |
| V95 = 2nd | radius |     |     |     |

**Results**

After the call-up the contents of the variables are as follows:

intersection P1      V90 = abscissa      V91 = ordinate  
 intersection P2      V93 = abscissa      V94 = ordinate

Position of the intersections, looking from the first to the second centre of the circle:

P1 lies to the right of the connecting line  
 P2 lies to the left of the connecting line

**Example**

The calculated points P1/P2 could be used as follows:


```

N1 G0 X60 Y85
N2 G890 V90=75 V91=90 V92=5 V93=82 V94=100 V95=8.5 cycle call-up
N3 G1 F750
N4 X=V90 Y=V91 allocation of variables
N5 G2
N6 X=V93 Y=V94 R=V95 allocation of variables
N7 M30

```

**INTERSECTION LINE/CIRCLE**
**G891**
**Definition**

This is a pure calculating cycle and it will not produce any axis movement.


**Input**
**G891**

V90 = A } centre of  
 V91 = 0 } circle  
 V92 = } radius  
 V93 = A } for point  
 V94 = 0 } ①  
 V95 = A }  
 V96 = 0 } ②

| G17 | G18 | G19 |
|-----|-----|-----|
| X   | Z   | Y   |
| Y   | X   | Z   |
| X   | Z   | Y   |
| Y   | X   | Z   |

|   |   |   |
|---|---|---|
| X | Z | Y |
| Y | X | Z |
| X | Z | Y |
| Y | X | Z |

**Results**

After the call-up the calculated values will be stored in variables as follows:

|                 |                |                |
|-----------------|----------------|----------------|
| intersection P1 | V90 = abscissa | V91 = ordinate |
| intersection P2 | V93 = abscissa | V94 = ordinate |

**Application**

The calculated points P1/P2 can be used as follows:

|    |       |        |         |        |        |                         |
|----|-------|--------|---------|--------|--------|-------------------------|
| N1 | G0    | X0     | Y0      |        |        |                         |
| N2 | G891  | V90=40 | V91=30  | V92=15 | V93=15 | cycle call-up           |
|    |       | V94=30 | V95=100 | V96=45 |        |                         |
| N3 | G1    | F750   |         |        |        |                         |
| N4 | X=V90 | Y=V91  |         |        |        | allocation of variables |
| N5 | G2    |        |         |        |        |                         |
| N6 | X=V93 | Y=V94  | R=V92   |        |        | allocation of variables |
| N7 | M30   |        |         |        |        |                         |


### ROUNDING CORNERS (3 POINTS)

**G892**

### Definition

### Calculation of positions to round corners with 3 known points.

This cycle calculates the positions and then initiates the traversing movement.



### Input

**G892**

① starting point = last programmed position

|                | G17 | G18 | G19 |
|----------------|-----|-----|-----|
| ② intersection | X   | Z   | Y   |
|                | Y   | X   | Z   |
| ③ end point    | X   | Z   | Y   |
|                | Y   | X   | Z   |

V94 = radius

V95 = 0 = machining up to P2

1 = machining up to end point (3)

### End Point of Machining

The end point of the machining is determined by the input for V95. When several contour cycles are linked together the previous contour cycle must not be machined up to the end point.

## Results


|                      |                   |                |
|----------------------|-------------------|----------------|
| 1st transition point | P1 V96 = abscissa | V97 = ordinate |
| 2nd transition point | P2 V98 = abscissa | V99 = ordinate |

### Example

|    |             |        |        |         |                                                            |
|----|-------------|--------|--------|---------|------------------------------------------------------------|
| N1 | G1          | X20    | Y20    | F100    | starting position                                          |
| N2 | <b>G892</b> | V90=55 | V91=60 | V92=100 | V93=30 V94=20 V95=1 cycle call-up<br>+ variable allocation |
| N3 | X110        | Y65    |        |         |                                                            |
| N4 | M30         |        |        |         |                                                            |

**ROUNDING CORNERS (2 ANGLES)**
**G893**
**Definition**

Calculation of positions to round corners with known angle values.  
 The cycle calculates the positions and initiates the traversing movement.


**G893**
**Input**

starting point ① = last programmed position  
 angles V90 = alpha V91 = beta  
 - input range -180° to +180°  
 - sign determines direction of rotation  
 - the abscissa is the reference axis

end point ②

| G17 | G18 | G19 |
|-----|-----|-----|
| X   | Z   | Y   |
| Y   | X   | Z   |

V92 = A

V93 = 0

V94 = radius for arc

V95: 0 machining up to point P2

1 machining up to end point

**End Point of Machining**

The end point of the machining is determined by the input for V95. When several contour cycles are linked together, the previous contour cycle must not be machined up to the end point.

**Programming**

G893 V90 = ... V91 = ... V92 = ... V93 = ... V94 = ... V95 = ...

**Results**

1st transition point P1

V96 = abscissa

V97 = ordinate

2nd transition point P2

V98 = abscissa

V99 = ordinate

# PROGRAMMING CONTOUR CYCLES


**BOSCH CC 100 M**  
User Handbook

## CHAMFERING

**G894**

### Definition

Calculation of positions to apply chamfers to straight contour elements.  
The cycle calculates the positions and initiates the traversing movement.



### Input

G894  
starting point 1 = last programmed position

intersection 2

V90 = A

V91 = 0

end point 3

V92 = A

V93 = 0

G17 | G18 | G19

X | Z | Y

Y | X | Z

X | Z | Y

Y | X | Z

V94 = length of chamfer

V95: 0 = machining up to point P2

1 = machining up to end point

### End Point of Machining

The end point of the machining is determined by the input  
for V95. When linking several contour cycles the previous  
contour cycle must not be machined up to the end point.

### Results

1st transition point P1 V96 = abscissa V97 = ordinate

2nd transition point P2 V98 = abscissa V99 = ordinate

### Example

N1 G1 X80 Y5 F1000

starting position

N2 X50

last contour point before call-up


N3 G894 V90=50 V91=40 V92=10 V93=45 V94=10 V95=1

cycle call-up and variable allocation

N4 M30

**CALCULATION OF THE END POINT OF AN ARC**
**G895**
**Definition**

Calculation of the end point of an arc, of which only one coordinate is known.  
 The cycle calculates the position and initiates the traversing movement if COND. SBP CALL-UP is high.


**Input**
**G895**

- starting point ① = last programmed position .
- end point ② V90 = A or 0-value  
 V91 = 1: V90 represents abscissa  
 V91 = 2: V90 represents ordinate
- centre of circle ③ V92 = A  
 V93 = 0  
 V94 =  $\pm$ radius (+) larger/equal 180°  
 - smaller 180°  
 V95 = direction of rotation = 2 : G2  
 = 3 : G3

**Programming**

G895 V90 = ... V91 = ... V92 = ... V93 = ... V94 = ... V95 = ...

**Results**


end point ② V90 = abscissa V91 = ordinate

The missing coordinate value of the end point is calculated.

**TRANSITION POINT ARC/ARC tangential**
**G896**
**Definition**

The control calculates the transition point of two consecutive arcs with tangential transition and a reversal of the direction of rotation.

The cycle calculates the positions and initiates the traversing movement.


**Input**
**G896**

starting point ① = last programmed position

 1st centre of circle  $V90 = A$   $V91 = 0$ 

 2nd centre of circle  $V94 = A$   $V95 = 0$ 

 end point ②  $V92 = A$   $V93 = 0$ 

 direction of  
rotation

 $V96 = 2$  corresponds to G2/G3

 $V96 = 3$  corresponds to G3/G2

**Programming**

 G896  $V90 = \dots V91 = \dots V92 = \dots V93 = \dots V94 = \dots V95 = \dots V96 = \dots$ 
**Results**


 Transition point P1  $V97 = \text{abscissa}$   $V98 = \text{ordinate}$



**CALCULATION OF THE END POINT OF A STRAIGHT LINE**
**G897**

**Definition** Calculation of the end point of a straight line, of which only one coordinate is known.

The cycle calculates the positions and initiates the traversing movement.


**Input**
**G897**

starting point ① = last programmed position

angle  $V92 = \pm 180$

end point ②  $V90 = A$  or 0-value  
 $V91 = 1$ :  $V90$  represents abscissa value  
 $V91 = 2$ :  $V90$  represents ordinate value

**Programming**

G897  $V90 = \dots$   $V91 = \dots$   $V92 = \dots$

**Results**


The unknown coordinate of the end point is calculated, after which the contents of the variables will be as follows:

$V90 =$  abscissa value  
 $V91 =$  ordinate value

**INTERSECTION OF TWO STRAIGHT LINES**
**G898**

**Definition** Calculation of the intersection of two straight lines from the entered angle values.

The cycle calculates the positions and initiates the traversing movement.


**G898**

**Input**

|                |                            |                |
|----------------|----------------------------|----------------|
| starting point | = last programmed position |                |
| end point      | V90 = abscissa             | V91 = ordinate |
| angles         | V92 = alpha                | V93 beta       |

- input range  $-180^\circ$  to  $+180^\circ$
- sign determines direction of rotation
- the abscissa is the reference axis

V94 = 0: machining up to P2  
 = 1: machining up to end point

**End Point of Machining** The end point of the machining is determined by the input for V94. When several contour cycles are linked together the previous contour cycle must not be machined up to the end point.

**Programming** G898 V90=... V91=... V92=... V93=... V94=...

**Results** The position of the intermediate point P2 is calculated and the axes drive to this position; the values are stored in the following variables:

V95 = abscissa value  
 V96 = ordinate value

# PROGRAMMING CONTOUR CYCLES

# BOSCH CC 100 M

User Handbook

## SURVEY OF FIRMLY ALLOCATED CYCLES

|                        | Function                                                            | Programmed<br>under cycle,<br>main mode | Call-up via                                     |
|------------------------|---------------------------------------------------------------------|-----------------------------------------|-------------------------------------------------|
| <b>User<br/>cycles</b> | freely programmable                                                 | 1 - 69                                  | G8nn                                            |
| <b>MTB cycles</b>      | priority routine                                                    | 74                                      | interface signal<br>fast input on<br>SERVO card |
|                        | MTB cycle                                                           | 75    "                                 | M22                                             |
|                        | MTB cycle                                                           | 76    "                                 | M21                                             |
|                        | MTB cycle                                                           | 77    "                                 | M6                                              |
|                        | allocation of functions<br>for keys F1 to F10 of<br>customer keypad | 78    "                                 | customer keys                                   |
|                        | referencing cycle                                                   | 79    "                                 | soft key selection                              |

Cycles 1 - 69 are available for use by the enduser, unless predetermined by the MTB.

These cycles can be used to program recurring machining tasks.

A cycle with the number nn is called up with G8nn. Input variables can be written together with the 3-digit G-code, for instance:

G824 V1 = ... V10 = ... V55 = ... (call-up for cycle 24)

Cycles 70 - 73 are routines which are used internally by the control and which have fixed functions. They are not available for use by the enduser.

## 4. PARAMETRIC FUNCTIONS

# V 15 = ATG VX

## Range

The following functions are available:

load instructions for numerical values, 125 variables V1 to V99, VA to VZ,  
basic arithmetic functions, trigonometric functions, copy instructions,  
logic operations, branching, access to NC data.

**The user can write his own cycles with parametric functions.**

CPC = Customer parametric Cycle

A CPC represents the solution of a problem in principle.

Values such as spindle speed, dimensions, tool no. etc. are kept variable.

Once the parametric program has been produced the only actions necessary for the execution are to load values for the variables and call up the program.

## Applications

Production of customer's own cycles for:

automatic measuring cycles with calibration of the probe,  
measuring of the workpiece, and automatic tool wear compensation  
production counters, random sample counters  
scale factors for similar parts,  
variable programs of all types

## Programming

During **panel input** the CPC key is pressed before the input of a computing function. This automatically activates the secondary function ( inscribed at the top) of the dual function keys.

During **external programming** the mnemonic codes used by the control when printing out parametric instructions must be used to write the program.

Example: load variable 5 with the content of variable 2 + value 10

## To store



## To execute



## External programming

N12 V5 = V2 + 10 ( **Note** Only whole numbers are accepted)

One program line can contain several computing functions. They will be executed in the same sequence in which they were written.

Example: V17 = V2 \* V3 V25 = SIN V17 V26 = COS V17

## Note

- The programming in each line must be either all conventional or all parametric.
- Parametric functions must always be programmed without space characters, e.g. ATG VX, in order to avoid syntax errors.

**Program Planning** Before starting to produce programs it is advisable to do some general program planning. This should take the following points into consideration:

- Is a program to be used completely independently?
- Or is the program to be used in conjunction with other program modules?  
If so, with which ones?
- Is the program to be produced as a main program, a subprogram or a cycle?
- Which other programs must/can be stored in the memory at the same time?
- Which variables will be used?

**Aims** Simplification of the continuing program administration.

- Rationalized program production
- Problem-free combination of programs
- Multiple use of program modules

**FORMS** The following forms help with program planning:

- Memory Allocation
- General Program Planning
- Variables
- Program Description

**Memory Allocation** This form shows **which programs, cycles, subprograms etc. are stored in the control together.**

**Program Planing** This form shows at a glance **which variables are used by which program**, and which are still available to be used.

**Variables** This form can be used when **testing** programs, by tracking the meaning and the contents of the variables.

**Program Description** This is an aid for the **program user**, and it should consist of at least a top sheet with

- a sketch of inputs/possibly the sequence
- required storage capacity, short functional description



[illegible]



## ARITHMETIC FUNCTIONS

|                       |                       |     |
|-----------------------|-----------------------|-----|
| <b>Addition</b>       | $V1 = V2 + V3$        |     |
|                       | $V1 = V2 + 157$       | *)  |
| <b>Subtraction</b>    | $V1 = V2 - V3$        |     |
|                       | $V1 = V2 - 157$       | *)  |
| <b>Multiplication</b> | $V1 = V2 * V3$        |     |
|                       | $V1 = V2 * 157$       | *)  |
| <b>Division</b>       | $V1 = V2 / V3$        |     |
|                       | $V1 = V2 / 157$       | *)  |
| <b>Square root</b>    | $V1 = \text{SQR } V2$ | **) |

**Definition** Arithmetic functions, using the contents of variables or direct numerical values.

**Programming**  $VN = VM + VP$        $V1 = VN * 12$  \*)       $VJ = \text{SQR } V1$  \*\*)

**Example** Finding the square roots of a quadratic equation in a program line.

$$X_{1/2} = -\frac{P}{2} \pm \sqrt{\left(\frac{P}{2}\right)^2 - q}$$

with  $P = V1$   
 $q = V2$

$$V4 = V1 / 2 \quad V3 = V4 * V4 \quad V3 = V3 - V2$$

$$V3 = \text{SQR } V3 \quad V5 = V4 * -1 \quad VX = V5 - V3 \quad VY = V5 + V3$$

VX and VY will contain the solutions after the execution of the program line.

**Sequence** The sequence in which the functions are written determines the sequence in which they are executed.

**Note** \*) For arithmetic and trigonometric functions the numerical values can be entered directly with max. 3-digit, positive integer numbers or max. 3-digit negative integer numbers.

\*\*) CPC computing functions (SQR, COS, SIN, ATG) should be programmed without any space characters only with variables; numerical values are not permitted.

**INCREMENT / DECREMENT**

|                        |               |
|------------------------|---------------|
| <b>Increment value</b> | <b>INC V1</b> |
| <b>Decrement value</b> | <b>DEC V1</b> |

**Definition** The content of a variable is incremented or decremented by 1.  
Any digits after the decimal points are deleted.

**Programming** INC VN DEC VM

**Example** N1 V1 = 12 V4 = 1.7 V5 = -1.3

N13 INC V1 INC V4 DEC V5

After the execution of N13 the contents of the variables are as follows:  
V1 = 13 V4 = 2 V5 = -2

**Integer Number** A real number can be converted into the corresponding integer number by performing the INCREMENT and then the DECREMENT function.

**REGISTERING TIME** **TIM V1**

**Definition** The time elapsed since the start of the program is loaded into the variable (seconds).

**Programming** TIM VN  
N from 1 to 99 and from A to Z.

**Example**

```

N1 $5-
N2 G91
N3 G1 X1 F250
N4 TIM V1

N5 V2 = 50
N6 V3 = V2 - V1 BGT P5

```

registering time for G1-function  
storing value in V1,  
time limit 50 seconds;  
checking condition and branching;  
the program sequence is not  
completed until the time limit  
of 50 seconds is reached; other-  
wise a jump is made into SBP 5.

N M2

## PARAMETRIC FUNCTIONS

## BOSCH CC 100 M

## User Handbook

## VARIABLES (global)

L = loaded value

C = constant

Ca = calculated value  
(temporary)

| function | V | value | function | V | value |
|----------|---|-------|----------|---|-------|
|          | 0 |       |          | 0 |       |
|          | 1 |       |          | 1 |       |
|          | 2 |       |          | 2 |       |
|          | 3 |       |          | 3 |       |
|          | 4 |       |          | 4 |       |
|          | 5 |       |          | 5 |       |
|          | 6 |       |          | 6 |       |
|          | 7 |       |          | 7 |       |
|          | 8 |       |          | 8 |       |
|          | 9 |       |          | 9 |       |
|          | 0 |       |          | 0 |       |
|          | 1 |       |          | 1 |       |
|          | 2 |       |          | 2 |       |
|          | 3 |       |          | 3 |       |
|          | 4 |       |          | 4 |       |
|          | 5 |       |          | 5 |       |
|          | 6 |       |          | 6 |       |
|          | 7 |       |          | 7 |       |
|          | 8 |       |          | 8 |       |
|          | 9 |       |          | 9 |       |
|          | 0 |       |          | 0 |       |
|          | 1 |       |          | 1 |       |
|          | 2 |       |          | 2 |       |
|          | 3 |       |          | 3 |       |
|          | 4 |       |          | 4 |       |
|          | 5 |       |          | 5 |       |
|          | 6 |       |          | 6 |       |
|          | 7 |       |          | 7 |       |
|          | 8 |       |          | 8 |       |
|          | 9 |       |          | 9 |       |
|          | 0 |       |          | 0 |       |
|          | 1 |       |          | 1 |       |
|          | 2 |       |          | 2 |       |
|          | 3 |       |          | 3 |       |
|          | 4 |       |          | 4 |       |
|          | 5 |       |          | 5 |       |
|          | 6 |       |          | 6 |       |
|          | 7 |       |          | 7 |       |
|          | 8 |       |          | 8 |       |
|          | 9 |       |          | 9 |       |


## LOAD FUNCTIONS

Load  $V_i$  directly with numerical value $V1 = 9316$ Load  $V_i$  with content of a variable (copy) $V1 = V2$  or  $V1 = V2 + V15$  $V1 = V2 - 4$ Load  $V_i$  with content of an NC address $V1 = X$ 

## Definition

The variables to the left of the equal sign are loaded from the sources written on the right.

## Programming



Several of these functions can be written into the same line.

## Example

N1    $V12 = 1.6$   $V3 = V5$   $V4 = Z$ 

## Execution

When N1 is carried out the programmed variables are loaded one after the other.

The sequence in which the variables are written determines the order of execution.

NC address values which can be loaded:

| address | loaded value corresponds to:                                                                                                                                                                                                                                                     |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| X Y Z E | absolute positions in the active type of dimension                                                                                                                                                                                                                               |
| A D R   | in the machine coordinates or relating to the                                                                                                                                                                                                                                    |
| I J K   | zero point set with G92                                                                                                                                                                                                                                                          |
| T       | T is loaded with 4-digits                                                                                                                                                                                                                                                        |
|         | <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"> <math>T_{cc \ oo}</math><br/> <div style="border-left: 1px solid black; height: 20px; margin-left: 5px;"></div> </div> <div> last output tool<br/> last effective compensation </div> </div> |
| F       | feedrate in the active type of dimension<br>as defined by G94 / 95 / 96                                                                                                                                                                                                          |
| S       | spindle speed or cutting speed<br>as defined by G96 / 97                                                                                                                                                                                                                         |

## TRIGONOMETRIC FUNCTIONS

**Sine**  $VN = \sin V1$

**Cosine**  $VN = \cos V1$

**Arc tangent**  $VN = \text{ATG } V1$

**Definitions** The sine or cosine value of an angle (in degrees) is formed (SIN/COS).

The corresponding angle (in degrees) is formed from the tangent (ATG).

**Programming**  $VN = \sin V1 \quad V0 = \cos V2 \quad VP = \text{ATG } V3$

**Example**  $N1 \quad V10 = 30 \quad VX = \cos V10 \quad VY = \sin V10$

.  
. .  
. .  
. .

**Operation** The sine or cosine of any angle can be formed.  
Angle values are to be entered via variables.  
The direct input of numerical values is not permitted.

## TOOLS

## LOAD TOOL STORE

COR = V1 R = V2 L = V3 \*\*)

**Definitions** The tool store is loaded.

**Programming** N1 VN = 15  
 N2 COR = VN R = VP DR = VR L = VQ S = VS  
 VN from 1 to max. 48.

After the execution of N2 tool 15 will be loaded with the data from VP to VS.

## COPY TOOL DATA

COR = V1 V2 = RR V3 = L \*\*)

**Definition** Variables are copied from the tool store.

**Programming** COR = VN VP = R VR = DR VQ = L VS = S  
 VN from 1 to max. 48.

**Operation** Values are only copied, i.e. the tool data do not affect the machined path.

**Example** N1 V12 = 15 V13 = 15.0 V14 = 75  
 N2 COR = V12 R = V13 L = V14

After the execution tool 15 is loaded with  
 R = 15.0 L = 75.0

**Example** N1 V4 = 25  
 N2 COR = V4 V1 = R V2 = L V3 = DR \*)

After the execution of N2 the contents of the variables will be as follows:

V1 = radius V2 = length V3 = tool wear of tool 25.

**Note** \*) The input of the tool wear (DR) depends on the radius (R); limit: 10% of radius.  
 The DR value/ modification is entered as an incremental value.

\*\*) The COR instruction should be programmed in **a single line** together with the variables.

## ZERO SHIFTS

Load zero shift G54 to G59

TRF = V1 X = V2 Y = V3

Copy zero shift G54 to G59

TRF = G54 V1 = X V2 = Y

Copy active zero shift G92

TRF = G92 V1 = X V2 = Y

Copy active pole  
(polar coordinates)

TRF = G20 V1 = X V2 = Y

Copy active scaling factor  
switching G36

TRF = G36 V1 = X V2 = Z

## Definitions

The zero shift table is loaded or values are copied from the zero shift table.  
The values of the zero shifts and the values of the pole position are copied.  
The values of the active scaling factor are copied into V1 for the active plane, and into V2 for a possible change in scaling factor in the third axis.

## Programming

Load zero shift G54 to G59

N2 TRF = VN X = VP Y = VQ Z = VR E = VS

Copy zero shift G54 to G59

N2 TRF = G54 VP = X VQ = Y VR = Z VS = E

Copy pole (the coordinates relating to the active G20  
zero point of the active pole are copied)

N2 TRF = G20 V1 = X V2 = Y V3 = Z V4 = E

Copy zero shift G92 (current difference between commanded  
position and machine position)

N2 TRF = G92 V1 = X V2 = Y V3 = Z V4 = E

## Example

N1 V1 = 54 V2 = 100 V3 = 200 V4 = 150 V5 = 70

N2 TRF = V1 X = V2 Y = V3 Z = V4 E = V5

N3 M2

After the execution of N2 the zero shift corresponding to G54 is defined as follows:

X workpiece zero point at coordinate 100

Y workpiece zero point at coordinate 200

Z workpiece zero point at coordinate 150

E workpiece zero point at coordinate 70

## UNCONDITIONAL BRANCHING

|                      |               |        |
|----------------------|---------------|--------|
| Jump into subprogram | indirect jump | BSR V1 |
|                      | direct jump   | BSR P5 |
| Jump to label        | indirect jump | BRA V1 |
|                      | direct jump   | BRA P5 |

## Definitions

Depending on the results of calculations a freely selectable subprogram can be called up, or a jump can be performed. Both instructions can also be carried out without condition.

The jump target can therefore either be

P5: direct jump address label 5 (\$5)  
 or subprogram 5 (\$5)  
 V1: indirect jump address  
 label no. = content of V1 or  
 subprogram no. = content of V1

Programming  
a jump  
indirectly

N1 VN = M allocation of value to variable  
 N2 BSR VN call-up of subprogram no. M  
 (content of VN)

Programming  
a jump  
directly

N2 BSR P5 call-up of subprogram 5

Indirect jump  
to label

N2 BRA V1

Note on  
multiple  
branching

Several branching directions BSR can be programmed in one NC block. The first subprogram call-up the conditions for which are fulfilled will be carried out. Subsequently the next block number will be executed.



## CONDITIONAL BRANCHING

In addition to being dependent on signals program branching can be tied to the following conditions:

- mathematical comparisons
- modal effect of various G/M-functions
- whether or not mirror image is active

## SETTING CONDITION REGISTER

TST V1

The basis of all types of branching described in the following text is the status of the

CONDITION REGISTER (CR).

After mathematical operations or after "TST" the control will load the result into the internal condition register with the values of the variables.

**TST must be used before the branching, if the variable on which the branching is to depend is not yet in the CR.**


### Programming

#### N10 TST VN

Branching operations are only carried out correctly if the result from the preceding operation contains the conditions for the particular branching.

If, for instance, a multiplication is carried out in line 5 and no further instruction follows, which would set the condition registers, the result of this multiplication would still take effect in block 12 of the example on the next page.

General format for programming conditional jumps:



If the jump condition is not fulfilled, the subsequent block will be executed.

**CONDITIONAL BRANCHING / CONDITION REGISTER (CR)****Automatic  
Loading**

The condition register is loaded automatically by operations such as the basic arithmetic functions.

After the operation it will indicate what the result of the computation is compared to zero:

|    |                      |
|----|----------------------|
| EQ | = equal zero         |
| NE | = not equal zero     |
| GT | = greater than zero  |
| LT | = less than zero     |
| LE | = less/equal zero    |
| GE | = greater/equal zero |

**Loading via  
TST**

Not all operations load the condition register automatically.  
Example: A value is copied into V15 from the tool table.

If a branching is to depend on the value contained in V15 after the copying the condition register must be set with TST 15 before the decision is defined.

**Programming**

|                   |                                                                             |
|-------------------|-----------------------------------------------------------------------------|
| N12 BLE P27       | jump to label 27, if condition "BLE" is fulfilled; otherwise                |
| .                 | continue at block 13                                                        |
| .                 |                                                                             |
| N20 \$27          | jump target                                                                 |
| or                |                                                                             |
| N10 V12 = V11-V10 | calculation of required jump address                                        |
| N11 TST V15       | set condition register                                                      |
| N12 BLE V12       | jump to address 28 (content of V12) if condition regarding V15 is fulfilled |
| .                 |                                                                             |
| .                 |                                                                             |
| N31 \$28          | jump target                                                                 |

**CONDITIONAL BRANCHING AFTER MATHEMATICAL COMPARISON**

The jump address can be defined by one of two means:

- **indicated**, as content of a **variable V** or
- **directly**, by specifying a **label with P**.

Conditional branching does not automatically set the condition register.

**BEQ** Branch if EQual to zero

**BEQ V5**

**BEQ P1**

All digits before and after the decimal point must be 0

**BNE** Branch if Not Equal to zero

**BNE V5**

**BNE P1**

The jump condition is fulfilled if at least one digit before or after the decimal point is not equal to zero.

**BGT** Branch if Greater Than zero

**BGT V5**

**BGT P1**

The condition is fulfilled if the result is a positive number of at least one increment.

**BLT** Branch if Less Than zero

**BLT V5**

**BLT P1**

The condition is fulfilled if the result is a negative number of at least one increment.

**BGE** Branch if Greater than or Equal to zero

**BGE V5**

**BGE P1**

The condition is fulfilled if the result is = 0 or positive.

**BLE** Branch if Less than or Equal to zero

**BLE V5**

**BLE P1**

The condition is fulfilled if the result is = 0 or negative.

**Note:**

If several jump instructions are programmed in one block the user must check the corresponding jump addresses.



**Example**


Variables for a fixed machining cycle are loaded into the NC by the PLC via the STV function.


N15 V70 = 50 V75 = 115      loading current variables via  
 .      MDI directly into the variable  
 .      table or in program by means  
 .      of load instruction

N19 G0 X = V70 Z = V75      traversing movement

N20 F500 S250 M3      machining parameters

N21 G81 V1 = 35 V2 = 109      1st boring operation

N22 STV       NC to interface **A18 Data 0**  
 (part program stops)

 interface to NC: data transfer  
 Axx Dxx V70  
 Axx Dxx V75  
 Axx Dxx V76

**A18 Data 1** - end of data  
 transfer; program continues

N23 X = V70 Z = V75      next boring position defined  
 .      by STV; 2nd boring operation  
 .

**Output**

BCD output bus: **A18 Data 0**

**Input**

BCD input bus: **A18 Data 1**

**Note**


The function is applicable to the complete variable table (V1 to V99 and VA to VZ).

## CPC SAMPLE PROGRAMS: 1. Ellipse

**Task** Path calculation for an ellipse (centre of ellipse = coordinates 0/0).  
The ratio between the two radii is to be 0.4. The program is stored as cycle 65. It is called up with G865. The ratio should be definable by one single variable.

|                 |      |                                              |      |
|-----------------|------|----------------------------------------------|------|
| Sequence        | N1   | jump address (label 1)                       |      |
|                 | N2,3 | calculation of X-coordinate                  |      |
|                 | N4-6 | calculation of Y-coordinate                  |      |
|                 | N7   | positioning to X/Y coordinates               |      |
|                 | N8,9 | feed-in in Z (1st positioning only)          |      |
|                 | N10  | increment angle until final value is reached |      |
| Used Parameters | V1   | starting angle alpha                         | 0    |
|                 | V2   | incrementing angle in alpha                  | 2    |
|                 | V3   | radius b                                     | 10   |
|                 | V4   | value for condition                          |      |
|                 | V5   | radius a (larger radius)                     | 25   |
|                 | V8   | final angle                                  | 360  |
|                 | V6   | cosine --> X-component                       |      |
|                 | V7   | sine --> Y-component                         |      |
|                 | V10  | milling depth in Z                           | -0.5 |

**Advantages** The resulting program is considerably shorter than a conventional program, which would describe an ellipse as a contour made up of at least 10 arcs. It is also fully flexible with regard to the used radii and the ratio between them (b/a).

**Programming****Cycle 65**

```

N1 $1
N2 V6 = COS V1
N3 V6 = V6 * V5
N4 V7 = SIN V1
N5 V7 = V7 * V5
N6 V7 = V7 * V3
N7 X = V6 Y = V7
N8 G1
N9 Z = V10
N10 V1 = V1 + V2
N11 V4 = V8 - V1
N12 BGE P1
N13 G0
N14 M2

```

**Call-up and Example**

```

N1 G0 Z20
N2 G865 V1=1 V2= 8 V3= 10 V5= 30 V8= 359 V10= 12
N3 Z20
N4 M30

```

**Note:** Careful selection of the V2 value (incremental angle) makes it possible to achieve an optimum combination of accuracy and speed. Angle values relate to the circle with radius a. The corresponding Y-coordinate is modified by radius b (V3)!  
The program will work in a counter-clockwise direction.

## PARAMETRIC FUNCTIONS


BOSCH CC 100 M

User Handbook

## CPC SAMPLE PROGRAMS:

## 2. Row of Holes

## Definition of the variables



$$X = V90$$


$$Y = V91$$

$$\Delta X = V92$$

$$\Delta Y = V93$$

$$\text{number of holes} = V94$$

## Sequence

Program construction  
(solution)

N1 V40 = V90

N2 V41 = V91

N3 V44 = V94

N4 BEQ P1

N5 F500 S250 M3

N6 G81 V1=20 V2=0

N7 \$2

N8 G0

N9 X = V40 Y = V41

N10 DEC V44

N11 BEQ P1

N12 V40 = V40 + V92

N13 V41 = V41 + V93

N14 BRA P2

N15 \$1

N16 G80

N17 M2


## CPC SAMPLE PROGRAMS:

## 3. Bolt Hole Circle

The following requirements need to be provided for:

- variable X/Y position
- variable number of holes
- variable angle related hole distribution

## Definition of the Variables



V33 calculated angle value

V35 calculated number of holes

V80 sine value for Y

V81 cosine value for X

V82 bolt hole circle radius

V83 Y-position

V84 X-position

V85 calculated increase in angle

V90 position of centre of circle in X

V91 position of centre of circle in Y

V92 bolt hole circle diameter

V93 starting angle

V94 incrementing angle

V95 number of holes

V96 hole distribution

V97 angle for hole distribution

1 = calculated angle

0 = defined angle (V94)




## PARAMETRIC FUNCTIONS

## BOSCH CC 100 M

## User Handbook

## Sequence



## Program Construction

(solution)

N1 F750

N2 V85 = V94

N3 TST V96

N4 BEQ P3

N5 V85 = V97/V95

N6 \$3

N7 V33 = V93

N8 V35 = V95

N9 BEQ P1

N10 V82 = V92/2

N11 \$2

N12 V80 = SIN V33 V81 = COS V33

N13 V83 = V82 x V80 V84 = V82 x V81

N14 V84 = V84 + V90 V83 = V83 + V91

N15 X = V84 Y = V83

N16 V35 = V35-1

N17 BEQ P1

N18 V33 = V33 + V85

N19 BRA P2


N20 \$1

N21 G80


N22 M2

## 5. TECHNOLOGY


**OUTSIDE CORNERS**

 angular variation  $\alpha$   
 between 0 and 90°



execution with G68




execution with G69



 angle  $\alpha$  larger than 90°  
 and smaller than 180°

programmed contour




identical execution with G68/69



steps

 tool radius larger than  
 contour radius


execution with G68



execution with G69




**Example 1 Direct entry into and exit from contour**

Tool radius compensation is used (G17 active).

The contour entry and exit movements overlap.

Contents of tool table for T03 : R = 3.25 DR = 0.06 L = 175.0 S = 1.75


**Program**

```

N1 G0 X0 Y0 Z0
N2 G1 X65 Y35 F200
N3 G41 Y55 T03
N4 X35
N5 G3 Y15 R20.0
N6 G1 X90
N7 G3 Y55 R20.0
N8 G1 X60
N9 G40 Y35
N10 M2

```

— programmed path  
 - - - corrected path  
 contour

**Example 2 Tangential entry into and exit from contour**


Tool compensations for length and radius (G17 active).

The max. possible tool diameter corresponds to the width of the keyway - 1 inc.

The compensations are phased in and out above the workpiece, which makes this procedure suitable for very limited spaces.

When activating or cancelling a compensation only the axis(es) involved in the radius compensation should be moved.

In the program below the tool table contains the following  
 for T10 : R = 8.0 DR = 0 L = 0 S = 0


**Program**

```

N1 G0 Z5 M3 T10
N2 G42 X70 Y10
N3 G1 Y30 F200
N4 Z-2 F50
N5 G2 X90 Y50 R-20 F250
N6 G2 X90 Y10 I90 J30
N7 G1 X30
N8 G2 X30 Y50 I30 J30
N9 G1 X90
N10 G5 X90 Y11
N11 G1 Z5 F2000 M5
N12 Y50
N13 G40 X81 Y60
N14 Z100
N15 M30

```


To cancel the compensation (G40) a movement is required from 7 to 8 in Y positive, or in Y and X positive direction.

Recommended exit via end point such as E, E', E" etc.; exit via end point such as N not recommended. Contour might be disturbed.

**SUPPRESSION  
OF CONTOUR  
ELEMENTS**


Not all programmed contour elements can be machined because of the radius of the used tool.

Programmed contour




Execution with G68

1. All contour elements are machined.




2. One element is suppressed, since tool radius is larger than contour element.


**Note:**

If more than one contour element can not be machined due to the geometrical data the control will interrupt the machining and output an error message.


**Cancelling  
Compensation  
on Inside  
Corners**

Programmed contour




Cancelling compensation with different end points

1. All programmed contour elements are machined correctly.



2. One contour element is damaged.



E = end point programmed in conjunction with G40 for the cancellation of the radius compensation

## END POINT, CANCELLING THE COMPENSATION

### End Point

The return from the contour to the tool change point is usually not made directly, but via an intermediary position (end point).

The choice of a suitable end point helps to avoid damage to the contour, and the tool length compensation can be phased out between the end point and tool change point.

The end point should, if possible, allow a tangential exit from the contour with active radius compensation. It should be positioned so that there will be no free-cutting due to a change in direction when driving away from the contour.

### End of Contour

The last section of the contour should be linear. Otherwise a short linear positioning movement (of at least 3 increments) must be inserted past the end of the contour.

### Cancelling the Compensation

The cancellation must be made while in a linear mode (G0, G1, G61). In cases where the tool radius is relatively large in comparison to the contour radius the block following immediately after the cancellation (G40) must also describe a linear movement.

With regard to the choice of the end points the same applies as for the choice of the starting point, in principle (see contour entry). The optimum exit movement is the direct extension of the last contour section (in analogy to starting point 1). Starting and end point are different in this case. A joint starting and end point (such as S2) is also possible.

Referencing is not possible until tool radius compensation has been cancelled

### Cancelling Compensation for Inside

Even when working within a restricted space the radius compensation must be cancelled in conjunction with a positioning movement, which must at least equal the tool radius.

### Contours

To keep the required space to a minimum one of two methods should be used:

- continue in the direct extension of the last movement, or
- move to a position which lies on the same side on which the radius compensation was active, i.e. the right side with G42.

The recommended programming sequence is as follows (G17/G41 active):

- last contour machining (for instance with G2)
- tangential exit from the contour in G1 (program X/Y only)
- retract Z-axis with G1 (program Z on its own)
- G40 with X/Y movement as an extension of the last movement (program only X/Y)
- T00 with Z-movement (program Z on its own)
- program end

**SPECIAL CASES - TOOL COMPENSATION****CHANGE OF COMPENSATION**

There should preferably be no compensation values active when selecting a new tool.

Any active compensation can only be changed for a new block within the contour description. The interpolation mode in the block in which the change is programmed and in the following block must be linear.

**The new compensation value will not be activated until a positioning instruction is carried out in the axis(es) which the compensation applies to.**

Example: G41 X5 Y7 T02 (XY plane)


The new compensation value is phased in gradually to become fully effective at the end of the first block in which the relevant axes carry out a movement.

**SWITCHING BETWEEN G41 and G42**

Switching from G41 to G42 and vice versa should preferably take place without radius compensation being active.


If radius compensation is active switching between G41 and G42 is only possible during linear interpolation.

The control will generate an adjusting movement which must be taken into account during the programming!



For instance: Section P0 --> P1 can be extended to P1', and similarly P2 --> P3 can be started at P2', in order to achieve a smooth change-over movement.

In some cases it might be necessary to cancel compensations via G40, program intermediary positions, and make a new compensation call-up with G41/G42. The minimum length of path sections with which a compensation can be called up or cancelled is 3 increments.

**ENTRY INTO CONTOUR FROM DIFFERENT STARTING POINTS**

**S1 - S4**

The compensation value is phased in from the starting point to P1 in a linear movement. The contour is fully machined at all points and there is no damage to the contour.

**S1**

Cleanest contour entry through tangential approach movement.

**S2**

Good contour entry; starting point can also be used as end point.


**S3**

Lowest possible starting point without collision, considering contour section ④ - - > ①.

**S4**

Free-cutting at ① due to a change in direction!

Example with S2 as starting and end point incl. tool compensation






|     |      |      |     |         |
|-----|------|------|-----|---------|
| N1  | G0   | Z-10 | T01 |         |
| N2  | G1   | X-20 | Y20 | F200    |
| N3  | G41  | X0   | Y0  | S500 M3 |
| N4  | X20  |      |     |         |
| N5  | G2   | Y-20 | R10 |         |
| N6  | G1   | X10  |     |         |
| N7  | X0   | Y0   |     |         |
| N8  | G40  | X-20 | Y20 |         |
| N9  | Z300 | T00  |     |         |
| N10 | M2   |      |     |         |



**CONTOUR TRANSITIONS WITH G68 (AUXILIARY ARC)**

The following examples show how the tool compensation works on corners, by the generation of auxiliary arcs (outside corners) and the calculation of the angle bisector (inside corners).


**Transitions between linear path sections**

**Transitions between circular path sections**

**Discontinuous transitions**


t = tangential  
u = discontinuous


.... arc generated automatically by the control

**CONTOUR TRANSITIONS WITH G69 (INTERSECTION)**



Programming  
angular variation 0 to 90°





Execution



angular variation 0 to 90°



angular variation 90 to 180°




... movement generated automatically by the control

**EXAMPLES**

**G41 on outside contour** Contour programming with tool radius compensation to the left of the workpiece and phasing out of the compensation at the end of the machining.


The tool radius compensation value was stored in the technology table as the R-value.  
(in this example for T1 : R = 2.5 DR = 0.05 L = 250.0 S = 25.0)



|     |      |              |
|-----|------|--------------|
| N1  | G0   | X125 Y90     |
| N2  | G1   | F200         |
| N3  | G41  | X125 Y60 T01 |
| N4  | Y50  |              |
| N5  | X105 | Y40          |
| N6  | X90  |              |
| N7  | G5   | X75 Y25      |
| N8  | G1   | Y20          |
| N9  | X25  |              |
| N10 | Y60  |              |
| N11 | X45  | Y80          |
| N12 | X70  |              |
| N13 | G3   | X100 R15     |
| N14 | G1   | X125 Y60     |
| N15 | Y50  |              |
| N16 | G40  | Y20          |
| N17 | M2   |              |

**G42 on inside contour** Contour programming with cutter path compensation to the right of the workpiece and phasing out of the compensation at the end of the machining.  
(in this example for T3 : R = 3.25 DR = 0.06 L = 175.0 S = 17.5)

The tool radius compensation value was stored in the technology table as the R-value.



|     |      |          |
|-----|------|----------|
| N1  | G0   | X95 Y50  |
| N2  | G42  | T03 F300 |
| N3  | G1   | X115 Y50 |
| N4  | G5   | X130 Y35 |
| N5  | G1   | Y20      |
| N6  | X55  |          |
| N7  | Y30  |          |
| N8  | G1   | Y20      |
| N9  | G5   | X25 Y45  |
| N10 | G1   | Y70      |
| N11 | X40  |          |
| N12 | G3   | X70 R15  |
| N13 | G1   | X100 Y80 |
| N14 | X140 |          |
| N15 | Y60  |          |
| N16 | X115 |          |
| N17 | Y50  |          |
| N18 | G40  | Y35      |
| N19 | M2   |          |

**TOOL RADIUS COMPENSATION**
**G40 / 41 / 42**
**Definition**

The radius compensation converts the contour related part program into a cutter centre path (equidistant).  
 The equidistant runs parallel to the programmed contour at a distance which corresponds to the active cutter radius.  
 The side at which the equidistant runs with respect to the programmed path is determined with G41/G42.

**Treatment of  
Corners**

The control calculates

- intersections at inside corners and
  - auxiliary arcs at outside corners (G68) or also
  - intersections at outside corners (G69)
- Whether G68 or G69 is active on switch-on is determined by M-parameter.

**Feedrates F**

Feedrate values modal and, when relating to the machining of the part contour, apply

- to the **cutting point** (G64) or
- to the **cutter centre path** (G65)

**Cutting  
Speed**

The cutting speed can be determined indirectly by

- the determination of a fixed spindle speed for a given tool radius (G97 + S-word).

Alternatively, automatic and direct definition is possible via

- G96 with the S-word in the technology store.

**Cutter Radius**
**R positive**

R is stored in the tool table and represents the cutter radius relevant for the program execution.

**R = 0**

R can be set to 0 if, for instance due to extreme speed requirements, the part is programmed by describing the tool centre path.  
 The program is then executed without any path compensation.

**Tool Wear  
DR**

Additive, small compensation for the nominal tool radius, which, for instance, takes into account the regrinding of the tool.

If DR is programmed without sign this corresponds to an increase in the effective tool radius.

Detailed description of the functioning of the **TOOL COMPENSATION** in the relevant chapter.

## STARTING POINT, BEGINNING OF CONTOUR

### Starting Point

In many cases it is not possible to drive directly onto the contour from the tool change point; usually it is necessary to position to an intermediary position (starting point).

The choice of a suitable starting point helps to avoid damage to the contour. The compensations are phased in during the movement onto this point.

If possible the starting point should allow a tangential approach to the contour, but at least it should be positioned so that there will be no reversal of the direction of any axis at the first contour point (free-cutting).


### Beginning of Contour

A linear workpiece edge should be chosen, otherwise an intermediary linear movement (of at least 3 increments) must be made.

### Compensation Call-up

Compensation call-up must be made while in a linear mode (G0, G1, G61). The block following directly after a call-up (G40, G41, G42) should also be linear.

### Sample Contour without Compensation Call-up



Call-up of a compensation with positioning of the axis (es) in which the compensation is active:

Example: positioning in Z for call-up of T (XY plane)  
position in XY for G41, G42 (XY plane)

### Phasing in the Radius Compensation

When a radius compensation is called up the control phases in the relevant value in a linear traversing movement. The equidistant starts vertically above the beginning of the first path section for which the compensation is to apply.

**TOOL LENGTH COMPENSATION**
**ADDRESS T**

The tool length is taken into account when the T-word is called up.  
 The effect of T is restricted to the tool length compensation.  
 Tool length compensation can be used in all machining modes.

**General  
Format**

T XX XX

tool number, physical, for output  
 compensation group for internal computations

**Allocation**

Compensation group and output tool number can be freely combined in the call-up for T.

**Examples**

T can be programmed with 2 or 4 digits.

|         |                                                                         |
|---------|-------------------------------------------------------------------------|
| T 00    | tool length compensation and path compensation are cancelled; no output |
| T 12    | compensation group 12 is selected; no output of number                  |
| T .. 02 | tool number 2 is output; tool length compensation remains unchanged     |
| T 0812  | compensation group 8 is selected; tool number 12 is output              |
| T 1212  | compensation group 12 is selected; the same number is output            |

**Effect**

**The first two digits behind the T (Txx) always effect the tool compensation call-up.**

The 3rd and 4th digits specify the tool number and are output at the interface, if they are programmed. The tool length L, which is stored in the tool table, is incorporated according to the sign into the values for the axis, in which the tool length compensation applies.

The compensation value takes effect

- immediately for the axis display
- for the path once the relevant axis is programmed.

**Examples**
**T + Z programmed separately**
**T and Z programmed together**

|    |     |                                        |            |                                                    |
|----|-----|----------------------------------------|------------|----------------------------------------------------|
| N2 | T08 | corrected display for Z-axis           | N2 T08 Z50 | immediate phasing in of the compensation in Z-axis |
| N3 | Z50 | phasing in of tool length compensation |            | movement + corrected axis display                  |

**Note**

When a tool number is programmed with 4 digits the last two are displayed in automatic mode to show the active tool number.

**TOOL LENGTH COMPENSATION**
**ADDRESS T**
**Call-up**

The tool length compensation is phased in and out during a movement in a linear mode. The feed-in axis is to be programmed on its own.

**Allocation**

| Plane     | tool length is compensated for in |
|-----------|-----------------------------------|
| G17 (X/Y) | Z                                 |
| G18 (Z/X) | Y                                 |
| G19 (Y/Z) | X                                 |

There are basically two situations in which the tool length compensation is used:

**Programming without consideration of the tool length.**

In this instance the effective length of the tool needs to be stored in the tool table.

The compensation value corresponds to the distance between spindle nose and the tip of the tool.

**Example:**  
complete  
tool length


G1 Z-50 F100 T08  
Content of tool length 8 = 100  
The Z-axis will position to  $-50 + 100 = 50$

**Programming with reference to a zero tool**

When using this original tool, tool compensation value  $L = 0$  is applied. If a new tool is any shorter or longer, the difference  $L_{act} - L_{orig}$  is entered into the compensation store.

**Example:**  
difference  
in tool  
lengths

G1 Z50 F100 T08  
Tool length taken into account by the program: = 100 mm.  
Actual length of tool 8 = 90 mm.  
Tool length compensation in Z-axis.  
Plane G17 (X/Y).  
Z will position to 40.



## PROGRAMMING

### INTERNAL PROCESSING OF TOOL TECHNOLOGY DATA

When the relevant machining functions are called up the control automatically provides tool compensation according to the tool data in the technology store:

**Tool Geometry**    G40 to G42 tool radius  
                               T                    tool length

The compensations for tool length and tool radius and their cancellation are programmed with separate instructions. Once called up the compensations remain active as modal functions. The relevant compensation group must be defined.

Tool radius compensation can be further defined by

G68/69    behaviour at outside corners.

All compensation data can be input via the keyboard after selection of TOOLS by soft key.

Parametric functions can be used to make allocations to tool compensation table data, and compensation data can be copied and applied.

**Feedrate**            The programmed feedrate (F-word) is interpreted in different ways:

G94/95        feedrate in mm per minute or per revolution  
 G96/97        cutting speed / spindle speed

The feedrate applies as follows:

with G64        along the programmed contour (cutting point path)  
 with G65        along the tool centre path

**Cutting Speed**    With G97        the control forms the spindle speed directly from the active S-word.  
                               The programmer determines the cutting speed by programming the appropriate spindle speed.  
                               With G96 the control calculates and outputs the required spindle speed depending on the S-address (cutting speed), as defined in the technology store, and the used tool radius


**Gear Ranges**        M41-44        direct selection in the program  
                               M40            selection made automatically by the control at the beginning of the block



## TOOL COMPENSATION

**Definition** The control can convert a part-related program into a tool path.

When a tool compensation is programmed the control will automatically take into account the following tool-related characteristics, which are stored in the technology store:



|              |    |                               |         |
|--------------|----|-------------------------------|---------|
| <b>Tools</b> | L  | length                        | mm      |
|              | R  | radius                        | mm      |
|              | DR | radius wear                   | mm      |
|              | S  | cutting speed                 | m/sec   |
|              |    | number of compensation groups | max. 48 |

**Without Tool Compensation** The control can carry out a program without any modification if the machine and the required machining do not require any adjustment. The block processing time is short. Geometry, spindle speed, output signals, and feedrate take effect as programmed.

**External Tool Compensation** This also applies to programs through which the cutter centre path is described by external calculations.

Any demands regarding values, which are to be determined indirectly, such as constant cutting speed, usage of the optimum spindle speed, must be realized through specific values for M and S for the particular program run.

See also chapter 1 INTERFACES for the transmission conditions.

**Compensation Call-up** The tool length compensation is called up via T.  
The radius compensation is called up with G41/42.

**Cancelling the Tool Compensation** Both tool length and radius compensation are cancelled with T00.  
G40 cancels the radius compensation alone.

## 6. APPENDIX

# APPENDIX PROGRAMMING KEY

# BOSCH CC 100 M User Handbook

## PROGRAMMING KEY

| G-CODES | Code       | Functions                                                           | Group |
|---------|------------|---------------------------------------------------------------------|-------|
|         | 0          | XYZE Positioning in rapid, with                                     | a     |
|         | 1          | XYZE Linear interpolation at programmed feedrate                    | a     |
|         | 2          | xxR Circular interpolation, clockwise, 2 axes                       | a     |
|         | 3          | xxR Circular interpolation, counter-clockwise, 2 axes               | a     |
|         | 4          | F Dwell in seconds                                                  |       |
|         | 5          | xxx Circular interpolation with tangential entry, 2 axes            | a     |
|         | 6          | XYZE Linear interpolation in rapid with extended IN POS range       | a     |
|         | 17         | Plane selection X/Y                                                 | b     |
|         | 18         | Plane selection Z/X                                                 | b     |
|         | 19         | Plane selection Y/Z                                                 | b     |
|         | 20         | XY Setting pole for polar coordinates                               |       |
|         | 21         | P Subprogram call-up depending on I/F signal                        |       |
|         | 22         | PL Subprogram call-up, unconditional                                |       |
|         | 23         | PL Jump to program label depending on I/F signal                    | c     |
|         | 24         | P Jump to program label, unconditional                              | c     |
|         | 25         | XYZE Field limitation, setting minimum values                       | d     |
|         | 26         | XYZE Field limitation, setting maximum values                       | d     |
|         | 27         | XYZE Cancelling field limitation                                    | d     |
|         | 36         | - Scale factor switching                                            | e     |
|         | 38         | xx Switch on programmable mirroring                                 | e     |
|         | 39         | xx Switch off programmable mirroring                                | e     |
|         | 40         | Cancelling tool radius compensation                                 | c     |
|         | 41         | xx Tool radius compensation to the left of the path                 | c     |
|         | 42         | xx Tool radius compensation to the right of the path                | c     |
|         | 53         | Cancel zero shift                                                   | f     |
|         | 54 to 59   | XYZE Switch on zero shift                                           | f     |
|         | 61         | XYZE 'In Position' function on                                      | g     |
|         | 62         | XYZE 'In Position' function off                                     | g     |
|         | 63         | Feedrate and spindle speed set to 100%                              | h     |
|         | 64         | Feedrate applies to contour on circular contours                    | i     |
|         | 65         | Feedrate applies for tool centre path                               | i     |
|         | 66         | Feedrate/spindle speed can be modified via pot.                     | h     |
|         | 68         | Auxiliary arc on outside corners                                    | j     |
|         | 69         | Intersection on outside corners                                     | j     |
|         | 74         | Referencing                                                         |       |
|         | 75         | Measuring probe                                                     |       |
|         | 80         | Cancel fixed cycles G81 to G89                                      | k     |
|         | 81         | V Drilling, centering                                               | k     |
|         | 82         | V Boring with dwell                                                 | k     |
|         | 83         | V Deep hole drilling with positioning movements in rapid            | k     |
|         | 84         | V Tapping with dwell                                                | k     |
|         | 85         | V Boring with dwell/oriented spindle stop                           | k     |
|         | 86         | V Reaming                                                           | k     |
|         | 87         | V Thread milling                                                    | k     |
|         | 90         | XYZE Input in absolute dimensions                                   | l     |
|         | 91         | XYZE Input in incremental dimensions                                | l     |
|         | 92         | XYZE Setting position stores                                        | c     |
|         | S          | Setting top limit for spindle speed                                 | d     |
|         | 93         | S Time programming                                                  |       |
|         | 94         | F Feedrate direct in mm/min                                         | m     |
|         | 95         | F Feedrate in mm/rev                                                | m     |
|         | 96         | S Automatic calculation of cutting speed                            | n     |
|         | 97         | S Direct spindle speed programming                                  | n     |
|         | 99         | Subprogram end                                                      |       |
|         | 800 to 899 | Customer cycles: call-up via G-functions with corresponding numbers |       |

Group identifications a to n: Functions of the same group exclude one another.

### Machine specific G-codes (cycles)

6 - 2

# APPENDIX

## PROGRAMMING KEY

**BOSCH CC 100 M**  
User Handbook

| M-CODES   | system specific functions                                                 |
|-----------|---------------------------------------------------------------------------|
| Code      | Internal effect                                                           |
| M0        | program stop after execution of the block                                 |
| M2        | main program end, cycle end                                               |
| M3 / M13  | main spindle on CW / coolant on                                           |
| M4 / M14  | main spindle on CCW / coolant on                                          |
| M5        | main spindle stop / coolant off                                           |
| M6        | call-up of the automatic<br>tool change cycle (cycle 77)                  |
| M19       | orientation of main spindle to fixed position                             |
| M19(S. .) | orientation of main spindle to programmable<br>position (degrees)         |
| M21       | call-up of MTB cycle 76                                                   |
| M22       | call-up of MTB cycle 75                                                   |
| M30       | program end with return to beginning<br>(continuation with Cycle Start)   |
| M40       | automatic gear range selection                                            |
| M41-44    | selection of fixed gear range 1 to 4                                      |
| M98       | SINGLE BLOCK command is not accepted                                      |
| M99       | SINGLE BLOCK command is possible,<br>i.e. the effect of M 98 is cancelled |

## MACHINE SPECIFIC M-FUNCTIONS

| Code | Function |
|------|----------|
|------|----------|

# APPENDIX

## PROGRAMMING KEY

BOSCH CC 100 M

User Handbook

### Parametric Functions

| Instruction                                                   | Function                                              | CR set | Time |
|---------------------------------------------------------------|-------------------------------------------------------|--------|------|
| V1 = n                                                        | load a numerical value                                | X      |      |
| X = V <sub>n</sub> , m = V <sub>n</sub><br>m = XYZEIJKADGFRST | execution instruction                                 |        |      |
| V <sub>n</sub> = X, V <sub>n</sub> = p<br>p = XYZEIJKADFRST   | transfer active data                                  |        |      |
| V1 = V2 + V3 (V1 = V1 + 10)                                   | addition                                              | X      |      |
| V1 = V2 - V3 (V1 = V2 - 12)                                   | subtraction                                           | X      |      |
| V1 = V2 * V3 (V1 = V2 * 10)                                   | multiplication                                        | X      |      |
| V1 = V2/V3 (V1 = V2/2)                                        | division                                              | X      |      |
| V1 = V2                                                       | copy                                                  | X      |      |
| V1 = SQR V2                                                   | squate root                                           | X      |      |
| INC V1                                                        | increment value, delete<br>digits after decimal point | X      |      |
| DEC V1                                                        | decrement value, delete<br>digits after decimal point | X      |      |
| V1 = SIN V2 (degrees)                                         | sine ( $360^\circ \leq V2 \leq 360^\circ$ )           | X      |      |
| V1 = COS V2 (degrees)                                         | cosine ( $-360^\circ \leq V2 \leq 360^\circ$ )        | X      |      |
| V1 (degrees) = ATG V2                                         | arc tangent                                           | X      |      |
| BSR V1 (BSR P5)                                               | jump to subprogram<br>(label 5) with no. V1           |        |      |
| BRA V1 (BRA P5)                                               | jump to label no. V1 (label 5)                        |        |      |
| BEQ V1 (BEQ P5)                                               | jump to label no. V1,<br>(label 5) if CR = 0          |        |      |
| BNE V1 (BNE P5)                                               | jump to label no. V1,<br>(label 5) if CR = 0          |        |      |
| BGT V1 (BGT P5)                                               | jump to label no. V1,<br>(label 5) if CR > 0          |        |      |
| BLT V1 (BLT P5)                                               | jump to label no. V1,<br>(label 5) if CR < 0          |        |      |
| BGE V1 (BGE P5)                                               | jump to label no. V1,<br>(label 5) if CR ≥ 0          |        |      |
| BLE V1 (BLE P5)                                               | jump to label no. V1,<br>(label 5) if CR ≤ 0          |        |      |

Note: CR = condition register; time = execution time in ms

# APPENDIX

## PROGRAMMING KEY

# BOSCH CC 100 M

## User Handbook

| Instruction                                                                          | Function                                                               | CR set     | Time |
|--------------------------------------------------------------------------------------|------------------------------------------------------------------------|------------|------|
| COR = V1 R = V2 L = V3<br>DR = V4 S = V5 (COR = T1)                                  | load tool no. V1 with values                                           |            |      |
| COR = T10 V1 = R V2 = L . .<br>(COR = T10)                                           | copy values from tool no. 10                                           |            |      |
| TRF = V1 X = V2 Y = V3<br>Z = V4 E = V5 (TRF = G54)                                  | load zero shift no. V1 with values                                     |            |      |
| TRF = G54 V1 = X V2 = Y<br>V3 = Z V4 = E (TRF = G54)                                 | copy values from the G54 table                                         |            |      |
| TRF = G20 V1 = X V2 = Y . .                                                          | copy active pole                                                       |            |      |
| TST V1                                                                               | compare V1 with 0.<br>set CR accordingly                               | X          |      |
| TST G1, TST G <sub>n</sub><br>n=0-3,17-19,36,39,53-59,62,63,<br>65,66,90,93,94,95,97 | CR = 0 if G01 active<br><br>CR = 0 if G <sub>n</sub> active            | X<br><br>X |      |
| TST M41, TST M <sub>n</sub><br><br>n = 3, 4, 5, 13, 41 - 44                          | CR = 0 if M41 active<br><br>CR = 0 if M <sub>n</sub> active            | X<br><br>X |      |
| TST QX, TST Q <sub>n</sub><br><br>n = X,Y,Z,E                                        | CR = 0 if X-axis mirrored<br><br>CR = 0 if <sub>n</sub> -axis mirrored | X<br><br>X |      |
| TST QM                                                                               | CR = 0 if metric dimensions                                            | X          |      |
| TIM V1                                                                               | record time from<br>program start in seconds                           |            |      |
| POS X (Y, Z, E)                                                                      | axes traverse with<br>external command                                 |            |      |
| STV                                                                                  | updating variables                                                     |            |      |

# APPENDIX

## PROGRAMMING KEY

BOSCH CC 100 M

User Handbook

### Axis Information

Format: +/- 7 digits, for instance 1.234567 or 123456.7

|          |                                  |                   |
|----------|----------------------------------|-------------------|
| <b>X</b> | - X-axis                         | (mm/inch)         |
| <b>Y</b> | - Y-axis                         | (mm/inch)         |
| <b>Z</b> | - Z-axis                         | (mm/inch)         |
| <b>E</b> | - E-axis                         | (mm/inch/degrees) |
| <b>I</b> | - centre of circle (X-direction) | (mm/inch)         |
| <b>J</b> | - centre of circle (Y-direction) | (mm/inch)         |
| <b>K</b> | - centre of circle (Z-direction) | (mm/inch)         |
| <b>R</b> | - radius                         | (mm/inch)         |
| <b>D</b> | - vector length (polar coord.)   | (mm/inch)         |
| <b>A</b> | - angle (polar coord.)           | (degrees)         |

### M-functions Auxiliary Functions

|                              |                                                                                                      |
|------------------------------|------------------------------------------------------------------------------------------------------|
| <b>M</b> (0. .99)            | M-function (M0, 2,3,4,5,6,13,14,19,21,22,40, 41,42,43,44,98,99 have a predetermined internal effect) |
| <b>T</b> <u>xx</u> <u>xx</u> | (0. .99) tool number (output as location number)                                                     |
|                              | (0. .48) compensation group (activates tool length compensation)                                     |
| <b>F</b> (0.001 .. 120000)   | feedrate (mm/min) or (mm/rev)<br>time (sec)                                                          |
| <b>S</b> (0. .9999)          | spindle speed (rpm)                                                                                  |

### Subprograms and Jumps

|                      |                                             |
|----------------------|---------------------------------------------|
| <b>\$</b> (0. . .99) | jump address or beginning of subprogram     |
| <b>P</b> (0. . .99)  | SBP number / label number (used in call-up) |
| <b>L</b> (0. . .99)  | number of SBP repetitions (used in call-up) |

### Special Characters

|                                 |                    |
|---------------------------------|--------------------|
| (. . . . .)                     | texts and comments |
| <b>N</b> (1. . .9999)           | block number       |
| <b>V</b> (1. . .99 and A. . .Z) | CPC variables      |

### Control Characters

|                |                                                                             |
|----------------|-----------------------------------------------------------------------------|
| <b>STX</b> -   | Start of Text (beginning of a data block such as a part program)            |
| <b>ETX</b> -   | End of Text (end of a data block, such as a tool table)                     |
| <b>EOT</b> -   | End of Transmission (end of the transmission of one or several data blocks) |
| <b>CR LF</b> - | Record Separator (separates two records, such as 2 NC blocks).              |



# APPENDIX

## PROGRAMMING KEY

# BOSCH CC 100 M

## User Handbook

### ASCII - Set of Characters

| ASCII Character | Parity Bit | 7-Bit Code | ASCII Character | Parity Bit | 7-Bit Code | Meaning of the Character  |
|-----------------|------------|------------|-----------------|------------|------------|---------------------------|
| A               | 0          | 1000 001   | NUL             | 0          | 0000 000   | 0                         |
| B               | 0          | 1000 010   | SOH             | 1          | 0000 001   | start of header           |
| C               | 1          | 1000 011   | STX             | 1          | 0000 010   | start of text             |
| D               | 0          | 1000 100   | ETX             | 0          | 0000 011   | end of text               |
| E               | 1          | 1000 101   | EOT             | 1          | 0000 100   | end of transmission       |
| F               | 1          | 1000 110   | ENQ             | 0          | 0000 101   | enquiry                   |
| G               | 0          | 1000 111   | ACK             | 0          | 0000 110   | positive acknowledgement  |
| H               | 0          | 1001 000   | BEL             | 1          | 0000 111   | bell                      |
| I               | 1          | 1001 001   | BS              | 1          | 0001 000   | back space                |
| J               | 1          | 1001 010   | HT              | 0          | 0001 001   | horizontal tabulator      |
| K               | 0          | 1001 011   | LF              | 0          | 0001 010   | line feed                 |
| L               | 1          | 1001 100   | VT              | 1          | 0001 011   | vertical tabulator        |
| M               | 0          | 1001 101   | FF              | 0          | 0001 100   | form feed                 |
| N               | 0          | 1001 110   | CR              | 1          | 0001 101   | carriage return           |
| O               | 1          | 1001 111   | SO              | 1          | 0001 110   | shift out                 |
| P               | 0          | 1010 000   | SI              | 0          | 0001 111   | shift in                  |
| Q               | 1          | 1010 001   | DLE             | 1          | 0010 000   | data link escape          |
| R               | 1          | 1010 010   | DC1             | 0          | 0010 001   | DC on                     |
| S               | 0          | 1010 011   | DC2             | 0          | 0010 010   | control 2                 |
| T               | 1          | 1010 100   | DC3             | 1          | 0010 011   | DC off                    |
| U               | 0          | 1010 101   | DC4             | 0          | 0010 100   | control 4                 |
| V               | 0          | 1010 110   | NAK             | 1          | 0010 101   | negative acknowledge      |
| W               | 1          | 1010 111   | SYN             | 1          | 0010 110   | synchro                   |
| X               | 1          | 1011 000   | ETB             | 0          | 0010 111   | end of transmission block |
| Y               | 0          | 1011 001   | CAN             | 0          | 0011 000   | cancel                    |
| Z               | 0          | 1011 010   | EM              | 1          | 0011 001   | end of medium (paper)     |
|                 |            |            | SUB             | 1          | 0011 010   | substitute                |
| 0               | 0          | 0110 000   | ESC             | 0          | 0011 011   | escape (code switching)   |
| 1               | 1          | 0110 001   | FS              | 1          | 0011 100   | file separator            |
| 2               | 1          | 0110 010   | GS              | 0          | 0011 101   | group separator           |
| 3               | 0          | 0110 011   | BS              | 0          | 0011 110   | block separator           |
| 4               | 1          | 0110 100   | US              | 1          | 0011 111   | unit separator            |
| 5               | 0          | 0110 101   | SP              | 1          | 0100 000   | space                     |
| 6               | 0          | 0110 110   | !               | 0          | 0100 001   |                           |
| 7               | 1          | 0110 111   | "               | 0          | 0100 010   |                           |
| 8               | 1          | 0111 000   | #               | 1          | 0100 011   |                           |
| 9               | 0          | 0111 001   | \$              | 0          | 0100 100   |                           |
|                 |            |            | %               | 1          | 0100 101   |                           |
| a               | 1          | 1100 001   | &               | 1          | 0100 110   |                           |
| b               | 1          | 1100 010   | '               | 0          | 0100 111   |                           |
| c               | 0          | 1100 011   | (               | 0          | 1100 000   |                           |
| d               | 1          | 1100 100   | )               | 1          | 0101 000   |                           |
| e               | 0          | 1100 101   | *               | 1          | 0101 001   |                           |
| f               | 0          | 1100 110   | +               | 0          | 0101 010   |                           |
| g               | 1          | 1100 111   | ,               | 1          | 0101 011   |                           |
| h               | 1          | 1101 000   | -               | 0          | 0101 100   |                           |
| i               | 0          | 1101 001   | .               | 0          | 0101 101   |                           |
| j               | 0          | 1101 010   | /               | 1          | 0101 110   |                           |
| k               | 1          | 1101 011   | :               | 0          | 0101 111   |                           |
| l               | 0          | 1101 100   | ;               | 1          | 0111 010   |                           |
| m               | 1          | 1101 101   | <               | 0          | 0111 011   |                           |
| n               | 1          | 1101 110   | =               | 1          | 0111 100   |                           |
| o               | 0          | 1101 111   | >               | 1          | 0111 101   |                           |
| p               | 1          | 1110 000   | ?               | 0          | 0111 110   |                           |
| q               | 0          | 1110 001   | @               | 1          | 0111 111   |                           |
| r               | 0          | 1110 010   | [               | 1          | 1000 000   |                           |
| s               | 1          | 1110 011   | \               | 0          | 1011 011   |                           |
| t               | 0          | 1110 100   | ^               | 1          | 1011 100   |                           |
| u               | 1          | 1110 101   | _               | 0          | 1011 101   |                           |
| v               | 1          | 1110 110   | {               | 0          | 1011 110   |                           |
| w               | 0          | 1110 111   |                 | 1          | 1011 111   |                           |
| x               | 0          | 1111 000   | }               | 0          | 1111 011   |                           |
| y               | 1          | 1111 001   | ~               | 0          | 1111 100   |                           |
| z               | 1          | 1111 010   | DEL             | 1          | 1111 101   |                           |
|                 |            |            |                 |            | 1111 110   |                           |
|                 |            |            |                 |            | 1111 111   |                           |

### OUTPUT OF ERROR MESSAGES

**Definition**

The CC 100 M will transmit errors recognized internally to the interface controller. The error messages are output in coded form, one digit to indicate the error message group (0-2) and two further digits to indicate the error number (01 - 88).

**Example**

**0 3 9**      E axis must be programmed alone

└── error number 39 - Text: E axis must be programmed alone

└── error message group 0

**Soft key operation  
for error display**

1. **EDIT**      Incorrect program blocks are automatically displayed with error numbers and descriptions.
2. **MACHINE**      Incorrect entries in MDI are displayed automatically with error numbers and descriptions.
3. **AUTOMATIC**      Incorrect program blocks, which are not recognized until RUN operation, cause program stop and a general error signal. To obtain information about the type of error you need to switch into INFO mode; there the error number and the description will be displayed.

# APPENDIX

## OUTPUT OF ERROR MESSAGES

**BOSCH CC 100 M**  
User Handbook

### Error message group 0:

A14 D0

| Data | Meaning                                           |
|------|---------------------------------------------------|
| 1    | syntax error                                      |
| 2    | syntax error                                      |
| 3    |                                                   |
| 4    | system error H-Size overflow                      |
| 5    | system error N-H-Size overflow                    |
| 6    | system error L-H-Size overflow                    |
| 7    | system error R-Size overflow                      |
| 8    | system error D-Size overflow                      |
| 9    |                                                   |
| 10   | repetition (L) without subroutine call            |
| 11   | cutter comp. programmed without tool              |
| 12   | this G code must be alone in block                |
| 13   | this G/M code is not allowed with TEACH IN or MDI |
| 14   | max. 3 axes or A, D allowed                       |
| 15   | R or I, J, K not allowed                          |
| 16   | max. 2 axes out X, Y, Z allowed                   |
| 17   | TIM, COR, or TRF must be alone in block           |
| 18   | max. 4 axes with value allowed                    |
| 19   | max. 4 without value allowed                      |
| 20   | max. 2 axes out of X, Y, Z, E or A, D allowed     |
| 21   | enter Dwell time (F)                              |
| 22   | unadmissible G number                             |
| 23   | enter S without sign                              |
| 24   | value too large                                   |
| 25   | with D, F, or R, zero not allowed                 |
| 26   | repetition of address not allowed                 |
| 27   | max. 2 coordinates out of I, J, K allowed         |
| 28   | no radius programmed with polar coordinates       |
| 29   | max. 2 axes with polar coordinates (A, D)         |
| 30   | max. 3 axes R or I, J, K                          |
| 31   | enter jump target (P)                             |
| 32   | jump target (P) allowed with G21/22/23/24         |
| 33   | G code required with P or L                       |
| 34   | axis without value not allowed                    |
| 35   | only integer value                                |
| 36   | this M code must be alone in block                |
| 37   | test not allowed                                  |
| 38   | unadmissible tool number                          |
| 39   | E axis must be programmed alone                   |
| 40   | input range 1 to 127                              |
| 41   | with G 96, S value not allowed                    |
| 42   | with G 92, S value not allowed                    |
| 43   | max. 4 axes or A, D allowed                       |
| 44   | axis value not allowed                            |
| 45   | max. 2 digits with \$, P, L or M                  |

# APPENDIX

## OUTPUT OF ERROR MESSAGES

BOSCH CC 100 M

User Handbook

## Error message group 0:

A14 D0

| Data | Meaning                                             |
|------|-----------------------------------------------------|
| 46   | only 2 or 4 digits with T                           |
| 47   | too many digits                                     |
| 48   | max. 1 axis with value allowed                      |
| 49   | max. 4 digits with S                                |
| 50   | sign. not allowed                                   |
| 51   | input range 0.001 to 5                              |
| 52   | enter value                                         |
| 53   | Y(es) or N(o) required                              |
| 54   |                                                     |
| 55   | input range 0 to 999                                |
| 56   | input range 1 to 720                                |
| 57   | input range 0 to 4                                  |
| 58   | input range 0 to 20000                              |
| 59   | input range 0 to 50000                              |
| 60   | input range 0 to 90000                              |
| 61   | input range 1 to 1000                               |
| 62   | input range -9999 to 9999                           |
| 63   | input range 0 to 100                                |
| 64   | input range 0 to 3                                  |
| 65   | input range 0 to 359.999                            |
| 66   | input range 0 to 5                                  |
| 67   | input range 1 to 100                                |
| 68   | E not allowed                                       |
| 69   | F not allowed with G0                               |
| 70   | only X, Y, Z allowed                                |
| 71   | only P, L allowed                                   |
| 72   | only X, Y, Z, E allowed                             |
| 73   | only X, Y, Z, E or M, T allowed                     |
| 74   | only X, Y, Z, E or F, S, M allowed                  |
| 75   | only X, Y, Z, E or S allowed                        |
| 76   | input range -100 to 100                             |
| 77   | DR value = -10 % to +10 % of R (1 mm or 0.05 i max) |
| 78   | input range 1 to 50000                              |
| 79   | with TEACH IN or MDI P, L not allowed               |
| 80   | M 19 must be programmed alone or with S             |
| 81   | incorrect input of variables                        |
| 82   | incorrect variable number                           |
| 83   | input range 12 to 48                                |
| 84   | input range 256 to 32767                            |
| 85   | M 06 must be programmed alone or with tool number   |
| 86   | input range -10000 to 1 or to 10000                 |
| 87   | input range 0 to 9999                               |
| 88   | address modification must be alone in block         |
| 89   | message has to start with "("                       |

# APPENDIX

## OUTPUT OF ERROR MESSAGES

**BOSCH CC 100 M**  
User Handbook

### Error message group 1:

**A14 D1**

| Data | Meaning                                     |
|------|---------------------------------------------|
| 1    | no previous movement before G5              |
| 2    | full circle programming not allowed         |
| 3    | radius value null or missing                |
| 4    | negative root                               |
| 5    | G code not allowed in automatic mode        |
| 6    | bad polar radius programmed                 |
| 7    | G95 and M5 or S value = 0                   |
| 8    |                                             |
| 9    | G5 not allowed following G0                 |
| 10   |                                             |
| 11   | incorrect circle definition                 |
| 12   | centre coordinates incorrect                |
| 13   | programmed radius was rounded               |
| 14   | tool radius too large (1)                   |
| 15   | tool radius too large (2)                   |
| 16   | tool radius too large (3)                   |
| 17   | tool radius too large (5)                   |
| 18   | no intersection possible parallel lines     |
| 19   | no intersection possible line / circle      |
| 20   | no intersection possible circle / circle    |
| 21   | tool radius too large (4)                   |
| 22   | the circles are not tangent                 |
| 23   | M30 or M2 required                          |
| 24   | jump target not found                       |
| 25   | max. 10 subroutine levels                   |
| 26   | cycle does not exist                        |
| 27   | G99 and no subroutine active                |
| 28   | M2 or M30 seen with cutter comp. active     |
| 29   | G code not allowed with cutter comp. active |
| 30   | Highest spindle speed exceeded              |
| 31   | 1. gear range defined incorrectly           |
| 32   | M3 or M4 missing                            |
| 33   | gear range inadmissible                     |
| 34   | G99 with subroutine or M2 with cycle        |
| 35   | no feed programmed with G75/94/95/93        |
| 36   |                                             |
| 37   |                                             |
| 38   |                                             |
| 39   | input missing                               |
| 40   | rotary axis with circular interpolation     |
| 41   | incorrect position programmed with E axis   |
| 42   | cycle end is M2                             |
| 43   | subroutine end is G99                       |
| 44   | preset not allowed with active zero shift   |

The control will display the messages in clear text.

# APPENDIX

## OUTPUT OF ERROR MESSAGES

**BOSCH CC 100 M**  
User Handbook

### Error message group 1:

**A14 D1**

| Data | Meaning                                               |
|------|-------------------------------------------------------|
| 45   | cycle unadmissible with cutter comp.                  |
| 46   | unadmissible value for G code                         |
| 47   | G code unadmissible with mirror function              |
| 48   | G code unadmissible with cutter comp.                 |
| 49   |                                                       |
| 50   |                                                       |
| 51   |                                                       |
| 52   | one movement missing for cutter comp.                 |
| 53   |                                                       |
| 54   | block modified or not executed due to cutter comp.    |
| 55   | max. 2 axes out of X, Y, Z, E or A, D allowed         |
| 56   | V95 must be 0 or 1                                    |
| 57   | transfer not possible                                 |
| 58   | reentry not allowed with G84                          |
| 59   | probe not triggered                                   |
| 60   | unadmissible jump target                              |
| 61   | double definition of axis (polar)                     |
| 62   | max. 1 axis with G2/3/5 and polar programming         |
| 63   | max. 3 axes with G2/3/5                               |
| 64   | G0/1/5 and radius or I, J, K not allowed              |
| 65   | G2/3 with radius and I, J, K not allowed              |
| 66   | no new cutter comp. with G2/3/5                       |
| 67   | G21/23 with cutter comp. not allowed                  |
| 68   | cutter comp. not allowed without tool number          |
| 69   | G40/41/42 not allowed with G2/3/5                     |
| 70   | no G2/3/5 following a zero shift                      |
| 71   |                                                       |
| 72   | G96 not allowed with S value                          |
| 73   | spind. speed calcul. not possible, tool radius = 0    |
| 74   | G92 not allowed with G41/42/T                         |
| 75   | G code not allowed with cut. or length comp.          |
| 76   | new plane not allowed with cutter comp.               |
| 77   | V95 must equal 2 or 3                                 |
| 78   | division by zero                                      |
| 79   | coordinates do not comply with active plane           |
| 80   | no tool active                                        |
| 81   | unadmissible tool number                              |
| 82   | unadmissible G number                                 |
| 83   | V91 must equal 1 or 2                                 |
| 84   | this zero shift is already active                     |
| 85   | DR value = -10 % to + 10 % of R (1 mm or 0.05 i max.) |
| 86   | spindle orientation not possible                      |
| 87   | calculation not possible                              |
| 88   | angle range -180 to + 180 deg.                        |

The control will display the messages in clear text.

# APPENDIX

## OUTPUT OF ERROR MESSAGES

**BOSCH CC 100 M**  
User Handbook

### Error message group 2:

**A14 D2**

| Data | Meaning                                       |
|------|-----------------------------------------------|
| 1    | 99 programs exist                             |
| 2    | memory full                                   |
| 3    | memory too small for jump target table        |
| 4    | check sum error                               |
| 5    | undefined jump target                         |
| 6    | parity memory                                 |
| 7    | duplication of jump target                    |
| 8    | 69 CYCLES exist                               |
| 9    | memory too small to copy                      |
| 10   | file protected                                |
| 11   |                                               |
| 12   | unadmissible file                             |
| 13   | file already exists                           |
| 14   | device not ready                              |
| 15   | parity error                                  |
| 16   | incorrect data format                         |
| 17   | incorrect baud rate                           |
| 18   | timeout period expired                        |
| 19   | no corresponding file type                    |
| 20   | TEACH IN                                      |
| 21   | movement not allowed with E, 2 blocks created |
| 22   | memory error, switch off                      |
| 23   | reference cycle does not exist                |
| 24   | interruption, abort with clear block          |
| 25   | inch / metric selection incorrect             |
| 26   | no corresponding cycle                        |
| 27   | undefined key                                 |
| 28   | reference not allowed with length comp.       |
| 29   | movement not allowed, 2 blocks created        |
| 30   |                                               |
| 31   | warning sent by PLC                           |
| 32   | too many characters for one block             |
| 33   | bad value for tool table size                 |
| 34   | size of memory changed, memory cleared        |
| 35   | no machine reference, send axes to reference  |
| 36   |                                               |
| 37   |                                               |
| 38   |                                               |
| 39   | circle calculation not possible               |
| 40   | limit                                         |

**APPENDIX**  
**OUTPUT OF ERROR MESSAGES****BOSCH CC 100 M**  
User Handbook

| Data | Meaning                                            |
|------|----------------------------------------------------|
| 41   | emergency stop                                     |
| 42   | servo error                                        |
| 43   | measuring system: marker missing                   |
| 44   | measuring system: not connected                    |
| 45   | measuring system: pulse is lost                    |
| 46   | measuring system: no feedback                      |
| 47   | bad axes parameters                                |
| 48   | gearbox not OK                                     |
| 49   | interpolator stop error                            |
| 50   | axis error                                         |
| 51   | code:                                              |
| 52   | T (s)                                              |
| 53   | /mn                                                |
| 54   | /rev                                               |
| 55   | conflict between hardware and software, NC stopped |



## A

- Access levels 2 - 3
- Addition 4 - 7
- Addresses 3 - 14
- Arc tangent 4 - 9
- Arithmetic functions 4 - 7
- ASCII character set 6 - 10
- ASCII control characters 1 - 7 6 - 3
- Automatic 2 - 9

## B

- Battery 1 - 5
- BEQ / BGE / BGT / BLE / BLT / BNE 4 - 15
- Block number 3 - 3
- Block selection 2 - 4
- Boring 3 - 61
- Boring cycles 3 - 49
- BRA 4 - 12
- Branching conditional 4 - 13
- Branching unconditional 4 - 12
- BSR 4 - 12
- Buffer battery 1 - 5

## C

- Calculation cycles 3 - 76
- Calculation end point - straight line 3 - 85
- Calculation end point - arc 3 - 83
- Cancelling compensation 3 - 41 5 - 11
- Chamfering 3 - 81
- Change compensation 5 - 12
- Checksum 1 - 22
- Circular interpolation 3 - 22
- Commands 2 - 3
- Component parts 1 - 2
- Conditional jump 3 - 34 4 - 13
- Conditional subroutine call 3 - 31
- Condition register 4 - 13
- Contour cycles 3 - 76
- Contour transitions 3 - 46 5 - 8
- Control signals 1 - 6
- Control characters 6 - 3
- Copy tool data 4 - 10
- COR 4 - 10
- Corner rounding 3 - 81
- Cosine 4 - 9
- CPC programming 4 - 1
- CP/MEM 1 - 5
- Cursor function 2 - 4
- Cutter centre path 3 - 45
- Cutting path 3 - 45
- Cutting speed 5 - 1
- Cutting speed calculation 3 - 72
- Cycles 2 - 21 3 - 2
- Cycles, MTB fixed 3 - 87

## D

|                         |        |               |
|-------------------------|--------|---------------|
| ● Data interfaces       | 1 - 5  | 2 - 20        |
| ● Data interfaces V.24  | 1 - 6  |               |
| ● Data interfaces 20 mA | 1 - 6  |               |
| ● Data lines            | 1 - 9  |               |
| ● Decrement             | 4 - 8  |               |
| ● Deep hole drilling    | 3 - 51 |               |
| ● Delete                | 2 - 4  | 2 - 14 2 - 23 |
| ● DFS header            | 1 - 19 |               |
| ● Dimensional units     | 2 - 3  | 2 - 5 2 - 15  |
| ● Dimensioning          | 3 - 67 |               |
| ● Division              | 4 - 7  |               |
| ● Drilling              | 3 - 55 |               |
| ● Drip feeding          | 3 - 9  |               |
| ● Dwell time            | 3 - 27 |               |

## E

|                            |               |
|----------------------------|---------------|
| ● Edit                     | 2 - 3         |
| ● Editor                   | 2 - 4         |
| ● Effect of feedrate       | 3 - 45        |
| ● End point calculations   | 3 - 83 3 - 85 |
| ● Entry into contour       | 5 - 7         |
| ● Error messages - display | 2 - 2         |
| ● Error message listing    | 6 - 9         |
| ● Error messages - output  | 6 - 8         |
| ● External VDU monitor     | 1 - 5         |

## F

- F-address 3 - 14
- Feed, linear interpolation 3 - 21
- Feedrates 3 - 70 5 - 1
- Feedrate 100% 3 - 44
- Field limitation 3 - 36
- File header 6 - 3
- Fixed cycles 3 - 49, 3 - 75, 3 - 87
- Fixed MTB cycles 3 - 87
- Fixed machining cycles 3 - 49
- Forms 4 - 3

## G

- G-functions 3 - 20
- G-code, three digit 3 - 75
- Gear ranges 3 - 16

## H

- Header 1 - 16

**SUBJECT INDEX****BOSCH CC 100 M**  
User Handbook**I/J**

|                                |        |        |        |
|--------------------------------|--------|--------|--------|
| ● I-address                    | 3 - 22 |        |        |
| ● Increment                    | 4 - 8  |        |        |
| ● Information                  | 2 - 13 |        |        |
| ● Inch/metric switching        | 2 - 18 |        |        |
| ● In position logic            | 3 - 43 |        |        |
| ● Insert                       | 2 - 4  |        |        |
| ● Interface V.24               | 1 - 5  |        |        |
| ● Interface 20 mA              | 1 - 5  |        |        |
| ● Interpolation in feed        | 3 - 21 |        |        |
| ● Interpolation in rapid       | 3 - 20 |        |        |
| ● Intersection circle / circle | 3 - 78 |        |        |
| ● Intersection line / circle   | 3 - 79 |        |        |
| ● Intersection line / line     | 3 - 86 |        |        |
|                                |        |        |        |
| ● J-address                    | 3 - 22 |        |        |
| ● Joining                      | 3 - 80 |        |        |
| ● Jump after comparison        | 4 - 16 |        |        |
| ● Jump conditional             | 3 - 34 | 4 - 13 |        |
| ● Jump instructions            | 3 - 5  | 3 - 32 | 4 - 12 |
| ● Jump unconditional           | 3 - 35 | 4 - 12 |        |

**K**

|                      |        |
|----------------------|--------|
| ● K-address          | 3 - 24 |
| ● Keys, programmable | 3 - 87 |

## L

- L-address 3 - 32
- Linear interpolation in feed 3 - 21
- Linear interpolation in rapid 3 - 20
- Linear interpolation in rapid with  
extended in position range 3 - 28
- Load functions 4 - 6
- Load tool store 4 - 10

## M

- M-address 3 - 15
- Machine 2 - 5
- Machine status display 2 - 14
- Main modes 2 - 1
- Manual machine operation 2 - 5
- Manual panel 1 - 4
- Measuring probe input 3 - 48
- Memory 2 - 3
- Memory allocation 3 - 2
- Messages 6 - 9
- Minicass operation 1 - 15
- Mirroring 3 - 39
- Modify 2 - 4 2 - 6
- MTB cycles 3 - 87
- MTB service 2 - 13
- Multiplication 4 - 7

**SUBJECT INDEX****BOSCH CC 100 M**  
User Handbook**N / O**

- N-address 3 - 3
- Operating panel 1 - 3
- Operating panel connection 1 - 5
- Operating program 1 - 5
- Operator instruction programming 3 - 18
- Outside corners 5 - 15

**P / Q**

- P-address 3 - 31 4 - 12 4 - 15
- Panel 1 - 3
- Part programs 2 - 20 3 - 2
- Plane selection 3 - 28
- Polar coordinates 3 - 30
- Position stores 3 - 68
- Priority routine 3 - 87
- Program header in DFS format 1 - 19
- Programming code 6 - 1
- Programming key 6 - 1
- Program planning 4 - 2
- Program production 3 - 1
- Program transfer 2 - 20
- Programs 2 - 21 3 - 2

**SUBJECT INDEX****BOSCH CC 100 M**  
User Handbook**R**

- R-address 3 - 23
- Radius compensation 3 - 41 5 - 2 5 - 5
- Rapid, linear interpolation 3 - 20
- Reaming 3 - 63
- Reentry 2 - 10
- Reference axes 2 - 5 3 - 47
- Reference cycle 2 - 5 3 - 87
- Registering time 4 - 8
- Reset 2 - 13
- Reset conditions 2 - 2
- Rounding corners 3 - 79

**S**

- S-address 3 - 16
- Setting a pole 3 - 30
- Setting condition register 4 - 13
- Setting position stores 3 - 68
- Sine 4 - 9
- Spindle speed 3 - 72
- Spindle speed 100% 3 - 44
- Square root 4 - 7
- Start conditions 2 - 2
- Status display 2 - 13
- Subdivision of VDU display 2 - 2
- Subroutine call 3 - 5 3 - 33
- Subroutine call, conditional 3 - 32
- Subroutine end 3 - 74
- Subtraction 4 - 7
- Suppression of contour elements 5 - 14



**Numerische Steuerungen · Computer Numerical Control**  
**Speicherprogrammierbare Steuerungen · Programmable Logic Controllers**  
**Antriebstechnik · Drives**  
**Robotersteuerungen · Robot Controls**  
**Schweißsteuerungen · Welding Controls**  
**Automatisierungstechnik · Automation Technology**

## **Bosch Elektronische Steuerungen · Verkaufsorganisation Inland** **Bosch Electronic Controls · German Sales Organisation**

Robert Bosch GmbH · Geschäftsbereich Industrierausrüstung · Produktbereich Industrielle Steuerungselektronik  
 Berliner Straße 25 · Postfach 1162 · 64701 Erbach/Odw. · Telefon (06062) 78-0 · Telex 41916-60 rbd · Telefax (06062) 78-428

Robert Bosch GmbH  
 Abteilung IA/VHR  
 Postfach 11 01 52  
**30856 Laatzen**  
 Tel. (0511) 8606-263  
 Telex 921163  
 Telefax (0511) 8606-419

Robert Bosch GmbH  
 Abteilung IA/VKÖ  
 Postfach 1005 43  
**50445 Köln**  
 Tel. (0221) 4905-297  
 Telefax (0221) 4905-228

Robert Bosch GmbH  
 Abteilung IA/VSU  
 Postfach 3002 68  
**70442 Stuttgart**  
 Tel. (0711) 8934-615  
 Telefax (0711) 8934-632

Robert Bosch GmbH  
 Abteilung IA/VMU  
 Postfach 2003 62  
**80003 München**  
 Tel. (089) 5128-284  
 Telex 522151  
 Telefax (089) 5128-205

## **Bosch Elektronische Steuerungen · Verkaufsorganisation Ausland** **Bosch Electronic Controls · Foreign Sales Organisation**

Robert Bosch AG  
 Geiereckstraße 6  
**A-1110 Wien**  
 Tel. (43-1) 797 22-0  
 Telex (047) 131638  
 Telefax (43-1) 797 22 75 99

EMTS PTY Ltd.  
 Factory 1, 40 Strong Avenue  
**Thomastown Victoria 3074**  
 Australia  
 Tel. (61-3) 460 69 00  
 Telefax (61-3) 462 12 14

N.V. Robert Bosch S.A.  
 Henri Genessestr. 1  
**B-1070 Bruxelles**  
 Tel. (32-2) 525 52 86  
 Telex (046) 21582  
 Telefax (32-2) 525 52 56

WEG Automação Ltda  
 Rua Joinville, 3000  
**BR 89256-900 Jaraguá do Sul, SC**  
 Tel. (55) (473) 72-20 20  
 Telex 475-247  
 Telefax (55) (473) 72-40 20

Robert Bosch AG  
 Hohlstraße 188  
**CH-8021 Zürich**  
 Tel. (41-1) 247 62 11  
 Telex (045) 812255  
 Telefax (41-1) 247 64 21

Representaciones Técnicas  
 Ripoll  
 Apartado 163  
**E-Zarauz-Guipúzcoa**  
 Tel. (34-43) 831051  
 Telex (052) 38762  
 Telefax (34-43) 1335 94

Robert Bosch France  
 Département VCI  
 32, Av. Michelet  
 B.P. 170  
**F-93404 Saint-Ouen Cedex**  
 Tel. (33-1) 4010 72 34  
 Telex (042) 234132  
 Telefax (33-1) 4010 20 43

Robert Bosch Ltd.  
 Meridian South  
 Meridian Business Park  
**GB-Braunstone/Leicester**  
 Tel. (44-533) 89 27 23  
 Telex (051) 341 254  
 Telefax (44-533) 89 28 78

Novotech Company Ltd.  
 Novosibirskaja St. 2  
**GUS 450059 UFA**  
 Tel. (34 72) 32 74 55  
 Telex 162125 ptb su  
 Telefax (34 72) 33 16 77

Robert Bosch  
 Industriale Commerciale S.P.A.  
 Casella Postale 15049  
 Via M.A. Colonna, 35  
**I-20149 Milano**  
 Tel. (39-2) 369 61  
 Telex (043) 321506  
 Telefax (39-2) 369 64 42

Electronica  
 Elektra Chambers  
**44 Mukand Nagar**  
**IND Pune 411037**  
 Tel. 42 2013  
 Telex 145-7432 EDM IN  
 Telefax 91-212 443532

Robert Bosch B.V.  
 Industrietechniek  
 Postbus 8061  
**NL-1005 AB Amsterdam**  
 Tel. (31-20) 580 02 47  
 Telex (044) 12282  
 Telefax (31-20) 580 08 82

PIAP  
 Industrial Research Institute  
 for Automation and  
 Measurements  
 Al. Jenożolimskie 202  
**PL 02-222 Warsaw**  
 Tel. (48) (22) 238-366  
 Telex 813-726 PI  
 Telefax (48) (22) 238-864

Automationshuset  
 Robcona AB  
 Elektrodgatan 1  
**S-72137 Vaesteraas**  
 Tel. (46-21) 8108 80  
 Telex (054) 40442  
 Telefax (46-21) 8108 88

Flexible Electronic Systemes  
 (PTY.) Ltd.  
 P.O. Box 3881  
 Kempton Park 1620  
 27, Forge Road  
**SA-Republic of South Africa**  
 Tel. (27-11) 975 70 00  
 Telefax (27-11) 394 20 85

Robmatic OY  
 P.O. Box 59  
 Kamreerintie 6  
**SF-02771 Espoo**  
 Tel. (35-80) 8591 31  
 Telex (057) 125316  
 Telefax (35-80) 8591 05

Robert Bosch  
 (South East Asia)  
 PTE. Ltd  
 P.O. Box 4  
 (Thomson Road)  
**38c-38d Jalan Pemimpin**  
**SGP-2057 Singapore 20**  
 Tel. (65) 258 55 11  
 Telex (087) 24062  
 Telefax (65) 258 46 71

Robert Bosch Corp.  
 Canton Business Park  
 97 River Road  
**Collinsville, Ct. 06022-1231**  
 USA  
 Tel. (1-203) 693 63 21  
 Telex (023) 643830  
 Telefax (1-203) 693 17 39



# BOSCH

Flexible Automation

**CNC**

Steuerungen für Werkzeugmaschinen

**CNC**

controls for machine tools

**RC**

Robotersteuerungen

**RC**

robot controls

**SPS**

Speicherprogrammierbare Steuerungen

**PLC**

programmable logic controllers

**Antriebstechnik**

Bürstenlose Servo- und Hauptspindelantriebe

**Drives**

brushless servo and main spindle drives

**Schweißtechnik**

Steuerungen für Widerstandsschweißanlagen

**Welding**

controls for resistance welding

**Automatisierungstechnik**

DNC – BDE/MDE

**Automation Technology**

DNC – MDP/ODP

**Berliner Straße 25, Postfach 1162**

**D-64701 Erbach/Odenwald**

**Telefon 0 60 62/78-0, Telefax 0 60 62/78-428**