

Wadkin

DIMENSION SAW TYPE P.P. PRINCIPAL DIMENSIONS AND CAPACITIES :-

Standard size of saw	18"	450 mm.
Maximum depth of cut	5½"	140 mm.
Depth of cut with saw canted to 45°	3.7'8"	100 mm.
Throat opening between fixed and sliding tables	6"	150 mm.
Saw cants up to	45°	45°
Maximum distance between saw and ripping fence on standard table	30"	760 mm.
Will crosscut on standard table with saw at 90°	5½" x 29½"	140 x 750 mm.
	1" x 36"	25 x 915 mm.
Length cut off using stop on mitre fence	36"	915 mm.
Ripping fence cants up to	45°	45°
Horse power of motor.. .. .	5	5
Speed of saw spindle 50 and 60 cycles	2800 r.p.m.	2800 r.p.m.

Details included with the machine.

One pair saw collars and nut.
Motor and control gear.
Saw guard and riving knife.
Single mitre fence with stop bar and stop.

Canting Ripping fence.
Set of spanners.
Tin of lubricant.

FIG. 1.




FIG. 2.





FIG. 3.



REMOVAL OF SAW SPINDLE CARRIAGE




Isolate machine electrically. Remove guard and fence assemblies. Remove complete sliding table unit by removing locking handles marked "A" Fig. 1 and lifting table clear of tenon marked "B" Fig. 1 and brackets marked "C" Fig. 1. Remove tee slot filling in strips from main table and knock through two dowel pins from the top and remove four hexagon head screws from underside of body flange, lift table clear. Remove electrical leads to motor and brake cable from brake shoe. Remove four hexagon head screws marked "C" Fig. 3 from each arm carrying handwheel these can now be withdrawn from both gearboxes. Wedge saw spindle carriage in 90 degrees position using wood blocks, then remove canting gearbox pivot pin, gearbox complete with canting screw can now be withdrawn from canting nut see Fig. 3. Remove dust deflector and exhaust extension, canting pointer from lip plate and remove lip plates see Fig. 2. Spindle carriage can now be removed from its position in the main frame. Reassemble in the reverse order of the above.

Maintenance that can be carried out with saw spindle carriage removed.

Changing of motor.

Changing of spindle bearings, see special instructions. Page 6.

Adjustment to wear strip of vertical slide.



SECTION THROUGH BELT DRIVEN SPINDLE.

www.DaltonsWadkin.com




FIG. 5.

To remove the spindle without removing saw spindle carriage, cant saw to approx. 30° . Remove sliding table (see page 4). Remove vee ropes see Fig. 3. Remove spindle nut, saw & saw flanges. Remove ball bearing locknut marked "A". This has a right hand thread. Remove pulley, end cap marked "B", this has four countersunk head screws, and driving key. Remove end cap marked "C" this has capscrews. Spindle can now be knocked out from rear end using a piece of wood or soft metal (Brass, Copper, Lead).

With the spindle removed rear bearing can be lightly tapped out of its housing. To change front bearing, remove locknut marked "D" this has a right hand thread, and lightly tap off bearing.

To Reassemble.

Before assembly clean out all old lubricant, assemble in the reverse order of the previous mentioned procedure, ensuring that no dirt or grit enters the bearings or housings. Smear the bearings with Wadkin ball bearing grease, grade L. 6. When fitting ball bearings do not hammer the races into position but give gentle taps with a soft rod all round the periphery. The inner race should be a good push-fit on the spindle and the outer race a good sliding-fit.

BALL BEARING LIST

One SKF 6309 Saw spindle front bearing.
One SKF 1306 Saw spindle rear bearing.
Four SKF 08 Two each for rise and fall and canting motions.

Lubrication see Figs. 2 and 3.

The grease lubricant recommended is Wadkin Grade L. 6. Alternative grease,
Shell-Mex & B. P. Ltd. - Shell ALVANIA GREASE 3
Mobil Oil Co. - MOBILUX GREASE No. 2
Castrol - SPHEEROL S

For oil lubrication, use Wadkin Grade L. 4. Alternatively
Shell Mex & B. P. Ltd. - Shell VITREA OIL 33
Mobil Oil Co. - Mobil VACTRA OIL (heavy
medium)
Castrol - PERFECTO. NN.


THOROUGHLY CLEAN DOWN MACHINE WEEKLY.

FOOT OPERATED BRAKE ADJUSTMENT

www.DaltonsWadkin.com

Grubscrew marked "A" Fig. 6 is initially set to depress micro-switch when foot pedal is operated to its full extent. Failure of brake pedal to return will prevent machine being started, check spring for fatigue and replace if necessary.

To replace micro-switch, isolate machine, remove switch, disconnect electrical leads, connect new switch and replace switch on facing. Start machine and ensure that when brake pedal arm is depressed to its full extent the micro-switch is operated by the grubscrew marked "A".




FENCES, TABLE AND GUARDS.

To set canting ripping fence for cutting. Move fence to approximate position required. Operate first lock by rotating clockwise, fine adjust to obtain correct dimension required. Operate secondary lock, this also squares fence to dovetail groove. To unlock fence operate first lock in anti-clockwise direction until dead stop is reached, secondary lock need not be operated.

CANTING RIPPING FENCE LOCKING ADJUSTMENT

Should the fence secondary lock not operate the two hexagon head screws (on the right hand side of the fence base) should be slackened off and the three grubscrews rotated clockwise each by the same amount until the eccentric secondary lock holds the fence in the required position after operating the first lock.



The ripping fence is initially pitched .004" this is measured at the front and rear of the saw, with the saw fully raised. The dimension at the rear of the saw being .004" greater than at the front of the saw. Should this pitching require altering the grub screw locking the eccentric pivot pin, should be slackened off and the eccentric pivot pin turned so as to increase or decrease the pitching.




Fig. 8.

To adjust the fence pointer measure dimension between set of saw nearest fence and fence plate, then slacken off pointer locking grub screw, set pointer to dimension obtained between saw set and fence, lock pointer in position.

DOUBLE MITRE FENCE. Fig. 8. is in two parts both made to pivot from a central pin fixed in sliding table. Degree angles are marked on the table for accurately setting the fences, the principal angles being positively located by spring plunger. Mitres can be cut giving accurately squared frames when assembled a bar and stop determines the exact length of material cut off. Front leaf is supplied as standard, rear leaf optional extra.



Fig. 9.

Cross cutting fence Fig. 9. is used for both square and angular work and can be used either side of the saw in the table grooves. A bar and stop determines exact length of material cut off. This fence is an optional extra.

FIG. 10 STANDARD MACHINE TABLE




FIG. 11 LARGER CAPACITY TABLE

Should a larger capacity main table be supplied of either 51" or 72" between saw and ripping fence. A guard carried from the riving knife will be supplied in addition to standard guard, 16" dia. saws can only be used with riving knife guard, and up to 30" wide can be ripped when using standard guard and 18" dia. saw.

SLIDING TABLE ASSEMBLY

Lock handles marked "E" fig.6. With rails carrying linear bearings in position, and hexagon head screws holding adjustable rail finger tight, lower table on to intermediate slide and insert four pieces of $\frac{3}{8}$ " diameter steel, two each end, and adjust hexagon hole grubscrew at each end of table to trap $\frac{3}{8}$ " diameter rods in position as shown in fig. 1.







Insert wooden wedges at one end of table only and remove $\frac{3}{8}$ " diameter rods at this end as shown in fig. 2.

Enter two-thirds of the steel bridge between table and intermediate slide as shown in fig. 3.

Nylon cages and $\frac{3}{8}$ " diameter steel balls can now be inserted by holding each ball in nylon cage with one finger of each hand and feeding into slide-way as shown in fig. 4.

With bridge piece complete with nylon cages in position, remove wooden wedges and $\frac{3}{8}$ " diameter rods and place in position end retaining plates at each end of slide-way.

Traverse table to its full extent in one direction, fig. 5, and using an allen key adjust slide with screws marked "A" fig.6 until table moves freely in this position. Now traverse table to its full extent in the opposite direction and repeat adjustment with screws marked "C". Centralise table and adjust slide with screws marked "B". With table traversed to its full extent check for slackness in the slide in both directions and if necessary re-adjust to eliminate. Check sliding table for alignment with main table by traversing table to its full extent and checking with straight edge across main and sliding tables; repeat this operation at the opposite end. Should sliding table need re-aligning with main table, first remove dowel pins in brackets marked "D", slacken hexagon head screws and adjust table in required direction as shown in fig. 6.



SAWS FOR USE ON

THE P.P. TYPE DIMENSION SAW




18" RIPPING SAW FOR GENERAL WORK. PART No QS10.



16" FLAT CROSS CUT QS8
16" HOLLOW GROUND QS9
18" HOLLOW GROUND QS12
18" FLAT CROSS CUT SAW QS11



14" HOLLOW GROUND SAW QS33
for cutting Bakelite, Tufnol and similar materials.
18" NOVELTY TYPE SAW QS84
for cutting Plywood.



SPINDLE AND PIN HOLES IN SAWS.

The saws illustrated are specially manufactured and tensioned to run at high speed: it is therefore recommended they are obtained from us. The teeth are designed to give the best possible finish to the work.

Always keep the teeth sharp with an even set on both sides. Before putting a new saw to use it must be ranged down when running at normal speed and each tooth brought to a sharp cutting edge.

TUNGSTEN CARBIDE TIPPED SAWS


14" TUNGSTEN CARBIDE TIPPED QS174
for cutting Plywood, Hardwood & Asbestos.

14" NOVELTY TUNGSTEN CARBIDE TIPPED QS176
for cutting Plastics and Plywood.

16" TUNGSTEN CARBIDE TIPPED QS175
for cutting Hardwoods and Plywood.

TWO-KNIFE WEDGE TYPE CIRCULAR CUTTERBLOCK, PLAIN BORE, Q. R. TYPE.

8" dia. x 15/16" thick x 1 1/4" bore, Part No. QR.16.




These cutterblocks are designed to take 5/32" up to 1/4" thick cutters: this permits tungsten carbide tipped cutters to be supplied when necessary.

The cutters can be used for mouldings requiring not more than 1/2" cutter projection when using 1/4" thick cutters.

Our standard VZ range of cutters can be used in these cutterblocks, also existing Whitehill head cutters.

See Section D Tools Catalogue.


HIGH SPEED STEEL INSERTED TOOTH GROOVING SAWS.



When enquiring please give width and maximum depth of cut required. These saws are used for accurate high grade work. They are fairly expensive and require good handling. They are available in sizes from 10" to 12" diameter, and in varying widths on cut.

See Section A Tools Catalogue

4. 1/16" SQUARE 1 1/4" BORE DOVETAIL CUTTER-BLOCKS. 2" LONG.



These cutterblocks are used for longer runs, cutters working in pairs, several pairs may be mounted on a single block to build up mould. The cutters on these cutterblocks have a very good cutting angle. They are 3/8" thick and are securely held by dovetail bolts. It is therefore possible to have a large overhang allowing deep moulds to be worked with safety.

A limited range of Tungsten Carbide Tipped cutters are available. Shaped cutters can be provided to special order.

For standard cutters see Section C of our Tools and Sundries Catalogue.

HEAVY TYPE WOBBLE SAW UNIT ON SCREWED SLEEVE



Once set, the saw and collars remain tightly locked on sleeve. This type may be set and kept at its setting when not on machine. It is a self-contained unit. A special spindle locknut is supplied with this unit.

12" Diam. 1/8" to 2 1/8" grooves

See Section A Tools Catalogue



Outside Cutter



Inside Cutter



Outside Cutter

This tool is recommended for giving a smooth finish, both with and across the grain in hard or soft woods. It is made up in sets and each set consists of two outside cutters, $\frac{1}{8}$ " thick, and several inside cutters of various thicknesses, $\frac{1}{16}$ ", $\frac{1}{8}$ " or $\frac{1}{4}$ " thick, so that by adding to or taking away, any width of groove

within the range of the set, measured in eighths or sixteenths of an inch, can be cut.

No. 1. For grooves $\frac{1}{16}$ " to $\frac{3}{16}$ " wide, rising by $\frac{1}{8}$ ths.

No. 2. For grooves $\frac{1}{8}$ " to $\frac{1}{2}$ " wide, rising by $\frac{1}{8}$ ths.

No. 3. For grooves $\frac{1}{8}$ " to $\frac{3}{4}$ " wide, rising by $\frac{1}{16}$ ths.

No. 4. For grooves $\frac{1}{8}$ " to 1" wide, rising by $\frac{1}{16}$ ths.



EXPANDING TRENCHING AND GROOVING HEADS

This type is expandable and made in two sizes 13" diameter. Accurate spacing collars give the desired width of cut rising by $\frac{1}{16}$ " up to the maximum. It is arranged to give a shearing cut and provided with side or spur cutters to produce clean cutting. The head is mounted on a loose sleeve and locked tight by a fine thread nut. One sleeve only is required for the two sizes of head.

Sleeve for either head P. P. 135 complete with special spindle nut.

J. P. 550 for grooves $\frac{1}{2}$ " to 1" wide and $1\frac{1}{2}$ " deep

J. P. 558 for grooves $1\frac{1}{16}$ " to 2" wide and $1\frac{3}{4}$ " deep



To minimise the throat between fixed and sliding tables, both spacing collar and rear saw collar are removed from the spindle, this permits the trenching or grooving head to be set back into the main table as shown in the accompanying photograph.

The head illustrated opposite can be used with equal facility but is not capable of such fine adjustment for width of groove as the one shown above. The width of cut is varied by changing the cutters. Side or spur cutters in addition to the grooving cutters effect clean cutting.

Head J. P. 215 is 11" diameter and will groove $\frac{3}{4}$ " to 2" wide 1" deep.

ELECTRICAL INSTALLATION INSTRUCTIONS

The cabling between the motor and the control gear has been carried out by Wadkin Ltd. , and it is only necessary to bring the line leads to the machine for it to be put into service. This should be done as follows :

1. Fit triple pole isolating switch near the machine unless it has been supplied to special order by Wadkin Ltd. , when it will be fitted and connected to the machine.
2. Connect the line lead to the appropriate terminals. See diagram of connections. The cables should be taken to the machine in conduit and secured to the control gear by locknuts.
3. Connect solidly to earth.
4. Close isolating switch and press start button. If motor does not rotate in the right direction, interchange any two incoming line leads.

FAILURE TO START

1. Electric supply is not available at the machine.
2. Fuses have blown or have not been fitted.
3. Isolating switch has not been closed.
4. Lock-off or stop button has not been released.
5. Micro switch open, due to foot brake lever depressing switch (see separate foot brake adjustment instructions)

STOPPAGE DURING OPERATION AND FAILURE TO RESTART


1. Fuses have blown.
2. Overloads have tripped. They will reset automatically after a short time and the motor can be restarted in the usual manner.

ADJUSTMENTS

For a finer overload setting, set the load indicator to a lower value and vice-versa for a less fine setting.

GENERAL

Check the earth connection from time to time. Users are recommended to display in an appropriate position in the maintenance department a Wadkin Electrical Maintenance Instruction Card, No. 356, which is issued gratis on application.

**INSTALLATION INSTRUCTIONS.**

Fit isolating switch near machine so that the electrical gear may readily be isolated for inspection purposes. Bring supply cables to isolating switch and to L1 - L2 - L3 at contactor through conduit which should be screwed into the machine and secured by means of locknuts. Ensure that the direction of rotation is correct before putting the machine into service. To reverse rotation interchange L1 & L3 at contactor.

OPERATING INSTRUCTIONS.

To start machine : close isolating switch and press 'start' button. To stop machine : press 'stop' button. To lock off machine : press and turn 'stop' button, this must be released before a start can be made.

OVERLOAD.

Should the machine stop due to overload, wait for a short time to allow the coils to cool then start in the usual manner. The overloads are set at these Works at 'M' for automatic reset after tripping, if set at 'P' the plunger on the overload assembly should be depressed to reset.