





SERI

K

INSTRUCTION MANUAL No.4016/2

www.DaltonsWadkin.com

PREFACE

IMPORTANT

IT IS OUR POLICY AND THAT OF OUR SUPPLIERS TO CONSTANTLY REVIEW THE DESIGN AND CAPACITY OF OUR PRODUCTS. WITH THIS IN MIND WE WOULD REMIND OUR THE DIMENSIONS **CUSTOMERS** THAT WHILE AND PERFORMANCE DATA CONTAINED HEREIN ARE CURRENT AT THE TIME OF GOING TO PRESS, IT IS POSSIBLE THAT DUE INCORPORATION OF TO THE THE LATEST PERFORMANCE, DEVELOPMENTS **ENHANCE VPPLIERS MAY VARY FROM THOSE** DIMENSIONS AND ILLUSTRATED.

THIS MANUAL IS WRITTEN AS A GENERAL GUIDE. A TYPICAL MACHINE IS SHOWN TO ILLUSTRATE THE MAIN FEATURES.

Failure to comply with instructions in this book may invalidate the guarantee.





www.DaltonsWadkin.com

The CE mark on this machine signifies that an EC declaration of conformity is drawn up indicating that the machine is manufactured in accordance with the Essential Health and Safety Requirements of the 'Supply of Machinery (Safety) Regulations 1992'.

The 'requirements for supply of relevant machinery' in the General Requirement of the Regulations are not only that the machine satisfies the relevant essential health and safety requirements, but also that 'the manufacture carries out the necessary research or tests on components, fittings or the complete machine to determine whether by its design or construction the machine is capable of being erected and put into service safely'.

Persons who install this machine have duties under the 'Provision and use of Work Equipment Regulations 1992'. An indication of these duties is given in the following extracts, but the user should be familiar with the full implications of the regulations.

REGULATION 5 requires that;

Every employer shall ensure that work equipment is so constructed or adapted as to be suitable for the purpose for which it is used or provided.

In selecting work equipment, every employer shall have regard to the working conditions and to the risks to health and safety of persons which exist in the premises or undertakings in which that work equipment is to be used and any additional risk posed by the use of that work equipment.

Every employer shall ensure that work equipment is used only for the operations for which, and under conditions for which, this suitable.

In this regulation 'suitable' means suitable in any respect which it is reasonably foreseeable will affect health or safety of any person.

The Provision and Use of Work Equipment Regulations also include requirements as follows:-

regulation 6 - maintenance

regulation 7 - specific risks

regulation 8 - information and instructions

regulation 9 - training

Note :-

Attention is drawn to those requirements of the 'Woodworking Machines Regulations 1974' which are not replaced by the Supply of Machinery (Safety) Regulations or other, e.g; Regulation 13 of the Woodworking Machinery Regulation, -'Training', still applies.

Whilst the prime duty for ensuring health and safety rests with employers, employees too have legal duties, particularly under sections 7 and 8 of the Health and Safety at Work Act. They include :-

Taking reasonable care for their own health and safety and that of others who may be affected by what they do or don't do;

co-operating with their employer on health and safety;

not interfering with or misusing anything provided for their health, safety and welfare.

These duties on employees have been supplemented by regulation 12 of the Management of Health and Safety at Work Regulations 1992. One of the new requirements is that employees should use correctly all work items provided by their employer in accordance with their training and the instructions they receive to enable them to use the items safely.

Noise

Noise levels can vary widely from machine to machine depending on the conditions of use. Persons exposed to high levels, even for a short time, may experience temporary partial hearing loss and continuous exposure to high levels can result in permanent hearing damage.

The Noise at Work Regulations 1989 place legal duties on employers to prevent damage to hearing.

There are three levels of noise defined in regulation 2;

HEALTH AND SAFETY

The first action level :-

a daily personal noise exposure (LEP,d) of 85dB(A)

The second action level :-

a daily personal noise exposure (LEP,d) of 90dB(A)

The peak action level :-

a peak sound pressure of 200 pascals (140dB re 20pa)

The exposure level is obviously influenced by the emission level of all the equipment in use.

Emission levels for machines are provided in the particular machine instruction manual.

These levels are measured in accordance with ISO 7960 under certain specified test conditions, they do not necessarily represent the highest noise level, which is influenced by many factors, eg number of spindles in operation, type and condition of work piece, spindle speeds etc.

For regulations and information on relevant personal protective equipment i.e. ear defenders, employers should refer to the Personal Protective Equipment at Work Regulations 1992.

Dust

Wood dust can be harmful to health by inhalation and skin contact and concentrations of small particles in the air can form an explosive mixture.

The Control of Substances Hazardous to Health Regulations (COSHH) 1989 place legal duties on employers to ensure that :-

the exposure of his employees to substances hazardous to health is either prevented or, where this is not reasonably practicable, adequately controlled.

.... adequate control to exposure of employees to a substance hazardous to health shall be secured

by measures other than the provision of personal protective equipment.

where the measures taken in accordance with the paragraph above do not prevent or provide adequate control of exposure to substances hazardous to the health of employees, then in addition to taking those methods, the employer shall provide those employees with such suitable personal protective equipment as will adequately control their exposure to substances hazardous to health.

Instructions for Use

Machinery manufacturers are required by the Supply of Machinery Safety Regulations to provide comprehensive 'Instructions for Use' of equipment, it is important that this information is transmitted to the person using the machine.

IMPORTANT

SAFETY PROCEDURES AND CONSIDERATIONS

To ensure safe working conditions, persons operating and assisting with the operation of this machine must ensure that they read and fully understand the instructions given within this manual and have received sufficient training in the use of the machine and the safety aspects to be observed.

Grinding wheels that are damaged or improperly used are dangerous. All users should take sensible precautions in their handling, storage mounting and use.

If a grinding wheel breaks whilst running, pieces fly from the wheel. The wheel guard must always be used.

The grinding process produces sparks and dust. Eye protection must always be used. Coolant should always be used to prevent airborne dust.

Safety requirements for installing, operating and maintaining the machine are described in the relevant sections of this manual.

Keep the floor area around the machine clean and free from refuse. Do not allow the floor around the machine to become slippery.

Stop the machine and report immediately to a person in authority any actual or potential malfunction or operator hazard. Do not attempt to repair or rectify the machine unless qualified and authorised to do so.

The operator must not leave the machine running whilst unattended.

Never by-pass interlocks.

Note :-Persons under the age of 18 years must not operate the machine except during a course of training under the supervision of a trained operator.

WARNING :-

Nadi

Failure to observe correct operating procedures prior to and during operation of this machine can result in severe injury.

DO NOT attempt to operate the machine while under the influence of anything that reduces your alertness. •

INDEX

INDEX

Section	<u>Title</u>	<u>Page</u>
	Machine and Test Numbers Preface Manufacturer Health and Safety Safety Considerations	'n
1 1.1 1.2 1.3 1.4	General Description Machine Layout Intended Uses Technical Specification Profile Grinding Theory	1:1 1:2 1:3 1:5
2 2.1 2.2 2.3 2.4 2.5 2.6 2.7 2.8	Installation Moving the Machine Space requirements Foundations Levelling Transit Clamps Electrical Supply Lighting Cleaning	2:1 2:1 2:3 2:3 2:3 2:4 2:4
3 3.1 3.2 3.3 3.4 3.5 3.6 3.7	Preparation for Use Training Coolant System Controls Template Making Arm Rest Adjustment Tools and Accessories Testing the Machine	3:1 3:1 3:3 3:4 3:5 3:5 3:5

www.DaltonsWadkin.com

INDEX

.

:

. 1

t

<u>Section</u>	Title	Page
4	Operating Instructions	
4.1	Safety	4:1
4.2	Grinding Head Position	4:2
4.3	Dressing the Wheel	4;3
4.4	Mounting the Cutterhead	4:9
4.5	Stylus	4:10
4.6	Positioning the Template	4:11
4.7	Head Adjustment	4 : 12
4.8	Coolant Application	4:14
4.9	Carriage Control	4.14
4.10	Rough Grinding	4.15
4.11	Finish Grinding	4:16
4.12	Side Relief	4 : 17
4.13	Grinding Segmental Tooling	4 : 18
4.14	Arbor Counter balance (Optional extra)	4:18
4.15	Cutter Rests	4:18
4.16	Grinding segmental Tooling	4 ; 19
4.17	Grinding Planerheads	4:20
4.18	Care of the Machine	4:22
	-nst	
5	Maintenance	
5.1	Safety	5:1
5.2	Cleaning	5:1
5.3	Lubrication	5:1
5.4	Wheel Mounting and Guards	5:1
5.5	Coolant System	5:2
5.6.	Electrical System	5:2
5.7	Machine Alignments	5:2

INDEX

6

Illustrated Parts List	
Dresser	6:2
Dresser location / lock	6:5
Single Stylus Assembly	6:7
Stylus Turret Assembly	6:9
Template Slide	6:11
Template Slide	6:13
Template Crosslide	6:15
Dial Indicators	6:17
Carriage	6:19
Carriage	6 : 21
Carriage Arbor Location	6 : 23
Carriage Locks	6:25
Manual Head Tilt Assembly	6 : 27
Powered Head tilt Assembly	6 : 29
Head Main Pivot Shaft	6:31
Head slide & Cutter Rest	6:33
Head Assembly	6:35
Head Adjustment Screws	6:37
Head Adjustment	6:39
G	

APPENDIX

- A.1
- A.2
- A.3
- Approved Lubricants Grinding Coolant Data Anti-bacterial Solution Data Tools etc Supplied with Machine Accessories Available A.4
- A.5
- **Electrical Circuit Diagram** A.6

- ••

SECTION 1

SECTION 1 : GENERAL DESCRIPTION 1.1 MACHINE LAYOUT (15 (12) (13) (14) (16) (11)8 7 1) 3 BB 2) 9 6) 10) 4 (5)

1	Arbor	9	Carriage
2	Cutterhead	10	Carriage Locks (Optional)
3	Arbor Support	11	Grinding Head
4	Coolant Tank	12	Head Tilt
5	Tool Cupboard (optional)	13	Worklamp
6	Electrical Cabinet	14	Coolant Nozzles
7	Dresser	15	Head Rise And Fall
3	Template Slide	16	Stylus
			•

1.1

. .

. .

1.2 INTENDED USES

The Wadkin Visage profile grinder is a tool grinding machine designed for the grinding and re-grinding of various types of cutters used primarily in the woodworking industry.

Profile grinding is used for the grinding and regrinding of shaped profiles onto cutters used for producing timber mouldings.

The blank cutters are set into the cutterhead prior to profile grinding, and the cutterhead mounted onto the grinder. A 'mirror image' template, made 1 : 1, ensures that all the cutters are not only ground to the same shape, but they are also in the same position laterally, and as near as possible radially. The finished ground block containing 2, 4, 6, 8 or more knives is transferred to the machine on which it is to be used, without further movement of the cutters.

A bi-linear carriage is used to support the cutterhead on a free rotating arbor, together with the template and dresser unit. A cutter rest is mounted in front of the grinding wheel, and a stylus assembly is situated to the right of the head.

The template is made to match the required timber profile, and the grinding wheel is dressed to match the form of the stylus.

Grinding is a manual operation requiring the operator to control the arbor rotation to keep the cutter in contact with the cutter rest and move the carriage to keep the template in contact with the stylus.

A wet grinding coolant system is provided with suitable outlets for all three types of grinding to prevent burning of the cutters and to remove the dust and debris generated during the grinding process.

Note: This machine is not designed for the grinding of aluminium, magnesium or other materials which might create risks of fire or explosion. It is not designed for use in an explosive atmosphere.

www.DaltonsWadkin.com

GENERAL DESCRIPTION

SECTION 1

1.3 TECHNICAL SPECIFICATION

MACHINE CAPACITY		
Maximum length of cutterhead :		-
Using locking collars	315 mm	(12.4")
	335 mm	(13")
Maximum cutting circle :	350 mm	(13.8")
Minimum cutting circle :	70 mm	(2.75")
Maximum depth of profile :	40 mm	(1.57 °)
GRINDING WHEELS	\wedge	
Diameter	230 mm	(9")
Width	5 mm	(0.197")
Dressed width	4.7 mm or 3.0 mm	. ,
Bore	31.75 mm	(1.25")
SPINDL <u>E SPEEDS</u> :		
With 50 Hz Supply	3000 rpm .	
With 60 Hz Supply	3600 rpm	
Variable speed (option)	1500 – 3000 rpm	
MOTOR OUTPUTS		
Grinding spindle	1.5 Kw	(2 h.p.)
Head tilt (option)	0.025 Kw	(0.03 h.p.)
Coolant pump	0.15 Kw	(0.2 h.p.)
COOLANT SYSTEM		
Tank capacity - maximum	36 litre	(8 galls)
- minimum	18 litre	(4 galis)
WORKLAMP	20w Halogen	
MACHINE DIMENSIONS		
Height	1560 mm	(62")
Width	1150 mm	(45")
Depth	1090 mm	(43")
Weight (nett)	510 kg	(1125 lbs)
The second se	01010	(TEC IDS

Note

This unit will operate between 41 & 104 Deg. F (5 to 40 Deg. C); upto 3300ft (1000m); 20% to 95% RH (non condensing); and transportation and storage conditions of –13 to 131 Deg. F (-25 to 55 Deg. C).

SECTION 1

NOISE EMISSION VALUES

MACHINE CRITERIA :

The machine was free standing on a concrete floor, not bolted down and not on any vibration dampening,

GRINDING CRITERIA:

Knives : Solid HSS 8 mm x 60 mm serrated back

Wheel :	GW 203, 230 mm dia.
Speed :	3000 rpm
Depth of cut :	0.3 mm

The figures quoted in the noise emission chart are emission levels and not necessarily safe working levels.

Whilst there is a correlation between emission levels and exposure levels, this cannot be used reliably to determine whether or not further precautions are required to achieve safe working levels.

Factors that influence the actual level of exposure to the work force include the duration of exposure, the characteristics of the work room, sources of noise etc. i.e. the number of machines and other adjacent processes, also the permissible exposure levels can vary from country to country.

Emission levels, however will enable the user of the machine to make a better evaluation of the 'hazard and visk'.

MODEL :- VISAGE		
DECLARED NOISE EMISSION VALUE in accordan	ce with ISC	0 4871
	Idling	Operating
Declared A-weighted sound power level		
LWAd , in dB re 1 pvv.	74	83
	• •	
Declared A-weighted emission sound level (L pAd)		
in dB re 20 µPa at the operator's position	00	74
N	60	[4
Environmental correction factor (K)		3
values determined according to specific test code IS	O 3744	
3RATION LEVEL	····	
arbor support Less than 2.5 m/s		

SECTION 1

1.4 PROFILE GRINDING THEORY

PROFILE DEVELOPMENT

The profile ground on a cutter is a geometrically developed shape of that profile which is to be machined onto the timber.

If the cutting action of a shaped cutter is examined, Fig. 1b, it will be observed that the outer cutting edge reaches the maximum depth of cut before the inner, and that the maximum depth of cut for both edges occurs when the edge passes a line drawn through the horizontal plane of the cutterhead, (X = If the cutting angle (A) was 0°, the cutter would be ground in the horizontal plane (X - X) and the finished profile would match the template. However, most cutterheads have a cutting angle (A) of between 15° and 45°. This necessitates the use of the cutter rest, to allow rotation of the cutterhead whilst grinding.



Fig. 1b Note : Profile depth P_2 is larger than P_1 .

GRINDING THE DEVELOPED PROFILE

On the grinder the cutterhead is rotated so that the cutter comes into contact with a fixed height rest, so ensuring that the cutter is brought into the same plane (X-X) and angle (A) as it is when cutting. This means that although the template is an exact 1: 1 mirror image of the finished article (P,), because the grinding occurs at the same angle at which cutting takes place, a 'developed' shape (P_) is actually ground onto the cutter. This automatically elongates the profile so that it produces the correct depth of mould on the finished article.

The cutter rest also ensures that each cutting edge ground is in the same plane as the template



Fig. 1c

SECTION 1

CUTTER REST GAP

Theoretically the cutter rest and the ground edge of the cutter should be at the same point, [the theoretical grinding point], however for practical considerations there must be a gap (G) between the cutter rest and the wheel. *Fig. 1c.*

There should be a gap of about 0.5 mm for finish grinding to achieve the best accuracy of profile shape. The gap can be increased up to 2 mm when roughing out blank cutters to allow greater coolant flow for cooling and washing away debris.

The height of the cutter rest is also important to maintain the theoretical grinding point level with the horizontal plane (X - X) of the cutterhead. Deviations will create inaccuracies in depth of profile and require compensation when grinding side relief. The cutter rest should be kept in good condition and replaced when worn.

CUTTING AND CLEARANCE ANGLES

The cutting angle (A) (*Fig. 1b*) theoretically varies from the top to the bottom of the profile as the cutterhead rotates. The angle is however determined by the particular cutterhead and cannot be altered on the profile grinder,

The clearance angle (B) (*Fig. 1b*) is set on the grinder by raising or lowering the position of the grinding wheel. The angle chosen will depend on the type of cutter, type of timber, jointing requirements etc. for the job in hand.

SIDE RELIEF

Side relief (or side clearance) may be necessary to prevent rubbing or burning of the cutters when machining timber, depending on the profile shape.

When the profile has been finish ground the head (wheel) is tilted to the left or right to grind side relief using the same template setting. The objective is to grind clearance without altering the shape of the ground profile. This is achieved in practice by leaving a small land or unground portion of the ground profile. The smaller the land, the longer the cutter will perform without burning.

The machine is arranged such that the wheel tilts about the theoretical grinding point and a minimum land is produced. In practice however factors such as worn cutter rests, cutter rest gap, etc. may cause a larger land or alteration of the ground profile to occur. This should be compensated for by adjustment of the left right template position.

Normally a relief angle of about 5° is sufficient but can be increased up to as much as 15° if required. Some profiles such as grooving cutters require both left and right side relief.



SECTION 2

SECTION 2 : INSTALLATION

2.1 MOVING THE MACHINE

Verify the weight of the machine which is given in the Technical Specification (see section 1.3), Ensure that all lifting equipment used is capable of lifting this weight as a minimum.

Always use the lifting points provided. Lifting using other parts of the machine can be dangerous and can cause damage to the machine.



Fig. 2a Lifting points

The machine is designed to be easily lifted and manoeuvred using a fork lift truck. The forks should be at least 800 mm (32") long, not more than 125 mm (5") x 63 mm (2 1/2") in section, and capable of lifting the machine weight.

Carefully slide the forks directly into the rectangular hollow steel lifting sections and lift ensuring that the machine body remains parallel with the floor.

If slings are used to move the machine, place a suitable sling through each of the rectangular hollow steel sections of the machine base and bring one end of each up behind the rear coolant tray and the other end of each up the front of the machine.

It is very important to ensure that the lifting slings are suitably arranged to enable the machine to be lifted so that the body is parallel to the floor prior to its siting. Take care to ensure that the slings do not cause damage to the sheet metal covers etc. during lifting. Note: Transit clamps are fitted by Wadkin to prevent damage to the machine during transit. If the machine is moved at a later date it is important that the transit clamps are re-fitted before the machine is moved.

2.2 SPACE REQUIREMENTS

The foundation plan Fig. 2b shows minimum distances for positioning the machine near to walls etc. It should be noted that these are <u>minimum</u> distances and more space should be provided if possible for ease of access during routine maintenance.

It is recommended that a workbench or table be located within easy reach of the machine for loading cutterheads onto arbors etc. An area should also be provided for work in progress.

The operator's working area at the front of the machine should allow sufficient space for safe loading and unloading of the machine. The actual size will depend on the layout of the toolroom, location of workbench etc. The working area should not be cramped.

2.3 FOUNDATIONS

If the floor consists of 100 - 150 mm (4 - 6") of solid concrete no special foundation is necessary. M12 "Hilti" type holding down bolts (not supplied) can be used to secure the machine to the floor.

A good wooden floor should provide adequate foundation for the machine provided that it does not transmit vibration from adjacent machinery.

The machine should be bolted down before use. Final bolting down is carried out during final levelling.

INSTALLATION

SECTION 2



SECTION 2

2.4 LEVELLING

IMPORTANT : THIS MACHINE MUST BE CORRECTLY LEVELLED.

The machine should be set to a spirit level by adjusting the four levelling screws on the machine base. At this point the transit clamps should be removed and final levelling carried out.

Level the machine such that the carriage will slide with equal ease to either the left or the right. The carriage must <u>not</u> have a tendency to slide towards the grinding wheel. It should be neutral, or tend to slide towards the operator to prevent unintentional contact with the grinding wheel when released.

2.5 TRANSIT CLAMPS

The transit clamps must only be removed from the machine after it has been finally sited and should be kept safe for possible future use if it ever becomes necessary to move the machine again.

There are two transit clamps which are fixed between the arbor supports and the arm rest bracket. The clamps and fixing screws should be removed from the machine. The arm rest which is shipped separately should be assembled as described in section 3.6.



Fig. 2c

Transit clamps

2.6 ELECTRICAL SUPPLY

IMPORTANT : ELECTRICAL WORK SHOULD BE CARRIED OUT BY A COMPETENT ÉLECTRICIAN

US & Canada - All supply wiring and conduit sizes must be sized in accordance with the NEC (National Electric Code – NPFA 70) and applicable state, county or jurisdictional codes, or CEC (Canadian Electric Code)

The customer is responsible for an adequate electrical supply. Details of the power requirements are provided on the machine nameplate. The electrical cabling between the motor and the attendant control gear has been carried out by Wadkin prior to despatch. It will only be necessary to connect the 3 - phase power supply to the incoming terminals L1, L2 and L3 at the disconnect switch in the electrical control cabinet.

ENSURE THAT THE MACHINE IS CONNECTED SOLIDLY TO EARTH.

1) Check that the electrical supply details on the machine nameplate correspond to the electrical supply available and select the size of main cable to correspond to the current indicated on the machine nameplate.

2) Check that the fuses at the electrical supply distribution board are correct.

3) Check that all connections are sound.

Power line to machine should be protected with inline fuses, rated as listed below, or with equivalent fuses to meet local requirements.

······	Fuse Details :	
	GEC Spec.	<u>Fuse Size</u>
575v	NIT 16 BS 88	16 Amp
460v	NIT 16 BS 88	16 Amp
415v	NIT 16 BS 88	16 Amp
380v	NIT 16 BS 88	16 Amp
230v	NIT 20 BS 88	20 Amp

2.3

www.DaltonsWadkin.com

www.DaltonsWadkin.com

INSTALLATION

SECTION 2

2.7 LIGHTING

The area where the machine is installed should be provided with amblent lighting of normal intensity. The machine is equipped with a worklamp for illumination of the immediate working area around the grinding wheel. Adequate lighting is essential for safe operation of this machine.

÷1 •

Interform Wadkin with all suvered with a rust preventative. Interform with a rust preventative. Interform of the carefully removed with a cloth sumped with paraffin or diesel. Ensure that the area around the machine is clean, free from oil, and anything that is likely to cause tripping or slipping.

cause

www.DaltonsWadkin.com

2.4

....

SECTION 3

SECTION 3 : PREPARATION FOR USE

3.1 TRAINING

Grinding operators should be trained in the safe use of each machine which they operate. They must also be given instructions in the safe use of grinding wheels.

It is recommended that personnel involved with the machine are aquainted with the Woodworking Machines Regulations 1974 and also Booklet Number 14 'Safety In The Use Of Woodworking Machines', issued by the Department of Employment and available from Her Majesty's Stationary Office. Also Code of Practice 'Safeguarding Woodworking Machines' Part1 BS6854.

Personnel involved with the use of grinding wheels should be aquainted with the Abrasive Industries Association leaflets 'Safety In The Use Of Abrasive Wheels (General)' and 'DO'S and DONT'S - Safety Guide For Grinding Wheel Users'. Also the Health and Safety Series Booklet HS(G)17, FEPA Safety Code 12-GB-1987 and HSE Guidance Book Note PM22.

In the U.K., the Health and Safety at Work Act (1974) requires that :-

NO PERSON SHALL MOUNT ANY GRINDING WHEEL UNLESS HE HAS BEEN TRAINED AND APPOINTED IN ACCORDANCE WITH THE ABRASIVE WHEELS REGULATIONS 1970 No.535 (REGULATION 9).

It is a statutory requirement that the person who mounts grinding wheels onto the grinding machine shall be a trained and competent person appointed by the factory occupier, and whose name must be registered in an appropriate register.

In other areas local regulations should be checked and adhered to.

In-house training courses for grinding machine operators are run by Wadkin at the Green Lane Road works in Leicester. Demonstrations can also be arranged, contact Wadkin for further details.

...

3.2 COOLANT SYSTEM

Before handling coolant fluids all operators should be familiar with the appropriate Health and Safety precautions - see Appendix A2.

Refer to Fig. 3a

Remove the coolant compartment door from the front of the machine by releasing the quarter turn latch and lifting from its location on the lip of the coolant tank. Slide the tank [9] forwards and lift off the coolant pump [7]. The pump is attached to a plate [8] which locates onto the lip of the tank, it is not necessary to remove any screws.

Coolant fluid supplied with the machine should be mixed according to instructions and the tank filled to the correct level. The pump is then replaced and the tank slid back into position in the machine base.

If the machine is fitted with a pump-out facility check that the flow control tap handle [5] is pointing to the left and that the end of the coiled pipe [6] is over or into the tank.

If the optional additional filter tray [10] is to be used it should be positioned as shown on top of the coolant tank. Filtration papers can be placed in this tray to filter out non-magnetic tungsten carbide materials if required.

Replace the coolant compartment door.

The two metal filtration magnets [3] should be placed in the separation trough [1] close to the drain hole positions [2]. Take care to ensure that fingers are not 'nipped' - the magnets are very strong. At the rear of the machine check that the two drain pipes [4] are correctly located in the holes directly over the tank.

.

SECTION 3



Fig. 3a

•

Coolant system

.

...

•

SECTION 3

3.3 CONTROLS

The operator should be familiar with the electrical controls before the machine is used. All the controls are located on the panel to the right hand side of the operator position.

1) The grinding spindle start / stop buttons are marked with the symbol :-



4) If the machine is fitted with a powered head tilt facility the head tilt buttons are used to tilt the head for side relief i.e. the movement will stop when the button is released. The head tilt left button is marked with the symbol :-.



2) The coolant pump start / stop buttons are marked with the symbol :-



3) If the variable speed facility is fitted the speed control knob is a single turn rotary potentiometer which is used to select the speed of the grinding spindle. Graduations are provided to indicate the selected speed.



5) The larger emergency/master stop button is also used to stop the grinding wheel and coolant pump on machines where individual stop buttons are not provided,

6) The isolator (disconnect) switch is located either at the rear of the coolant tray or on the electrical cabinet door (see fig.2b).

SECTION 3

3.4 TEMPLATE MAKING

Both steel templates made by hand and plastic templates made by machine are suitable for use on this grinding machine.

HAND MADE TEMPLATES

Steel templates should be made from blanks (NXT 6) as supplied with the machine. They should always be made at least 20 mm wider than the cutter [1] and should have at least two fixing holes if screw fixings are to be used. Fixing holes are not regulied if template clamps are used.

An exact mirror image of the finished moulding [2] is drawn on to the template [3]. If the cutter projects [P] beyond the moulding, a similar projection should be included on the template. The blank is then cut out using a hacksaw and filed very accurately to shape. Due to the relatively thin steel used, this is easily achieved, although if still produces a stiff and stable template. The template should fit precisely on to the moulding.

Note : Detailed instructions are provided as part of the Wadkin in-house training course on profile grinding. In addition an Instruction manual is included in the Wadkin template making toolkit (see Appendix A5).

TEMPLATE MAKING MACHINE

Template making machines which produce plastic templates suitable for this grinding machine can be supplied by Wadkin. Contact Wadkin for full details.

Using CNC technology, complex profiles can be drawn on screen and downloaded to the machining unit for rapid template production. Some of the benefits of this method are :-

Consistent accuracy guaranteed The facility to scale down existing profiles to suit variations in timber sizes. Profiles can be stored on file for immediate production of duplicate templates Finish component checking gauges can also be made.



SECTION 3

3.5 ARMREST ADJUSTMENT

The armrest is adjustable in both height and position and should be set to give a comfortable posture for the operator.

Four height settings are available by arranging the loose collars [1] above or below the fixing bracket [2]. With the fixing nuls loosened the armrest can be moved forwards or backwards to suit the operator's forearm length, and the diameters of cutterheads to be ground. If a wide range of cutterhead diameters are used it may be necessary to move the armrest to the forward position for small diameters and to the outer position for large diameter cutters. Short operators may require a duckboard to stand on to avoid excessive reaching.



3.6 TOOLS AND ACCESSORIES

The tools and accessories supplied with the machine should be unpacked and checked (Appendix A4) to ensure that the machine is complete. Hand tools should be conveniently placed for use by the operator as and when required.

Grinding wheels must be stored carefully to avoid damage.

On some machines a tool and wheel storage cupboard is provided on the left of the machine. Storage for spanners and other equipment is provided in the door and the sliding middle tray, and for grinding wheels in the slide-out lower tray.

3.7 TESTING THE MACHINE

Check that all guards and covers are correctly fitted - particularly the wheel guards.

Check that the carriage movement is free and does not tend to move towards the grinding wheel when released.

Check that there are no loose items on the grinding spindle before starting the machine

Switch power on and check that the worklamp is working correctly.

It is important to check that the machine has been connected to give the correct direction of rotation:-

On machines without a variable speed facility start and stop the grinding spindle and check the direction of rotation. The profile grinding spindle should rotate anti-clockwise when viewed from the right hand side of the machine.

If a variable speed facility is fitted the above method <u>cannot</u> be used as the spindle rotation will be correct even if the connections are incorrect.

Where a powered head tilt is fitted, the left arrow button should cause the head to tilt down to the left. Check that the limit switch will prevent movement beyond the limit of travel.

As a final check on all machines, make sure that the rotation of the coolant pump corresponds to the arrow on the pump body. NOTE: Do not run coolant on a stationary grinding wheel

If any of the above criteria are wrong, any two of the line lead connections at the incoming supply should be reversed by a competent electrician, and the rotations rechecked.

SECTION 4

SECTION 4 : OPERATION

4.1 SAFETY

Wheel Guard - The Wheel guard serves two purposes :

1) To avoid, as far as possible, the chance of an operator coming into contact with the wheel,

2) The guard should contain the majority of wheel fragments if it shatters.

The wheel guard should ALWAYS be in the correct position.

<u>Safety Goggles</u> - Eye protection is of the utmost importance in the presence of sparks and flying particles caused during grinding. Safety goggles should be worn at all times in the grinding area.

<u>Protective clothing</u> - Safety aprons, gloves and safety shoes should be worn particularly when handling woodworking cutters.

<u>Dust protection</u> - A coolant flow from above aids the cooling of the cutter, but more importantly it washes away all the wheel and grinding dust. Always use coolant when grinding or dressing the wheel.

Note : Dry grinding requires extraction.

<u>Grinding wheels</u> - Must always be correctly mounted, and only by suitably trained personnel.

<u>Personal items</u> - such as jewellery, rings, watches, bracelets etc. should be removed. Remove or fasten loose articles of clothing such as neckles, and confine long hair to avoid risk of entanglement.

<u>Barrier cream</u> - the use of a barrier cream is recommended when working with coolant fluids.

<u>Stop the machine</u> before making adjustments, measuring, loading or unloading, etc. to avoid unintentional contact with the grinding wheel.

Keep clear until rotation has ceased.

Lighting - Always ensure adequate lighting. Areas of poor lighting or shadow can create unnecessary risks for the operator.

<u>Care of the machine</u> - Clean down regularly and ensure that the machine is kept in good condition.

<u>Safe operation</u> - of machinery requires constant alertness and close attention to the work in hand.

<u>Materials</u> - This machine is not designed for the grinding of aluminium, magnesium, or other materials which might create risks of fire or explosion.

SECTION 4

4.2 THE GRINDING WHEELS

in the U.K., the Health and Safety at Work Act (1974) requires that :-

NO PERSON SHALL MOUNT ANY GRINDING WHEELS UNLESS HE HAS BEEN TRAINED AND APPOINTED IN ACCORDANCE WITH THE ABRASIVE WHEELS REGULATIONS 1970 No.535 (REGULATION 9).

It is a statutory requirement that the person who mounts grinding wheels onto the grinding machine shall be a trained and competent person appointed by the factory occupier, and whose name must be registered in an appropriate register.

In other areas local regulations should be checked and adhered to.

CHOOSING THE WHEEL

Aluminium oxide vitrified bonded grit wheels are normally used for profile grinding solid H.S.S. and H.S.S. on iron cutters. The various wheel options are listed in Appendix A5

As a general guide, the wheels used for profile grinding are coarser and softer than those used for hand grinding, so a much faster grind is possible. A 60 grit wheel is normally used for roughing out and a 220 grit wheel for finishing.

New wheels should always be 5 mm wide. Subsequent dressing will bring the wheel to the required width and form to match the stylus.

The wheel speed should be checked. Grinding wheels should never be operated at a speed in excess of the permissible speed (r.p.m.) marked on the wheel. The speed of the grinding spindle is marked on the machine.

CHECKING THE WHEEL

The wheel should be closely inspected for any signs of damage (e.g. chips, cracks, discolouration, etc.) which may have occurred in storage, or in transit. The 'Ring Test' should be carried out in a place where the 'ring' may be easily heard.

The ring test depends on the fact that the damping characteristics of a cracked wheel alters the sound emitted when a wheel is lightly tapped. It is subject to interpretation by the operator and is primarily applicable to vitrified bonded wheels. To perform the ring test, wheels should be tapped gently with a light non-metallic implement such as the plastic handle of a screwdriver.

Tap the wheel approximately 45 degrees each side of the vertical centre line and approximately 1 or 2 inches from the periphery, then rotate the wheel 45 degrees and repeat the test.

A sound, undamaged wheel will give a clear tune. If cracked, there will be a dead sound and not a clear ring, and the wheel must NOT be used.

DAMAGED WHEELS MUST NOT BE USED.

MOUNTING THE WHEEL

The machine should be electrically isolated to prevent unexpected start-up of the spindle whilst mounting the wheel.

When the spindle rotation has ceased the wheel guard should be opened. Note : The wheel guard is designed to be opened by the use of a spanner to deter unauthorised access.

If a wheel is already fitted it should be gripped to prevent it rotating whilst the spindle nut is loosened. The nut [1], washer [2], outer flange [3] and wheel [4] can then be removed. The rear flange [6] can be left in position on the spindle.



SECTION 4

Check that the wheel flanges are in good condition, free from burrs, and seat correctly on the grinding spindle. Wipe the spindle and flanges clean before re-assembly.

When fitting a new wheel, one side of the wheel should be marked as datum.

Whenever a wheel is fitted the marked (datum) side should always be brought up against the rear flange [6].

It is most important that soft card washers (blotters) [5] are fitted between the wheel and the wheel flanges. These ensure that the tightening stresses are evenly distributed around the inner and outer flanges, prevent slipping at lower clamping pressures and reduce wear on the flanges.

Note : Wadkin wheels are normally supplied with the blotters already fitted to the wheel.

The wheel bore should always give a good location fit. Do not attempt to force a wheel on or modify the bore size. With the wheel and blotters correctly seated, re-fit the outer flange [3], washer [2] and nut [1]. The wheel should be gripped to prevent rotation and the spindle nut tightened. Excessive clamping of the spindle nut should be avoided to prevent damage to the wheel.

Note : The method of gripping the wheel by hand when tightening the locknut ensures that only a limited amount of torque can be applied. The correct tightening torque required is 12 Nm (9 ft lbs).

PRE-MOUNT WHEEL FLANGES

Pre-mount wheel flanges are an optional extra which allow wheels to be interchanged whilst retaining the wheel in its originally dressed position.

The wheel should be mounted as previously described using blotters [5] and locked using the flange locknut [8]. The complete wheel/flange assembly is then locked onto the grinding spindle using washer [7] and locknut [1].

The complete wheel/flange assembly can be removed by releasing the spindle locknut [1] and replaced with another wheel/flange assembly.



Fig 4b Pre-Mount Wheel Flanges

RUNNING THE WHEEL

The wheel guard <u>must</u> be closed and securely locked before the wheel is started.

A newly mounted wheel and a wheel being remounted, should run free for a short period (1 minute is recommended) before it is used, and everyone should <u>stand clear</u>. Note : A re-mount should always be treated as a new wheel. If damage to the wheel has gone undetected it is possible that the wheel could disintegrate when it is started up.

IMPORTANT

SHOULD A WHEEL DISINTEGRATE, ALWAYS CAREFULLY EXAMINE THE SPINDLE, THE GUARDS AND THE FLANGES TO ENSURE THAT. THEY ARE NOT DAMAGED.

A small amount of unevenness is not uncommon on new wheels, but any high spots are normally removed when the wheel is dressed.

SECTION 4

Grinding wheel DOs and DON'Ts

DO

1) HANDLE and STORE wheels in a safe manner.

2) VISUALLY INSPECT and RING all wheels before mounting, for possible damage.

3) MAKE SURE OPERATING SPEED established for machine does not exceed speed marked on wheel.

4) CHECK MOUNTING FLANGES for equal and correct diameter and that they are clean, free from burrs and recessed where applicable.

5) USE MOUNTING BLOTTERS where required.

6) Be sure CUTTER REST is not more than 2 mm away from the periphery of the wheel.

7) Always USE THE WHEEL GUARD.

8) Allow NEWLY MOUNTED WHEELS to run at operating speed with guard in place for at least one minute, with ALL PERSONNEL STANDING CLEAR before grinding.

9) Always WEAR SAFETY GLASSES or some type of eye protection and protective clothing, where necessary, when grinding.

10) TURN OFF COOLANT before stopping wheel to avoid creating an out-of-balance condition.

11) DRESS the wheel regularly to avoid loading.

<u>DON'T</u>

1) Use a wheel that HAS BEEN DROPPED.

2) FORCE a wheel onto the machine spindle OR MODIFY size of the mounting hole.

3) EVER EXCEED MAXIMUM OPERATING SPEED established for the wheel.

4) Use mounting flanges on which the bearing surfaces ARE NOT CLEAN AND FLAT.

5) TIGHTEN the mounting nut EXCESSIVELY

6) TRAP the workpiece between the wheel and cutter rest.

7) Start the machine until the WHEEL GUARD IS IN PLACE.

8) Grind on the SIDE OF THE WHEEL

9) STAND DIRECTLY IN FRONT OF a grinding wheel whenever a machine is started.

10) Grind material for which the WHEEL IS NOT DESIGNED.

11) ROLL WHEELS ALONG THE FLOOR.

12) BANG THE WORKPIECE AGAINST THE WHEEL.

SECTION 4

DIAMOND WHEELS

Diamond wheels are normally used for profile grinding T.C.T. cutters. The various wheel options are listed in Appendix A5.

Diamond profile grinding wheels have a relatively thin layer of diamond abrasive bonded onto a solid aluminium core.

DIAMOND WHEELS SHOULD NOT BE DRESSED.

Because dressing is not used, the correct width and form of wheel must be selected to match the stylus used. Diamond wheels are mounted using the normal wheel flanges, but blotters should not be used.

A small amount of unevenness is not uncommon when these wheels are started up, but the wheel should quickly bed down as any high spots are worn down during grinding.

www.Daltons

4.3 DRESSING THE WHEEL

The purpose of dressing the wheel is :-

1) To produce a wheel profile identical to the stylus.

2) To compensate for wheel wear.

3) To 'open up' the wheel for free cutting by presenting new sharp grains of abrasive to the surface.

A full width rounded wheel should be dressed for most cutter profiles as this wears down more or less evenly. It may be used to rough and finish grind external corners, external curves, bevels, straight sections and internal curves with a radius larger than that of the wheel.

A suitable small radius or sharp edged wheel should be used to complete those parts that the half-round wheel cannot finish. The contact area of small radius and corner grinding wheels is small, so it is advisable to use a harder wheel. When changing the grinding wheel shape it is essential to make sure that it matches the stylus and that it is aligned correctly.

www.DaltonsWadkin.com

OPERATION

SECTION 4

THE DRESSER

. .

The dressing diamond is mounted onto the end of a screw [1] which allows for initial alignment, compensation for diamond wear and can provide for variations in radius of dressing.

The dresser has two basic movements. One is a rotary movement about a vertical axis, which is used to dress a radius on the periphery of the wheel (rounded). A lock [3] is provided for this movement.

The second is a swivel movement about a horizontal axis which is used to dress the sides of the wheel and to dress the periphery to a square edge or angle.

The movements are controlled using a hand lever [2] which allows dressing to be carried out with the hands well clear of the wheel and coolant flow. The dresser is located in its vertical position by spring plunger [7]. The plunger can be dis-engaged by a quarter turn. The swivel movement can be locked using the knurled knob [8].

When the dresser is not in use it should be parked swivelled down to the horizontal position to avoid possible foul conditions with the spindle drive motor.





4,6

SECTION 4

DRESSER LOCATION

The positioning of the dresser relative to the grinding wheel is determined by the fork assembly on the front of the dresser unit which should be engaged with the location plate mounted directly below the cutter rest.

The lateral adjustment screw on the right hand side of the dresser fork is factory set, such that the dresser rotates symmetrically about the grinding wheel and should not be tampered with.

A handwheel [9] is provided on the left hand side of the dresser fork which is used to secure the dresser in position.

The adjustment handwheel [10] positions the dresser relative to the cutter rest and hence determines the gap between the grinding wheel and the cutter rest. Winding the handwheel in will reduce this gap whilst winding it out will increase it. The gap should be set between 0.5 mm and 2 mm as described in section 1.4.

The locking nut [11] should always be secured after making this adjustment.

With the dresser securely located, the set relationship between the stylus, dresser, template and wheel ensures that, when dressing is carried out, the wheel is automatically re-aligned to the stylus. As the wheel reduces in diameter no additional adjustment is needed for re-alignment.

NN N

DRESSER OPERATION

IMPORTANT:

The dressing movement should be un-hurried and the cut light to avoid ripping out and wasting grit, to achieve a good surface finish from the single point diamond, and to avoid unintentional contact with the wheel.

Coolant should be used whilst dressing to prevent dust formation, and to prolong the life of the diamond.

Eye protection must be used.

The wheel guard should be closed.

WIDTH DRESSING Because of the firing process in

Because of the firing process in the manufacture of vitrified wheels, the wheel cannot be guaranteed to be perfectly flat and the right thickness. Although dressed and sized wheels may be purchased, truing is best carried out on the grinding machine.

Wheels are generally supplied at 5.0 mm width and so the wheel must be sized to the selected stylus width (generally 4.7 mm or 3.0 mm wide).



Using the handlever the dresser should be rotated to the stop position at the right hand side of the wheel and locked [3] in position. With the spring loaded plunger [7] dis-engaged the dressing diamond can be moved along the side of the wheel.

The dressing diamond [1] should be screwed in until it touches the side of the wheel and the locknut locked. The wheel and coolant are then started and the side of the wheel dressed.

Stop the wheel and rotate the dresser through 180° to the opposite side.

Lock [3] in position and dress the left hand side of the wheel.

SECTION 4

With both sides dressed and the wheel stopped, the width of the wheel should be measured using a micrometer or vernier calliper, and compared to the stylus width. The difference between the two measurements is halved and this distance is the amount the dressing diamond will need to be moved in, in order to size the wheel.

Successive dressings may be required from both sides of the wheel to bring it to the required width. A maximum dressing cut of 0.1 mm (0.004") is recommended. Each graduation on the dressing diamond scale represents 0.05 mm (0.002").

Note : Machines are often despatched from Wadkin with the dresser set to suit a 4.7 mm stylus and a wheel which has been dressed to width during machine testing.

DRESSING A RADIUS

...



Using the handlever [2] the dresser should be brought up to the wheel and, with the plunger [7] engaged, rotated through 180° to dress the radius. Successive dressing cuts are taken by moving the wheel towards the dresser using the handwheel [5] (*Fig. 4c*) at the top of the wheel guard. The lock [6] should be released when moving the wheel.

Note : When dressing a radius on a new wheel or changing shape, the wheel should be backed off from the dresser and then advanced taking a series of small cuts. Regular changing of shapes by dressing can be wasteful on wheels. It may be preferable to change wheels.

DRESSING SQUARE

The dresser is brought up to the front of the wheel and set at 0° using the scale [4] (*Fig. 4c*). The rotation should then be locked [3]. With the plunger [7] dis-engaged, the front of the wheel is dressed by moving from side to side.



The dresser is used as for square dressing but with the required angle set on the scale to suit the stylus shape. A series of cuts should be used if changing the wheel shape.

DRESSING AN ANGLE



Dressing is again carried out as for square or 'V' dressing but in this case the dresser location position must be changed by adjustment of handwheel [10] (*Fig 4c*) and the cutter rest gap reset. Note : If the dresser location position is changed part way through a cutter grind, the automatic datum is lost and must be compensated for by adjustment of the template slide.

SECTION 4

4.4 MOUNTINGTHE CUTTERHEAD

IMPORTANT : The grinding wheel must be stationary when loading or unloading the machine to avoid unintentional contact with the wheel.

Hydro-lock type cutterheads should be pressurised to lock the block onto the arbor. All other cutterheads should be locked to the arbor using the locking coltars supplied.

One half of the locking collar set [6] is clamped either side of the cutterhead. To lock the cutterhead in position, the lock nut [7] of the larger collar is wound firmly against the cutterhead using the tommy bar provided. Fit the cutterhead onto the arbor or, if the same arbor has been used on the setting stand, simply transfer it over to the grinder. The arbor should be loaded onto the grinder with the handwheel [1] to the right. The pair of arbor bearings should locate over the axial location key [8]. The arbor clamps [2 & 3] should then be 'nipped' in position - do not over-tighten.

Note : The machine is normally supplied with a heavy duty arbor which is fitted with a 37 mm outside diameter bearing [4]. Arbor sizes below 40 mm (1 1/2") diameter are fitted with a 28 mm outside diameter bearing to allow removal of the cutterheads. If the smaller arbor sizes are used, alternative sizes of shell [5] and clamp [3] must be used. (See Appendix A5).



Fig. 4d Art

Arbor assembly

OPERATION .

SECTION 4

The cutterhead should not be locked to the arbor until the template and stylus are fitted. The cutterhead is positioned along the length of the arbor to align the position of the cutter profile and grinding wheel with that of the template and stylus. When in approximately the correct position the cutterhead should be locked to the arbor.

4:5 STYLUS

The most commonly used stylus is 4.7 mm wide, half round at one end and square at the other. The stylus can be rotated in its holder to present either of these forms to the template. For the majority of profiles the radiused form is used throughout the grinding process. If features such as square corners are contained within the profile then it will be necessary to turn the stylus round. More intricate profile shapes may require the use of the alternative stylii.

Before using any particular stylus it will be necessary to square it up to the template location using either a template with a square end, or an engineers square. The stylus is locked in position using the locking screw [2]. Two types of stylus mounting are available for this machine. In each case the stylus should be positioned to suit the diameter of cutterhead to be ground and locked [3]. This sliding stylus arrangement provides a quick set facility when grinding cutterheads of widely differing diameters.

In order to maintain the automatic dressing datum, the stylus position should not be moved part way through grinding a cutterhead.

Note : Whenever the stylus is changed it will be necessary to redress the wheel.

The stylus turret mounting contains six stylii to suit various profiles. The turret is rotated by releasing knob [4],and rotating to the selected stylus. The turret is positioned by a pin location. Lock knob [4]. This can be carried out without losing the dressing datum.



Fig.4e

www.DaltonsWadkin.com

SECTION 4

3

8

4.6 POSITIONING THE TEMPLATE

The grinding wheel must be stationary whilst positioning the template. Ensure that both the template and the template carrier are clean and that the location edges are free of bumps or bruises. The template is fixed in position [6] on the carrier using either two M8 screws in the tapped holes provided, or, using the two template clamps. Ensure that the template seats correctly.

The template and stylus positions must be set to bring the cutter into the correct position relative to the grinding wheel.

When the stylus has been locked in position, fine adjustment is made by moving the template slide in and out. The lock [2] should be released and adjustments made using the handwheel [1].

The axial (left / right) position of the template is adjusted by unlocking the handlever [5] and adjusting the handwheel [8]. It may be necessary to make repeated adjustments of the in / out and axial windings before the template is positioned sufficiently accurately relative to the cutter when regrinding existing profiles. When grinding, the depth of cut is controlled by movement of the template slide using handwheel [1]. Locks [2] and [5] should always be secured whilst grinding is carried out.

Dial indicators [3] can be provided for both axes of the template slide to allow more accurate positioning. The amount of travel on the dial indicators is less than that provided for the template slides. The locking knobs [4] should be left unlocked whilst setting up the templates to avoid damage to the dial indicators. When required, the appropriate locking knob [4] should be secured and the indicator dial rotated to set to zero. The dial indicator will then indicate the amount of movement of the template slide.



3

1
SECTION 4

4.7 HEAD ADJUSTMENT



Fig. 4g

To set the cutter dearance angle, the grinding wheel is wound up or down in relation to the cutter rest. The rise and fall handwheel [1] is located at the top of the machine. (It is advisable to use the crank handle supplied with the machine when making this adjustment.) By winding the head up the clearance angle is increased and by lowering it is reduced. The lock for this movement is at position [3].

Whenever the cutter clearance angle is varied it will be necessary to re-dress the wheel to restore the automatic datum and cutter rest gap.

A scale [2] is fitted to indicate the clearance angle set. Due to the complex geometry of the headslide variations will occur as the wheel diameter is reduced. If an accurate clearance angle setting is required when using a reduced diameter wheel, a modified scale reading from *Fig. 4j* should be used.

4.12

SECTION 4



To set a clearance angle of 15° using a 185 mm diameter wheel, the head should be set to 16° on the scale.

.. .

SECTION 4

4.8 COOLANT APPLICATION

IMPORTANT : Coolant must always be used when grinding;

a) It prevents overheating of the cutters which may lead to loss of hardness or even cracking of the cutting edges. If this should occur, cutters would need to be replaced.

b) it washes away grinding dust and debris.

c) It prevents the formation of airborne dust.

The flow of coolant to the twin nozzles above the cutter is controlled by taps mounted above the wheel guard... fig. 4g [5]. The flow to the underside of the cutter is controlled by a tap located below the head motor to the left of the tool rest... fig 4g [4]. Both flows of coolant should be as large as possible and directed as close as possible to the grinding point. NOTE: A good flow to the underside is also important to avoid clogging or overheating of the nylon pipe.

Prolonged immersion of a stationary wheel can create an out of balance condition. Coolant should never be left to run onto a stationary wheel. When starting up :-

1) Start wheel 2) Start coolant

When stopping, do not stop the wheel before the coolant.

4.9 CARRIAGE CONTROL

The machine carriage may be moved around in order to reproduce the cutter profile to the depth allowed by the stylus and template. The rotation of the arbor must be controlled to keep the cutter in contact with the cutter rest. The best control may be achieved by keeping both elbows or forearms on the armrest and holding the arbor handwheel with one hand and the plain arbor handle with the other. Controlling the machine in this way will aid operator comfort by keeping hands away from the grinding area thereby reducing contact with the grinding coolant.

Once the cutter is firmly in contact with the cutter rest watch the template and stylus (NOT the cutter) so as to anticipate the carriage movements needed. Grinding progress can then be gauged by the sound and feel of grinding. Grinding pressure should be light enough to allow the grinding wheel to cut freely. If necessary let the cutter ride lightly on the grinding wheel, leaving a gap between the template and stylus, which is narrowed during repeated grinding passes until the cutter is ground away. Keep the cutter moving at all times and in the smoothest possible manner.

Side grinding should only be performed with wheels designed for the purpose. Grinding on the flat sides of wheels designed for peripheral grinding may be dangerous and cause broken wheels. This does not preclude their use for applications such as shoulder and form grinding where it is recognised that a limited amount of side grinding is performed. Extreme caution should be exercised not to use excessive pressure.

4,14

SECTION 4

4.10 ROUGH GRINDING

When a profile is first ground into a set of cutter blanks, it is necessary to 'rough out' in order to remove the majority of the material.

Always set the grinding wheel vertical when grinding out large amounts so that pressure is applied only to the rim of the grinding wheel.

When roughing out a nibbling action is adopted, i.e. a series of parallel plunging cuts directly into the grinding wheel, to form a series of close slots. Avoid unnecessary sideways movement as excessive side pressure can cause wheel breakage.



When grinding solid H.S.S. or T.C.T. cutters deep plunge grinding can cause excessive burning of the cutters. In addition, it can cause wear to the side of the wheel, causing it to become thirmer than the stylus, resulting in insufficient material being ground off the cutters.

A combination of plunging and nibbling movements can therefore be used:



1) Shallow plunge grind.



2) Nibble across.



3) Continue with a combination of plunging and nibbling until the full profile depth is achieved.

For deep shoulder sections it is advisable to rough out the majority of the material before grinding the profile to its full width.

When first using the profile grinder it may be an advantage to set the template to small grinding depth (say 3mm). Grind this out, then step back the template by a further 3 mm to allow more grinding. Continue this procedure until the cutter is fully profiled. By using the template in this way a grind limiter is set, so allowing only a small amount to be ground off the cutter at any setting. This allows for more control so enabling confidence to be gained quickly.

Note : In cases where a cutterhead has several knives it is advantageous to 'rough out' all the knives at a single template setting. This procedure will necessitate frequent wheel dressing.

4.15

SECTION 4

All the knives on the cutterhead should be roughed out and the wheel re-dressed to re-establish the fixed datum. A small amount is then ground from each knife without adjusting the template position to ensure that all the knives are ground equally prior to finish grinding.

The optional variable speed facility enables the optimum grinding speed to be found for any type of tool steel. By increasing the grind speed, a given composition of grinding wheel will seem to behave harder and be less likely to breakdown. This can be useful when grinding delicate profiles where good form retention by the grinding wheel is required. Similarly, by reducing the grind speed, the wheel will seem softer and breakdown more quickly, thereby being less prone to glazing.

As the wheel diameter reduces, the spindle speed can be increased to maintain a constant surface speed at the point of grind and so maintain constant cutting conditions.



4.11 FINISH GRINDING

Once the rough grinding is completed an all of the cutters, the wheel should be dressed again to reestablish the datum. If desired, the template may be wound slightly back off the stylus to increase the amount to be ground off the cutters. The cutter can be finish ground using the soft roughing wheel (usually a 60 grit). As the finish cut is very small almost no wear will take place, therefore, all of the cutters are of the same shape and as near as possible in the same projection radially.

A finishing wheel (usually a 220 grit) is harder and less free cutting than a roughing wheel, however, they are less subject to wear and so retain their shape much longer. They are therefore ideally suited for producing very fine detail, or square corners, on the cutter. Fig.4i Finishing square corners

Generally, a round nosed shape will be used for grinding operations, however, any square corners which are required on the cutter will need the use of a squared off face on the stylus. The stylus is thus selected and the 60 grit wheel replaced with a 220 grit finishing wheel. By dressing the wheel square the fixed datum point is achieved, and this allows the stylus to be just touched into the square corners on the template, and the wheel only removes the small radii in the corner left by the round nosed wheel. By dressing the wheel the depth of cut is automatically aligned to the previous depth, so ensuring that neither a small step nor an undercut is left on the previously ground edge.

This procedure applies to all fine detailed work. The only point to remember is to ensure that the wheel is dressed to the exact shape and size of the stylus selected.

4.16

SECTION 4

4.12 SIDE RELIEF

The grinding of the cutters should now be complete except where side relief is required.

The head should be tilted, either to the left or the right, using the handwheel [1] to the right of the head and set to the scale [2] which is graduated from 0° to 15° in both directions. If the machine is provided with a powered head tilt the head should be tilted, either to the left or the right, using the arrowed buttons on the control panel and set to the scale.

The wheel should be dressed to suit the stylus shape and to restore the automatic datum.

Note : When dressing the wheel for side relief :

a) A bull nose should be shaped <u>BEFORE</u> the wheel is tilted over to the left or right.

b) A square face should be shaped AFTER tilting.

The areas requiring side relief should be located on the template and the back of the knife ground away without grinding deeper at the cutting edge. It will be found that the side relief will only be formed part way down the back of the knife. This is to prevent inadvertently removing material from the cutting edges. If side clearance is required to be generated right up to the cutting edges then this can be achieved by sideways adjustment of the template.

All knives are ground to give clearance on, say, the right hand side and then the whole operation is repeated with the wheel tilted to the left hand side. This ensures all areas of the profile at 90° to the cutting action are given the required relief.

The cutters should now be complete. Any grinding burr should be removed from the cutters to achieve the best cutting edge. The cutterhead, complete with profiled cutters, can now be mounted directly onto the moulding machine and run without further operation.



Fig. 4j

4 17

SECTION 4

4.13 MEASURING

If measurement of the ground cutters is necessary with the cutterhead still on the machine, the carriage should be moved to a position well away from the grinding wheel. The machine should be switched off and the wheel allowed to come to a standstill before measuring is carried out.

It may be necessary to 'stone' the cutter to remove grinding burns in order to achieve an accurate measurement.

Setting and measuring stands are available from Wadkin which are designed to accept the grinding machine arbor. This allows the cutterhead to be quickly transferred from machine to stand and visaversa without removing the cutterhead from the arbor. Contact Wadkin for full details.

4.14 ARBOR COUNTER BALANCE (OPTIONAL EXTRA)

A counter balance can be supplied by Wadkin (see Appendix A5) for use with both profile and straight knife grinding.



Fig. 4k

The counter balance is mounted onto the plain arbor handle. With the cutter located on the cutter rest the counter balance is locked to the arbor handle to maintain the cutter in its located position. This allows the operator to control the carriage movement without having to control the arbor rotation as well.

4.15 CUTTER RESTS

A 25mm wide hardened steel cutter rest is ideal for most cutters. It is important to keep this in good condition as described in Section 1.4.

A tungsten carbide cutter rest is supplied on some machines to give an increased wear life.



Fig.4I Carbide Cutter Rest

Replacement carbide tips can be supplied by Wadkin. The tip [1] is released by loosening the two clamp screws [2]. Make sure that the seating is clean when fitting the new tip.

Other special cutter rests are available as described in Appendix A5.

4 18

4.16 GRINDING SEGMENTAL TOOLING

Segmental and Tena-Disc tooling can be ground using the same method as that used for profile grinding.

In some cases the standard 25mm wide cutter rest will be too wide for these types of cutterheads. Special narrow cutter rests are available from Wadkin to overcome this problem. See Appendix A5.

Some segmental blocks include overlapping profiles that cannot be ground in situ. In these cases a longer sleeve can be used with spacing collars [S] to make up the additional length. When grinding is carried out, the spacing collars are used to spread the block segments apart by a known amount thereby eliminating the overlap.

The template is made to suit [X+S] and may include undercuts as shown to allow square shoulders to be ground using the round nosed wheel



www.DaltonsWadkin.com

4.19

.....

SECTION 4

4.17 GRINDING PLANERHEADS

Straight knife grinding of planerheads can be carried out using exactly the same method as that for profile grinding, except that in this case the template profile is straight.

The accuracy of this method depends on the straightness of the template. A special 'trued' template is available from Wadkin together with a ball bearing stylus that reduces wear on both the template and stylus. NOTE: A trued template is normally supplied with machines that do not have carriage locks.

A special C.B.N. (Borazon) grinding wheel is also available for straight knife grinding which eliminates any inaccuracies due to wheel wear that can occur when using the normal softer aluminium oxide bonded grit wheels. See Appendix A5.

Straight knife grinding can be carried out using the same grinding wheel as used for profile grinding. A round nosed shape should be dressed on the wheel before the carriage is set.

Knives are set into the planerhead ' off machine'. If this is done on a Wadkin setting stand the planerhead and arbor can be transferred directly to the grinding machine.

The planerheads are mounted on to the arbor as for profile cutterheads described in section 4.4 making sure that the knives are correctly orientated to suit the cutter rest.

If the machine is fitted with optional carriage locks, templates are not required. The accuracy of the grinding is generated by the accuracy of the machine slideways.

CARRIAGE LOCKS



The lower carriage lock [1] is used to lock the left / right carriage movement. The upper carriage lock [2] is used to lock the in / out movement and is fitted with a graduated fine adjustment screw [3] and pointer [4].

When straight knife grinding is carried out the in / out movement is locked and progressive grinding cuts are made using the fine adjustment screw [3] (unlike profile grinding where cuts are made by moving the template slide).

When the machine is set up prior to grinding, the pointer [4] can be rotated to a suitable position by releasing the pointer locking screw using a 3 mm A/F allen key. Each graduation represents 0.02 mm (0.0008").

The in / out movement should be locked when the knife is correctly positioned on the cutter rest just clear of the wheel.

4.20

www.DaltonsWadkin.com

OPERATION

SECTION 4

GRINDING WITH LOCKS

With one axis locked, the carriage is free to move in the left / right axis only. The carriage should be moved to the left where the arbor is free to rotate.

Check that the wheel, guards, cutters etc. are correctly positioned and locked, and start the wheel and coolant. Adjust the coolant flow if required.

Control of the arbor rotation and carriage movement is carried out in the same way as for profile grinding. The cutter should be moved to the right to locate the knife on the cutter rest. The arbor should be controlled to keep the knife in contact with the cutter rest throughout the grinding pass.

The arbor is then rotated and the second knife located and ground in the same way. Always grind all knives in the planerhead before altering the cut. When grinding a planerhead with freshly set knives it is advisable to check that all knives pass the wheel in case some knives have a larger projection than others.

The depth of cut is adjusted using the fine adjustment screw [3] (*Fig. 4nl*). Each graduation represents 0.02 mm. Do not attempt to take too much off in one pass - it is better to take a series of lighter cuts.

Roughing cuts are progressively taken until all knives are cleaned up and hence brought to a concentric cutting circle.

When a normal aluminium oxide wheel is used dressing should be carried out before the finishing cut is made and during roughing, if required. Dressing should only be carried out when all knives have been ground to a particular setting. The carriage lock is released, the wheel dressed, the knife re-set to the wheel and the carriage re-locked.

To finish off the planerhead a lighter finishing cut of can be used. The speed at which the knife is moved past the wheel should be reduced to ensure that a good surface finish is produced on the ground knife. Note : A good surface finish on the back of the knife will produce a stronger, longer lasting cutting edge by eliminating microscopic irregularities on the cutting edge.

Additional accuracy can be achieved by sparkingout. This is carried out by passing the knives across the wheel again but with <u>NO</u> adjustment to the depth of cut.

The planerhead should then be complete. Any grinding burr should be removed by careful stoning to achieve the best cutting edge taking care not to alter the cutting edge itself.

4.21

www.DaltonsWadkin.com

SECTION 4

4.18 CARE OF THE MACHINE

The machine should be cleaned down when grinding is finished. The abrasive dust produced by the grinding operation can cause damage to moving parts and slideways if cleaning is not carried out correctly.

COMPRESSED AIR SHOULD NOT BE USED

to assist cleaning. It can cause abrasive dust and coolant to be forced into slides, screws and bearing surfaces. It can also be dangerous to other people.

A flow of coolant can be used to wash the machine but <u>ONLY ON THE AREAS WHERE COOLANT</u> <u>NORMALLY FLOWS</u> during grinding. If a coolant flow is used, the following guidelines must be observed :-

- Coolant must not be sprayed onto electric motors. These are splashproof but are <u>not</u> designed to withstand constant jets of coolant.
- Coolant must not be sprayed under covers or into slides, screws, bearings etc.
- Coolant should not be used to simply wash all the grinding debris down into the tank - this only leads to more frequent cleaning of the tank.

Accumulations of grinding debris should be scooped out of the coolant trays. It is a matter of personal choice as to whether this is better done with the debris wet or dry.

If the metal filtration magnets are correctly placed in the coolant tray, they should be visible to the operator. They should be cleaned when necessary.

The level of coolant in the system should be 'topped up' as necessary. (See Appendix A2.) A level indicator is fitted to the coolant tank. The coolant should be allowed time to drain into the tank before the reading is taken. Note : Different types of coolant fluid should not be mixed together, see maintenance section 5.



4,22

SECTION 5

SECTION 5 : MAINTENANCE

5.1 SAFETY

The machine should always be electrically isolated when maintenance is carried out unless specifically required otherwise.

Maintenance personnel should be familiar with the Health and Safety precautions for handling coolant fluids. See Appendices A2 and A3.

Maintenance personnel should not mount grinding wheels unless specifically trained to do so.

5.2 CLEANING THE MACHINE

Cleaning should be carried out on a regular basis as part of the normal operation of the machine (see section 4.18). During machine maintenance any shortcomings should be made good by thorough cleaning.

COMPRESSED AIR SHOULD NOT BEUSED ...

for cleaning the machine. It can cause the abrasive dust and grit produced during grinding to be forced into slides, screws and bearings etc. A flow of coolant can be used to wash the machine but <u>ONLY ON THE AREAS WHERE COOLANT</u> NORMALLY FLOWS. (See section 4.18).

5.3 LUBRICATION

The machine is designed to require minimum lubrication. The grinding spindles, motors, coolant pump and carriage slideways are fitted with sealed bearings which require no additional lubrication. Note : The carriage slideway bearings are fitted with lubrication points. These are not intended to be regularly lubricated. If the carriage is dismantled at any time, these bearings can be lightly regreased.

.

. . . .

.....

If too much grease is applied, the carriage movement can become very stiff, making the machine difficult to operate.

All bushes employed are of the 'bronze oil retaining type'. Slides and screws should be examined periodically with careful attention paid to any moving parts that become stiff.

Accessible slides, screws, bushes etc. should be lubricated weekly with Wadkin grade L4 oil. A list of approved lubricants is given in Appendix A1.

On a monthly basis, one shot of grease (Wadkin L6) should be applied to the head tilt screw/nut lubrication point which is located towards the rear of the main head support (see Fig 6n, item 16).

5.4 WHEEL MOUNTINGS AND GUARDS

It is essential for the safe operation of this machine that the wheel mountings and wheel guards are maintained in good condition. The grinding spindle ends should run true and be free from burrs. The wheel flanges should be flat and free from burrs. The spindle nuts should be in good condition.

The wheel guards must be intact with no cracked welds. The profile guard door including the hinge and latch should be in good condition and the fixing of the guards should be solid.

These items should be checked whenever wheels are mounted but particularly if a wheel should disintegrate. If any of these items are worn or damaged they should be replaced.

5.1.

SECTION 5

5.5 COOLANT SYSTEM

Topping up of the coolant system and evaporation over a period of time can affect the dilution of the mixture. This should be checked using a refractometer, which can be supplied by Wadkin (see Appendix A5). As a general guide the mixture should be checked and corrected if necessary every 1 to 2 months.

The useful life of the coolant mixture is dependent on various factors such as the amount of use, type of wheels used, cleaning down practice etc. As a general guide the coolant should be replaced every 4 to 6 months.

The machine should be thoroughly cleaned down and drained of coolant. The coolant should be disposed of as per Appendix A2.

The tank can be removed from the machine more easily when the coolant is at a low level. Some machines are provided with a washdown/pump-out facility which is provided for emptying the coolant tank. Located in the coolant compartment (*Fig 3a*) is a coiled pipe [6], the end of which should be placed in a bucket or other suitable container. With the tap [5] switched over, the coolant pump can be started to pump the fluid out of the tank. The tank can be withdrawn and tilted to pump out lower levels, but take care not to pump sediment.

The system should be cleansed with an antibacterial cleaning fluid when required. Details of the anti-bacterial solution supplied by Wadkin are given in Appendix A3.

Important : If coolant fluids are used other than those supplied by Wadkin, the Health and Safety recommendations supplied with the fluid should be strictly followed.

Different types of coolant fluid should not be mixed together. When changing supply, the system should be thoroughly drained and cleaned before refilling with the new coolant.

5.6 ELECTRICAL SYSTEM

All electrical maintenance work should be carried out by a competent electrician.

The electrical circuit diagram is included at the end of this manual - see Appendix A6. A copy of the circuit diagram for the machine together with a separate instruction manual and wiring diagram for the inverter (variable speed unit) (if fitted), should be enclosed with the machine documentation inside the electrical control cabinet.

Routine maintenance of the electrical system is not necessary other than to check the condition of the controls and worklamp. Any damaged control buttons etc, or detective bulbs should be replaced.

5.7 MACHINE ALIGNMENTS

There are a number of alignments and checks which are built into the machine from new and <u>MUST</u> be re-set whenever parts are dismantled and re-built. The following alignments should be set by a competent engineer.

.

MAINTENANCE

SECTION 5

CARRIAGE



www.DaltonsWadkin.com

5.3

SECTION 5



SECTION 5

TEMPLATE SLIDE

.

.



5.5

.....

.

SECTION 5

HEAD PIVOT AND CUTTER REST



SECTION 5

ł



.

.

SECTION 5

DRESSER

. .

.



www.DaltonsWadkin.com

.

5.8

•

MAINTENANCE

SECTION 5



•

SECTION 5

ţ



SECTION 6

SECTION 6 : ILLUSTRATED PARTS LIST

Should it become necessary to replace worn or damaged parts of the machine, it is essential that the work is carried out by a competent engineer in order to maintain the grinding accuracy of the machine. Alignments <u>MUST</u> be re-set as described in section 5.7.

Always quote the Machine No. and Test No. when ordering spare parts from Wadkin. This information is marked on the machine nameplate.

6:1

.....

١

SECTION 6



.

DRESSER (Fig. 6a)

ļ

<u>ITEM</u>	QTY	PART No.	DESCRIPTION
1	1	T3005120	Bush
2	1	NN 332	Pivot Pin
3	2	T3053109	M15 locknut
4	1	NN 337	Locking knob
5	1	K3005681	Spring plunger unit
6	1	NN 336	Dresser handle
7	1	T3041252	Ball knob
8	1	NXU 523	Graduated dial
9	1	K0527102	M8 nut
10	1	NXU 522	Diamond dresser
11	1	NN 327	Mounting
12	1	K0604142	Thrust bearing 51102
13	1	NN 335	Pivot pin
14	1	NN 331	Location disc
15	2	K3005163	Bush
16	1	K0604138	Thrust bearing 51106
17	4	TEO 350	M7 tapered capscrew
18	1	NN 140	Dresser scale
19	1	NN 334	Pivot bracket
20	1	NN 148	Arm extension
21	Nº 1	NN 333	Dresser arm
22	S ¹	T3005341	Thrust washer

...

ومترجمية فالمتحا والمتحاف والمروان والمروبية المروبين والمراجع والمراجع

.

..... 6.3....

· ······

-- -- ----

• - •

SECTION 6

DRESSER LOCATION/LOCK (Fig. 6b)

• .

<u>ITEM</u>	<u>QTY</u>	PART No.	DESCRIPTION
4	4		
1	1 A	ININ 320	End stop screw
Z	1	KU527111	M12 locknut
3	1	K3005104	Bush
4	1	K0526541	M10 x 40 dog screw
5	1	K0527110	M10 locknut
6	1	K0526268	M10 x 55 stud
7	1	K5127139	Knob
8	1	NN 329	Threaded lock
9	1	NN 330	Plain lock
10	1	K0526240	M8 x 60 stud
11	1	K5127197	Handlever
			$\langle O \rangle$
		<u> </u>	
		S	•
		.xO`	
		\sim	
		\checkmark	
	4	*	
	12		

6.5

SECTION 6



SECTION 6

TEMPLATE CROSSLIDE (Fig. 6g)

<u>ITEM</u>	QTY	PART No.	DESCRIPTION	
1	1	K0530257	Handwheel	
2	1	K0528205	Plain collar	
3	NOTE:	There are 2 ty	pes of item 3 :-	
	either	MPG 20	Graduated dial	
	or	K0528205	Plain collar	
4	1	NN 343	Screw mounting	
5	2	K0531302	Bush	
6	· 1	NN 325	Adjucting screw	
7	1	NN 340	Crosslide	
8	2	K0531589	Bush	
9	1	NN 120	Crossslide	
		S	7.0	
		HOM		
	<	2 01		
	N.			
Nr				

SECTION 6

ì.



SECTION 6

ŧ

:

DIAL INDICATORS (Fig. 6h)

<u>ITEM</u>	QTY	PART No.	DESCRIPTION
1	2	K0525502	Hex hd screw M6 x 16
2	1	K0526208	Slud M6 x 45
3	4	K0527108	hex lock nut M6
4	2	K0528102	Washer M6
5	2	K3025455	Dial Indicator
6	2	K3025456	Post back for dial indicator
7	4	K3089202	M12 thin washer
8	2	NN 155	D.T.I. actuator
9	1	NN 344	Plate for D.T.J.
10	1	NN 347	Spacer for D.T.I. lock
11	1	NN 348	Stud for D.T.I. lock
12	2	T3053101	M6 thumb screw
		S	•
		,×0 ¹	
	A	•	
	N.		

www.DaltonsWadkin.com

PARTS LISTS

SECTION 6

<u>Fig. 6i Carriage</u>



SECTION 6

CARRIAGE (Fig.6i)

ITEM	QTY	PARTI	<u>No.</u>	DESCRIPTION
,		A (A)	50	Conversion to an
1	1		92	
2	1	NN 1	109	Arbor support base
3	1	NN 1	128	Arbor post LH
4	1	NN 1	29	Arbor post RH
5	6	K05251	190	Hex skt capscrew m8 x 35 mm
6	4	K0525 [,]	193	Hex skt capscrew m8 x 50 mm
7	4	K05253	323	Hex skt countersunk screw m6 x 10 mm
	MMM	Daltor	5	vadin

6.19



SECTION 6

I.

CARRIAGE (Fig. 6/)

<u>ITEM</u>	<u>QTY</u>	PART No.	DESCRIPTION
	4		
1	1	NN 9	Spiasn guard
2	1	NN 39	Carraige plate
3	1	NN 40	Carraige mid plate
4	2	NN 41	Carraige bearing strip
5	2	T3005653	Swing bolt m8 x 50 mm x 8 bore
6	52	K0525144	Hex hd capscrew m5 x 16mm
7	8	K0525145	Hex hd capscrew m5 x 20mm
8	2	K0525514	Hex hd screw m8 x 12mm
9	2	K0528103	wasker 8 mm
10	2	K0529145	Plain dowel 8 mm x 30 mm
11	2	K0530320	Handwheel 50 mm thread 8 mm No 141
12	2	K0607180	Linear bearing assembly. 460 lg
13	2	K0607181	Linear bearing assembly. 820 lg
		S	
		,xO	
		~ 0	
		\checkmark	
		•	
	N.		
	11-		
	5		
	,		

SECTION 6



ł

PARTS LISTS

SECTION 6

CARRIAGE - ARBO	OR LOCATI	ON (Fig. 6	<u>k)</u>
ITEM	QTY	PART No.	DESCRIPTION
1	1	NN 133	Arbor location key
2	1	K0525122	Hex skt capscrew M4 x 12 mm
3	2	K0526144	Grubscrew M6 x 10 mm
4	1	K0525310	Hex skt csk screw M4 x 12 mm
5	1	NHP 346	Arbor shell
6	1	NN 131	Arbor clamp (37 dia.)
7	1	NN 130	Arbor clamp (47 dia.
Alternative parts to s	suit 28 dia. :	arbor bearings :-	dkin
4	1	K0525122	Hex skt capscrew M4 x 12 mm
5	1	NXU 189	Shell
6	1	NN 132	Arbor clamp (28 dia.)
	NNN	Dalton	

-

.

.

.

....




CARRIAGE LOCKS (Fig. 6/)

ITEM	QTY	PART No.	DESCRIPTION
1	1	NN 11	Cover plate (carriage locks)
2	2	NN 18	Locking pad
3	1	NN 25	Graduated cut adjuster
4	1	NN 26	Scale pointer ring
5	1	NN 27	Lock shaft
6	1	NN 28	Eccentric lock
7	1	NN 29	Lock adjusting block
8	1	NN 30	Lock block
9	2	NN 31	Shaft support plate
10	1	NN 32	Lock plate
11	1	NN 33	Short lock strip
12	1	NN 34	Locking block
13	1	NN 35	Lock screw
14	1	NN 87	Carriage lock bracket
15	1	NXU 186	Lower slide lock strip
16	5	K0520504	Taper pin No1 11/64 x 1 1/4
17	2	K0525324	Hex skt csk screw M6 x 12 mm
18	6	K0525501	Hex hd screw M6 x 12 mm
19	7	K0525502	Hex hd screw M6 x 16 mm
20	4	K0525504	Hex hd screw M6 x 25 mm
21	4	K0525514	Hex hd screw M8 x 12 mm
22	1	K0526112	Hex skt M6 x 6 mm
23	2	K0527102	Hex full nut 8 mm
24	8	K0528102	Washer 6 mm
25	4	K0528103	Washer 8 mm
26	2	K0528207	Collar 12 mm dia.
27	2	K0530257	Handwheel 55 mm x 12 bore
28	2	K0531320	24 Fl.Bush 12 B x 18 OD x 12 lg
29	2	K0531526	Bush 12 x 16 x 12

SECTION 6

6.25

www.DaltonsWadkin.com

SECTION 6



6,26

SECTION 6

I.

.

JAL HEAD 1	<u>ILT ASSEME</u>	LY	(Fig	<u>g. 6m)</u>	
<u>ITEM</u>	QTY	PART	<u>No.</u>	DESCRIPTION	
1	1	K0950	105	Nipple	
2	1	NN	217	Adj. Nut for head cant	
3	1	NN	322	Adj. screw	
4	1	K0528	209	Collar	
5	1	NN 2	218	Adj. screw mount for cant	
6	1	NXU S	316	Collar	
7	1	NXU 4	424	Handwheel	
· 8	ť	K0604	133	Thrust bearing	
9	1	NN 3	323	Scale mounting	
10	1	NN 2	275	Cant scale	
11	1	NN 3	324	Pointer Mounting	
12	1	NN 2	288	Pointer for scale	
			C		
•			Ň		
		, xO			
	•	\sim			
	~	\mathbf{N}			
	2				

MANUAL HEAD TILT ASSEMBLY

6.27

www.DaltonsWadkin.com

SECTION 6

5

.........



•

SECTION 6

RED HEAL	D TILT ASSEMBLY		(Fig.	<u>6n)</u>
ITEM	QTY	PAR	<u>T No.</u>	DESCRIPTION
1	1	NN	217	Adj. nut for head cant
2	1	NN	218	Adj. screw mount for cant
3	1	NN	223	Cant adjusting screw
4	1	ΝN	262	Bracket for cant motor
5	1	NN	263	Bracket for cant motor
6	1	ΝN	264	Coupling for cant motor
7	1	ΝN	272	Bracket for limit switch
8	4	NXU	S0033	Limit switch
9	1	NN	276	Scale mounting
10	1	NN	275	Cant scale
11	1	K052	28209	Collar
12	1	k060	4133	Thrust bearing
13	1	K131	14346	Geared motor (380 - 440v) - CHECK VOLTAGE
14	1	NN	277	Pointer mounting
15	1	NN	288	Pointer for scale
16	1	K098	50105	Nipple
	\sim	0		
)		
	N.			
	n.			·
	N			
	ITEM 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	ITEM QTY 1 1 2 1 3 1 4 1 5 1 6 1 7 1 8 4 9 1 10 1 11 1 12 1 13 1 14 1 15 1 16 1 17 1 8 4 9 1 10 1 11 1 12 1 13 1 14 1 15 1 16 1 MMMM MMM	ITEM OTY PAR 1 1 NN 2 1 NN 3 1 NN 4 1 NN 5 1 NN 6 1 NN 8 4 NXU 9 1 NN 10 1 NN 11 1 K052 12 1 k060 13 1 K13* 14 1 NN 16 1 K094	RED HEAD TILT ASSEMBLY (Fig. ITEM QTY PART No. 1 1 NN 217 2 1 NN 218 3 1 NN 223 4 1 NN 262 5 1 NN 263 6 1 NN 264 7 1 NN 272 8 4 NXUS0033 9 1 NN 275 10 1 NN 275 11 1 K0528209 12 1 k0604133 13 1 K1314346 14 1 NN 277 15 1 NN 288 16 1 K0950105

6.29

.....

....

......

.....

SECTION 6

Ç,

Fig. 6p Head Main Pivot Shaft



6.30

www.DaltonsWadkin.com

SECTION 6

.

l

AD MAIN PIVOT SHAFT			<u>(Fig. 6p)</u>		
ITEN	<u>1 Q</u>	TY	PART	<u>No.</u>	DESCRIPTION
1		1	NN	226	Pivot shaft for head
2		1	K0526	6149	Grubscrew M12 x 16
3		2	T3062	2303	Nylon hole plug 25.5 mm
4	:	2	K0520	0480	Tension pin 4 x 12
5	:	2	K0527	7209	Notch nut M40 x 1.5
6		2	K0531	592	Bush 40 x 46 x 30
7		1	K0610	256	AS-4060 INA Thrust washer
8	:	2	K3005	5328	SKF GLYPX G426601.5 bearing
	- An	ww.Do		ns h	adk

6.31



HEAD SLIDE AND CUTTER REST

ITEM

11 12

|--|

<u>EM</u>	<u>QTY</u>	PART	No.	DESCRIPTION
1	1	NE	79	Coolant pipe clip
2	1	NN	215	Tool rest mounting
3	1	NN	216	Dresser location
4	1	NN	225	Head vertical adj. nut
5	2	NN	227	Slide strip
6	1	NN	228	Slide lock strip
7	1	NN	268	Main pivot slide
8	1	NN	270	Main head mount
9	1	NN	286	Clearance angle scale
1 0 ·	1			Cutter rest (see appendix A5)
11	4	K0528	5518	Hex hd screw M8 x 30 mm
12	4	K0528	6128	Skt set screw M8 x 20 mm cup
				N.O.
•			6	
			~)
		. x O		
		10		
	S.			
	A.			
	N			
	*			

www.DaltonsWadkin.com

.

SECTION 6

7

.

. .

SINGLE	STYLUS.	ASSEMBLY	(Fig.	<u>6c)</u>	
	<u>ITEM</u>	QTY	PAR	<u>T No.</u>	DESCRIPTION
	1	1	K052	5472	Brass pad
	2	3	K052	5473	Brass pad
	3	1	K052	6265	M10 stud
	4	3	K052	6489	M12 dog screw
	5	3	K052	7111	M12 locknut
	6	1	K512	7198	M10 handlever
	7	1	K052	8105	M12 washer
	8	1	NX	40	Stylus
	9	1	K300	9931	'E' retainer
	10	1	K052	5165	M6 capscrew
	11	1	NN	352	Beilows
	1 2	1	NN	351	Bellows retainer
	13	1	NN	314	Housing
	14	1	K300	5165	Bush
	15	1	NN	350	Siylus bar
	16	1	K301	0162	Circlip
			()		
		2			
		N			
		N			
	•	2			

6.7

•

.

. . . .

,

. .



www.DaltonsWadkin.com

SECTION 6

HEAD ASSEMBLY (Fig. 6r)

<u>ITEM</u>	<u>QTY</u>	<u>PART N</u>	Io. DESCRIPTION
1	1	K13041	29 Profile spindle motor
2	1	NE (90 Wheel guard (profile)
3	1	K30532	64 M8 Coilar nut
4	1	T30056	53 M8 Swing bolt
5	1	NN 29	90 Fixed wheel flange
6	1	NN 29	91 Front wheel flange
7	1	NXU 34	41 Locking washer
8	1	K05271	05 M16 Spindle nut
	MMM	Daitor	swadkill'

6,35

........



www.DaltonsWadkin.com

ł

www.DaltonsWadkin.com

SECTION 6

HEAD ADJUSTMENT	SCREWS	<u>(Fig. 6s)</u>	
ITEM	QTY	PART No.	DESCRIPTION
1	1	NE 29	Handwheel support
2	1	NN 224	Rise and fall screw
3	1	NN 229	Mounting block
4	1	NN 236	Shaft - Handwheel to universal joint
5	1	NN 237	Shaft - universal joint to pulley
6	2	NXU 424	Handwheel
7	4	K0528207	Loose collar
8	4	K0531302	Flanged bush
9	1	K3078774	Taper lock bush
10	1	K3078776	Pulley
11	1	K3078777	Timing belt
12	1	T3009772	Universal joint
		1	NO.
		~	
		\mathcal{V}	
	\frown^{0}		
	N.		
	2		•
	•		

6.37

.

SECTION 6

·····

Fig. 6t Head Adjustment



6-38----

.

.....

SECTION 6

HEAD ADJUSTMENT (Fig. 6t)

<u>ITEM</u>	<u>QTY</u>	PART No.	DESCRIPTION
1	1	NN 230	Screw plate
2	1	NN 238	Adjusting screw
3	1	NN 239	Mounting shaft
4	2	NN 240	Locking plate
5	2	NN 241	Motor mounting bracket
6	1	NN 242	Profile head mount
7	2	K0527110	M10 Locknut
8	1	K0528207	Loose collar
9	2	K0531302	Flanged bush
10	2	K0531592	Bush 40 x 46 x 30
11	1	K3078775	Pulley
12	1	K3078777	Timing belt
13	1	K5127198	M10 Locking handle
14	1	T3033103	M12 Thread insert
		~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	
		·×O`	
		$\sim$	
		$\mathbf{\nabla}$	
	12.	•	
	N		
	N		

# APPROVED LUBRICANTS

Wadkin	B.P.	Caltex	Castrol	Esso	Gulf	Mobil	Shell
L1	Energol HLP 32	Rando	Hyspin AWS 32	Nuto H32 43 AW	Harmony Oil HDA	DTE oil Light 24	Tellus 37
L2	Energol HP 150	URSA P40	Alpha ZN 150	Spartan EP 150 Heavy	Service 13	Vactra Extra	Vitrea 150 or CS 150
L4	Energol HP 68	URSA P20	Magna 68	Norray 68 Heavy Medium	Service 51	Vactral Oil	Vitrea 68 or CS 68
L6	Energrease LS 3	Regal Startak Premium 3	Spheeroi AP3	Beacon 3	Gulfcrown Grease No. 3	Mobilplex Grease No. 48	Alvania Grease No. 3
· · ·	MAN	И.					

L1 Oil	Hydraulic oil with anti-corrosion, anti-oxidation, anti-wear, anti-foam performance.
L2 Oil	Gear oil (viscosity 150 centi-stokes at 40 degrees C).
L3 Oil	Plain mineral oil (viscosily 68 centi-stokes at 40 degrees C.)
L6 Grease	Grease NLG1 No.3 consistency lithium bearing grease.

i

. .. .

A1.1

# NXT 138 GRINDING COOLANT

IMPORTANT : The following information is reproduced for reference only. When handling coolant from <u>ANY</u> supplier <u>ALWAYS</u> use the data sheets provided with the product.

#### APPLICATION

The recommended dilution for use on this machine is 2% by volume (i.e. 50 : 1 water to coolant ratio).

Measure (do not guess) the required volume of water into a <u>clean</u> coolant tank or other suitable container.

Calculate the volume of coolant concentrate required. For example 30 litres of water would require 0.6 litres of coolant concentrate.

Always mix the emulsion by introducing the concentrate gradually to water. Continuously paddle the emulsion during mixing, circulating the fluid from bottom to top. Care should be taken to ensure that the emulsion is properly formed. Fallure to do so may result in an emulsion of water in oil rather than oil in water. If an emulsion of water in oil is formed then it will have none of the properties normally expected of the coolant, and will lead to rapid rusting.

POINTS TO REMEMBER :-

- Always add the coolant to water <u>NEVER</u> vice versa.
- DON'T prepare coolant mixtures by guesswork
   measure all quantities.
- NEVER pour the coolant concentrate into the water too quickly. It must be mixed in at a steady rate to achieve a stable emulsion.
- <u>DON'T</u> use dirty, saline, or hard water. Rain water is only acceptable if clean and free from debris.
- <u>DON'T</u> use dirty, rusted, galvanised or "old-oil" contaminated buckets etc.
- <u>NEVER</u> try to mix the coolant using the coolant pump.

# TYPICAL PHYSICAL CHARACTERISTICS

Concentrate :

Appearance - Amber

### Relative density - 1,002 gm/cm³

Translucent / white

liquid.

9.1 - 9.4

www.Dat

at 20°C

Emuision :

Appearance

pH at 3%

concentration Refractometer

Factor

### TOPPING UP

If it is found necessary to 'top up' the coolant tank at a later stage, allowance should be made for water evaporation. This is necessary to prevent a gradual increase in fluid concentration. An approximate dilution of 1% by volume when 'topping up' will normally achieve this.

NEVER ADD NEAT COOLANT TO STRENGTHEN, OR JUST WATER TO WEAKEN, EMULSIONS THAT ARE ALREADY IN USE IN THE MACHINE.

Incorrect coolant strength <u>MUST ALWAYS</u> be compensated for by adding either a stronger or weaker <u>EMULSION</u> to the existing mix. Failure to observe this criteria is the cause of most aspects of poor coolant performance.

Remember to multiply direct refractometer readings by the refractive index of the product to gain the true coolant concentration figure.

NOTE : If the concentration should become too high, above a maximum of 10%, not only will the emulsion become unstable, but there is also the possibility of skin complaints among operators.

NOTE : Wadkin Plc reserve the right to change the type of cutting fluid supplied to our customers at any time. However, any changes of supply will be accompanied by the necessary safety data sheets.

A2.2

1:    The	Compar	ATION NY / UI	of thi Vdert/	e subs [.] Aking	TANCE	e / Pre	PARAT	ION AN	DOF			
Prod Appi Com Addi Telej	uct Name; ication: pany; ess: phone (24 ]	Hy Mete Cast Burn hours):	Iworking rol (U.K. 12h Castro 0793 5	fluid - Sol ) Limited )I House, I 512712	uble _. Sipers Wi	ay, Swin	don, Wilts	hire, SN3 Fax: 079	IRE 93 43287	Code:	7040	-UK
2: C	OMPOSIT	ION/I	FORM	ATION	ON IN	GRED	IENTS		0			
Com	position:	Highly 1	efined mi	neral oil, e	mulsific	rs and ad	ditives .		5	•		
Haza	rdous Ingr	edient(s	)	Sym	bol Ri	sk Phra	ses 🔹	Othe	r Infor	mation	%	
This p classif they a quant produ	roduct conta led as hazard re NOT pres ties to warra ct as hazardo	ins ingre lous, How ent in suf nt classif us	lients wever, ficient ying the			Ň	201				•	
All co Subst	nstituents of inces) or ELI	this prod NCS (Et	uct are lis ropean Li	ted in ED st of New	ECS (Er Chemica	ropean I I Süöstai	nventory of an	of Existing e exempt.	Comme	rcial Chen	nicel	—. 
Refer	to Section 8	for Occu	pational E	πposure L	imits.	•			•			
3: H	AZARDS	DENT	IFICAT	ION		•	•	•	٦	-		
This p	roduct is NC	T classi	ied as haz	ardous		<u> </u>	•		•			
4: Fl	RST AID	MEÀS	URES									
Eyes Skin: Inhal Inges	ation: Co	igate imm tain med ush thoro move fro tain med	nediately v ical attenti ughly with m exposu- ical attenti	with copion ion if irrits in soap and re- ion urgenti	us quanti ution pers water or iy. Do N	ties of w ists suitable fOT indu	ater for se skin clean ace yomitin	ser as soon	ies 1 as poss out mout	ble •	licr.	
5: FI	RE FIGH	TING I	MEASU	RES			-			•		
Suita Spec Spec	ble Exting al Exposu al Protecti	uishing te Haza ve Equi	Media: rds: pment:	Carb Nitro Self-	oon dioxi ogen con containe	de, powo pounds d breathi	ler, foam o ng apparat	r water fog us	; - Do no	n use wat	er jets	-
	•			·							•	
7	No: 01		Date: 0	1/04/1994	•	Code	: 7040-U	ζ.	Pag	e: 1 of 4	•	7

. ....

. . .

A2

ŧ

___

SECTION 6

Fig. 6d Stylus Turret Assembly



Personal Precautions:	Spilt product presents a significant slip hazard	
Environmental Precautions:	Prevent entry into drains, sewers and water courses	
Decontamination Procedures	: Soak up with inert absorbent or contain and remove by best availa means	ble .
7: HANDLING AND STOI	RAGE	
Handling: To avoid the possibil type must be avoided Avoid breathing spra	lity of skin disorders, repeated or prolonged contact with products on 1. It is essential to maintain a high standard of personal hygiene y mist	f this
Storage: Protect from frost. S	Store out of direct sunlight. Store between (°C): 5-50	
8: EXPOSURE CONTROL	S/PERSONAL PROTECTION	
Occupational Exposure Limi	ts:-	
Substance	8 Hr. TWA STEL Source/Other Informat	ion
Mineral oil (see Oil mist, mineral)	5mg/m ³ tong/m ³ BH40	•
Engineering Control Measur	es: Local exhaust ventilation is recommended. Mechanical metho minimise exposure must take precedence over personal protect	ds to ive
Personal Protective Equipme	ent: Safety glasses. Plastic apron. Wear impervious gloves (eg of case of repeated or prolonged contact.	PVC), in
Personal Protective Equipme 9: PHYSICAL AND CHEM	AICAL PROPERTIES.	PVC), in
Personal Protective Equipme 9: PHYSICAL AND CHEM	Liouid	PVC), in
Personal Protective Equipme 9: PHYSICAL AND CHEM Physical State: Colour:	Anter Liquid Amber	PVC), in
Personal Protective Equipme 9: PHYSICAL AND CHEA Physical State: Colour: Odour:	Amber Mild	PVC), in
Personal Protective Equipme 9: PHYSICAL AND CHEA Physical State: Colour: Odour: oH(concentrate):	Interstites. Interstites. Interstites. Interstites. Interstites. Interstites. Interstites. Interstites. Interstites. Liquid Amber Mild Not applicable	PVC), in
Personal Protective Equipme 9: PHYSICAL AND CHEA Physical State: Colour: Odour: pH(concentrate): pH(working dilution):	Amber Mild Not applicable 9 (5%)	PVC), in
Personal Protective Equipme 9: PHYSICAL AND CHEA Physical State: Colour: Odour: pH(concentrate): pH(working dilution): Boiling Point/Range (°C):	Anter Safety glasses. Plastic apron. Wear impervious gloves (eg of case of repeated or prolonged contact. Change contaminated clothing and clean before re-use AICAL PROPERTIES. Liquid Amber Mild Not applicable 9 (5%) Above 100	PVC), in
Personal Protective Equipme 9: PHYSICAL AND CHEA Physical State: Colour: Odour: pH(concentrate): pH(concentrate): pH(working dilution): Boiling Point/Range (°C): Flash Point (closed, °C):	Amber Mild Not applicable 9 (5%) Above 100 Abave 100	PVC), in
Personal Protective Equipme 9: PHYSICAL AND CHEA Physical State: Colour: Odour: pH(concentrate): pH(concentrate): pH(working dilution): Boiling Point/Range (°C): Flash Point (closed, °C): Autoignition (°C);	ent: Safety glasses. Plastic apron. Wear impervious gloves (eg of case of repeated or prolonged contact. Change contaminated clothing and elean before re-use AICAL PROPERTIES. Liquid Amber Mild Not applicable 9 (5%) Above 100 Above 100 Not determined	PVC), in
Personal Protective Equipme 9: PHYSICAL AND CHEA Physical State: Colour: Odour: pH(working dilution): Boiling Point/Range (°C): Flash Point (closed, °C): Autoignition (°C): Relative Density (at 20°C):	ntestites. ent: Safety glasses. Plastic apron. Wear impervious gloves (eg of case of repeated or prolonged contact. Change contaminated clothing and clean before re-use AICAL PROPERTIES. Liquid Amber Mild Not applicable 9 (5%) Above 100 Above 100 Not determined Below 1.0	PVC), in
Personal Protective Equipme 9: PHYSICAL AND CHEA Physical State: Colour: Odour: pH(concentrate): pH(working dilution): Boiling Point/Range (°C): Flash Point (closed, °C): Autoignition (°C); Relative Density (at 20°C): Water Solubility:	ntestites. ent: Safety glasses. Plastic apron. Wear impervious gloves (eg of case of repeated or prolonged contact. Change contaminated clothing and clean before re-use AICAL PROPERTIES. Liquid Amber Mild Not applicable 9 (5%) Above 100 Above 100 Not determined Below 1.0 Emulsifiable	PVC), in
Personal Protective Equipme 9: PHYSICAL AND CHEA Physical State: Colour: Odour: pH(working dilution): Boiling Point/Range (°C): Flash Point (closed, °C): Flash Point (closed, °C): Autoignition (°C): Relative Density (at 20°C): Water Solubility: Fat Solubility:	ntestites. ent: Safety glasses. Plastic apron. Wear impervious gloves (eg of case of repeated or prolonged contact. Change contaminated clothing and clean before re-use AICAL PROPERTIES. Liquid Amber Mild Not applicable 9 (5%) Above 100 Above 100 Not determined Below 1.0 Emulsifiable Not determined	PVC), in
Personal Protective Equipme P: PHYSICAL AND CHEA Physical State: Colour: Odour: pH(concentrate): pH(working dilution): Boiling Point/Range (°C): Flash Point (closed, °C): Autoignition (°C): Relative Density (at 20°C): Water Solubility: Fat Solubility: Fat Solubility: State Solubility: Fat Solubility: Fat Solubility:	ntestites. ent: Safety glasses. Plastic apron. Wear impervious gloves (eg of case of repeated or prolonged contact. Change contaminated clothing and clean before re-use AICAL PROPERTIES. Liquid Amber Mild Not applicable 9 (5%) Above 100 Above 100 Not determined Below 1.0 Emulsifiable Not determined	PVC), in
Personal Protective Equipme P: PHYSICAL AND CHEA Physical State: Colour: Odour: pH(concentrate): pH(working dilution): Boiling Point/Range (°C): Flash Point (closed, °C): Autoignition (°C): Relative Density (at 20°C): Water Solubility: Fat Solubility: Eat Solubility: Stability:	ntestries. ent: Safety glasses. Plastic apron. Wear impervious gloves (eg of case of repeated or prolonged contact. Change contaminated clothing and clean before re-use AICAL PROPERTIES. Liquid Amber Mild Not applicable 9 (5%) Above 100 Above 100 Not determined Below 1.0 Emulsifiable Not determined CCTIVITY.	PVC), in

A2

1

. . . . . .

.

. .

A2

·- ----

<ul> <li>Conditions to</li> </ul>	Avoid:	Tempera	itures (°C) above 60		
Materials to A	lvoid:	Strong o	xidising agents. Strong ac	ids.	•
Hazardous D	composition Prod	lucts: Nitrogen	a compounds		
11: TOXICO	LOGICAL INFO	DRMATION			,
The following to Expected oral L Not classified as	xicological assessme D50, rat > 2g/kg. E an eye or skin irritan	ut is based on a spected dermal : t	knowledge of the toxicity LD50, rabbit > 2g/kg.	of the product's components.	
Health Effec	ts	•			•
On Eyes:	May cause transient	t irritation			
On Skin:	May defat the skin			•	
By Inhalation	: Mist and vapours m	ay cause irritati	ion to nose and respiratory	tract	
By Ingestion:	May cause nausea,	vomiting and di	amhoea	0	
Chronic:	Repeated and prolo	nged skin conta	ct may lead to skin disorde	15	
Other:	None known	·	•	$\sim$	
12: ECOLO(	ICAL INFORM	ATION	2		
- Environmenta	l Åssessment:	May cause sig be used and d in this safety	gnificant ecological damage lisposed of in accordance w data sheet	e in aquatic systems and must ith the recommendations made	,
Mobility:		Mobile liquid	. Emulsifiable in water.		
Persistence an	d Degradability:	Not readily h	iodegradable		
Bioaccumulati	ve Potential:	Not determin	ed		
Ecotoxicity:		· Not determin	ed ·		
13: DISPOSA	L CONSIDERA	TIONS			
	in accordance with	ocal and nations	al legislation	· · · · · · · · · · · · · · · · · · ·	<del></del> .
Unused Produ	ct;	Dispose of thro	ugh an authorised waste co	ntractor to a licensed site	
Used/Contam	inated Product:	Diluted product an authorised w	may be separated by chem aste contractor	ical means before removal by	
Packaging:		For further into Must be dispose May be steam of	rmation see Section 16 ed of through an authorised leaned and recycled	waste contractor	
14: TRANSP	ORT INFORMA	TION		• • • • •	
			·		
This product is h	IOT classified as dan	gerous for trans	port		
15: REGULA	TORY INFORM	IATION	•	•	
Hazard Labe	l Data:-				
This product is N	IOT classified as dan	gerous for suppl	ly in the UK		
EC Directives	:	Fram	ework Waste Directive, 91	/156/BEC	
		wast(	e On Direcuye, 87/101/BE	lu -	
Issue No: 01	Date: 0	1/04/1994	Code: 7040-UK	Page: 3 of 4	
<b>L</b>	···-·	<u> </u>		· · · · ·	
		A2.5			

Statutory Instruments:

Codes of Practice: Guidance Notes: Health & Safety at Work, etc. Act 1974 Consumer Protection Act 1987 Environmental Protection Act 1990

Waste Management. The Duty of Care

Occupational skin diseases: health and safety precautions (EH 26) Occupational exposure limits (EH 40) Carcinogenicity of mineral oils (EH 58). Metalworking fluids - health precautions (EH 62) Skin cancer caused by oil [MS(B)5] Save your skin! - Occupational Contact Dermatitis [MS(B)6] Dermatitis - cautionary notice [SHW 367] Effects of mineral oil on the skin [SHW 397]

The above publications are available from HMSO or HSE

#### 16: OTHER INFORMATION

MAN

Castrol publication: Talking about Cutting Fluids

Castrol Advice Sheet: The Disposal of Used Metalworking Fluids

Castrol publication: Talking About Health and Safety - Lubricants and Allied Products

The data and advice given apply when the product is sold for the stated application or applications. The product is not sold as suitable for any other application. Use of the product for applications other than as stated in this sheet may give rise to risks not mentioned in this sheet. You should not use the product other than for the stated application or applications without seeking advice from us.

If you have purchased the product for supply to a third party for use at work, it is your duty to take all necessary steps to secure that any person handling or using the product is provided with the information in this sheet.

If you are an employer, it is your duty to tell your employees and others who may be affected of any hazards described in this sheet and of any precautions which should be taken.

Further copies of this Safety Data Sheet may be obtained from Castrol (U.K.) Limited.

Issue No: 01 Date: 01/04/1994 Code: 7040-UK Page: 4 of 4

## NXT 145 ANTI-BACTERIAL SOLUTION

IMPORTANT : The following information is reproduced for reference only. When handling antibacterial solutions from <u>ANY</u> supplier <u>ALWAYS</u> use the data sheets provided with the product.

The solution normally supplied by Wackin Is a nitrite-free, medium to heavy duty machine tool cleaner / steriliser based on a powerful detergent. It has been specially formulated to deal with a wide variety of machine tool contaminants and is easy to use, being added directly to the coolant system whilst still in operation.

- Cleans machine tool systems of a wide range of contaminants including fatty build up in pipelines and floor ducts.
- Kills bacteria and emulsifies floating tramp oil.
- Particularly useful in areas of hard water where greater amounts of insoluble material are likely to occur.
- Minimises maintenance downtime.
- Can be used whilst machines are operating normally.
- Helps keep machine tools in a clean and efficient condition.

#### **APPLICATION**

- 1) An addition of 0.5% 2% of System Cleaner is recommended. The amount added depends on the general condition of the coolant system (1% Is usually adequate).
- 2) Introduce System Cleaner where there is good coolant movement, e.g. in the main coolant tray near to the drain hole position. This ensures complete mixing with the cutling fluid.
- 3) Add System Cleaner on the day before the coolant is programmed to be discarded. The machine should then be operated normally for a minimum of eight hours.
- Following this period of circulation, emply the entire coolant system and machine, and dispose of the coolant in accordance with local authority regulations.

#### TECHNICAL DATA

Alkalinity	Medium (contains a small amount of free caustic)
Density @ 20° C	1.080
pH (1% solution)	11.25
Surface tension (1% solution at 20° C)	34mN/m
Appearance	Blue liquid, moderately

NOTE : Wadkin Plc reserve the right to change the type of anti-bacterial solution supplied to our customers at any time. However, any changes of supply will be accompanied by the necessary safety data sheets.

www.DaltonsWadkin.com

A3

	Castrol (U.K.) Lin The Leading Lubricant Sy SAFETY DATA	nited necialist A SHEET	
1: IDENTI	ICATION OF THE SUBSTANCE / PR ANY / UNDERTAKING	EPARATION AND OF	
Product Nat Application Company: Address: Telephone (	<ul> <li>1e: System Cleaner</li> <li>Machine tool coolant system cleaning</li> <li>Castrol (U.K.) Limited</li> <li>Burmah Castrol House, Pipers Way, Swi</li> <li>24 hours): 0793 512712</li> </ul>	Ce ndoa, Wiltshire, SN3 1RE Fax: 0793 432872	ode: <b>7949</b> -'U
2: COMPO	SITION/INFORMATION ON INGRE	DIENTS	
Compositio	Aqueous solution of alkalis, surfactants and	additives .	· · · · · · · · · · · · · · · · · · ·
Hazardous ]	ngredient(s) Symbol Risk Phr	ases Other Informat	ion %
Sodium hydro 1,3,5-Tris- (2 hexahydrotria	tide C R35 hydroxyethyl)-1,3,5- Xi R22,36/3 ine	CAS No 1310-72 CAS No 4719-04	2 0.5 - 2 4 < 20
Substances) or Refer to Section 3: HAZAR	ELINCS (European List of New Chemical Subsu n 8 for Occupational Exposure Limits. OS IDENTIFICATION	unces) or are exempt.	
Initating to cy	s and skin	IRRITANT	•
4: FIRST A	D MEASURES	<u> </u>	
4: FIRST A Èyes:	ID MEASURES , Inigate immediately with copious quantities of a Obtain medical attention urgently	water for several minutes	·
4: FIRST A Èyes: Skin:	ID MEASURES Irrigate immediately with copious quantities of a Obtain medical attention urgently Wash immediately with soap and water or suital Obtain medical attention if irritation persists	water for several minutes	·
4: FIRST A Èyes: Skin: Inhalation;	ID MEASURES Irrigate immediately with copious quantities of a Obtain medical attention urgently Wash immediately with soap and water or suital Obtain medical attention if irritation persists Remove from exposure	water for several minutes	
4: FIRST A Eyes: Skin: Inhalation: Ingestion:	ID MEASURES Irrigate immediately with copious quantities of a Obtain medical attention urgently Wash immediately with soap and water or suitab Obtain medical attention if irritation persists Remove from exposure Obtain medical attention. Do NOT induce vom	water for several minutes ole skin cleanser iting. Wash out mouth with water	
4: FIRST A Èyes: Skin: Inhalation: Ingestion: 5: FIRE FI	ID MEASURES Irrigate immediately with copious quantities of to Obtain medical attention argently Wash immediately with soap and water or suitable Obtain medical attention if irritation persists Remove from exposure Obtain medical attention. Do NOT induce vom CHTING MEASURES	water for several minutes ole skin cleanser iting. Wash out mouth with water	
4: FIRST A Èyes: Skin: Inhalation: Ingestion: 5: FIRE FI Suitable Ext	ID MEASURES Irrigate immediately with copious quantities of the Obtain medical attention urgently Wash immediately with soap and water or suitable Obtain medical attention if irritation persists Remove from exposure Obtain medical attention. Do NOT induce vom SHTING MEASURES Inguishing Media: Carbon dioxide, pow	water for several minutes ole skin cleanser iting. Wash out mouth with water /der, foam or water	

- -

ì

.

. Special Exposure Hazards: Special Protective Equipment	Nitrogen : Self-cont	compounds since breathing apparatus		
6: ACCIDENTAL RELEAS	E MEASURE	5	•	
Personal Precautions:	Spilt product pro Wear rubber boo	esents a significant slip hazard ots in addition to the recomme	aded protective clothing	-
Environmental Precautions: Decontamination Procedures:	Prevent entry in Soak up with ine means. Clean c	to drains, sewers and water co art absorbent or contain and re ontaminated area with water.	urses move by best available	
7: HANDLING AND STOR	AGE	·		-
Handling: Handle and open cont Storage: Protect from frost. St	niners with care. ore only in hazar	Avoid skin and eye contact. A d labelled containers.	Avoid breathing spray mist.	-
8: EXPOSURE CONTROL	/PERSONAL	PROTECTION	<u></u>	
Occupational Exposure Limit: Substance	x- 8 Hr.TW	A STEL Source	e/Other Information	
Sodium hydroxide Formaldehyde (formed in solution)	 2ppm (M	2mg/m ³ EH40 EL) 2ppm (MEL) EH40		
Engineering Control Measure	S: Local exhaus minimise exp measures.	t ventilation is recommended, osure must take precedence or	Mechanical methods to ver personal protective	
Personal Protective Equipmen	It: Goggles. Im Change conta An eye wash	pervious gloves (eg PVC). Pi infinated clothing immediately station must be available.	and clean before re-use.	
9: PHYSICAL AND CHEM	ICAL PROPE	RTIES		
Physical State:		Liquid	· · · · · · · · · · · · · · · · · · ·	
Colour:		Blue		
Odour:		Sharp		
pH(concentrate):		13.3		
pH(working dilution):		11.3 (1%)		
Boiling Point/Range (°C):		Above 100		
Melting Point/Range (°C):		Below 0	•	
riash Point (closed, °C):		None, as supplied		
Relative Density (at 20°C):	•	Above 1.0		
Water Solubility:		Soluble	• •	
Fat Solubility:		Not determined		
10: STABILITY AND REAC	TIVITY			<b>.</b>
Stability:	Stable, v	vill not polymerise		
Conditions to Avoid:	Tempera	tures (°C) above 60		
				7
Issue INO: 01 Date:	V1/04/1994	COG6: 7949-UK	Page: 2.of4	J
	A3.3		······································	<u></u>

,

7

......

. . . . <u>.</u>

<u>A3</u>

ŗ

-

1

:

A3

. . . . . . . . .

Materials to Avoid:	Strong acids	lite and a support					
11: TOXICOLOGICAL INFO	RMATION						
The following toxicological assessmen Classified as an eye and skin irritant. irritants.	t is based on a knowledge of the toxicity Recommended working concentrations a	of the product's components to not classified as eye or skin					
Health Effects	•						
On Eves: Irritating and may it	iure eve tissue if not removed promotiv	• •					
On Skin: Irritetion	,						
UI OKUG: ITTIEROR By Inhelation. Mict and vanous may cause indication to note and recoinstory tract							
By Investion: May cause initiation	of month throat and directive tract	,					
Chronic: Nose know	or motion, more and motions inst	$\sim$					
Other Note how							
	•	O`					
12: ECOLOGICAL INFORM	ATION						
Environmental Assessment:	May cause significant ecological dama be used and disposed of in accordance in this safety data sheet	e in aquatic systems and must with the recommendations made					
Mobility:	Mobile liquid. Soluble in water.						
Persistence and Degradability:	Inherently biodegradable						
Bioaccomulative Potential:	Not determined	· *					
Ecoloxicity:	Not determined						
12. DISPOSAL CONSIDERA	TIONS						
13: DEFORE CONSIDERA							
Disposal must be in accordance with to	cal and national legislation.						
Unused Product:	)ispose of through an authorised waste c	ontractor to a licensed site					
Used/Contaminated Product:	s for Unused Product bilited product may be separated by che-	mical means or reverse osmosis					
Packaging:	contains hazardous residues, must be dis vaste contractor. May be steam cleaned	posed of through an authorised and recycled.					
14: TRANSPORT INFORMA	FION						
This product is NOT classified as dans	erous for transport						
15: REGULATORY INFORM	ATION						
Hazard Label Datas-							
Named Ingredienter	Sodium hudesside 0 5.2 02	•					
Sumivole).	Yi						
Diek Dhrees	dat						
ліда, Г Шазоў,	untaining to eyes and skin						

A3.4

Safety Phrases:	In case of contact with eyes, rinse immediately with plenty of water and seek medical advice
	After contact with skin, wash immediately with plenty of somp
	wear suitable protective clothing, gloves and eye/lace
EC Directives:	Dangerous Preparations Directive, 88/379/EEC
	Safety Data Sheets Directive, 91/155/EEC
	Framework Waste Directive, 91/156/EEC
Statutory Instruments:	Health & Safety at Work, etc. Act 1974
· ·	<ul> <li>Chemicals (Hazard Information and Packaging) Regs. 1993 (SI 1746)</li> </ul>
	Consumer Protection Act 1987
	Control of Substances Hazardous to Health Regs, 1988 (SI 1657)
	Environmental Protection Act 1990
Codes of Practice:	Classification & labelling of substances dangerous for supply (COP 22)
	waste Management. The Duty of Care
Guidance Notes:	Storage of packaged dangerous substances [CS 17 / HS(G)71]
	Occupational exposure limits (EH 40) +
	Occupational skin diseases: health and safety precamions (EH)
	26)
•	Classification, Packaging & Labelling of Dangerous Substances
	Koga. 1984 [H5(R)22]
•	Deve your skint - uccupational Contact Dematitis [MS(B)6]
	Trainants - wanter of the DVI
The above publications are ava	Hadie from HMSO of HSE
14 OTTEN THEODER ANTON	
10: UTHER INFORMATION	5
Information approved for the election	ration machine and labelling of damagene cuberagene for surviv and
mutumers with white test for end engaging	server's how we are under the stand of an it could be a server of a stand of and

conveyance by road (Third Edition)

Castrol publication: Talking About Health and Safety - Lubricants and Alifed Products

The data and advice given apply when the product is sold for the stated application or applications. The product is not sold as suitable for any other application. Use of the product for applications other than as stated in this sheet may give rise to risks not mentioned in this sheet. You should not use the product other than for the stated application or applications without seeking advice from us.

If you have purchased the product for supply to a third party for use at work, it is your duty to take all necessary steps to secure that any person handling or using the product is provided with the information in this sheet.

If you are an employer, it is your duty to tell your employees and others who may be affected of any hazards described in this sheet and of any precautions which should be taken.

Further copies of this Safety Data Sheet may be obtained from Castrol (U.K.) Limited.

Date: 01/04/1994

Issue No: 01

Code: 7949-UK

Page: 4 of 4

x 460, 4 01 ·

A3.5

A3

# TOOLS AND ACCESSORIES SUPPLIED WITH THE VISAGE

.

<u>Qty</u>	Part No.	Description
5	GW 202	Grinding wheel 230 x 5 x 1 1/4" finish
5	GW 203	Grinding wheel 230 x 5 x 1 1/4" coarse
1	K30 41140	Allen key 2.5 mm A/F
1	K30 41141	Allen key 3 mm A/F
1	K30 41142	Allen key 4 mm A/F
1	K30 41143	Allen key 5 mm A/F
1	K30 41144	Allen key 6 mm A/F
1	K30 41145	Allen key 8 mm A/F
1	K30 41146	Allen key 10 mm A/F
1	K30 73738	D/ended spanner 17 x 19 A/F
1	K30 73782	D/ended spanner 11 x 13 A/F
1	K30 73785	D/ended spanner 24 x 27 A/F
3	NXT 6	Template blank 330 mm long
1 ·	NXT 138	Grinding coolant conc. 5 litres
1	T30 29105 🗸	Crank handle - 13 mm square
1	NNT 122	40 mm dia. Heavy duty arbor (Note: 40 mm diameter
	N.	arbor and locking collars are supplied unless
	N.	specified otherwise).
1	NXT 301	40 mm bore locking collar
1	NXT 302	40 mm bore threaded collar
1	NXT 303	Clamping nut for collar
1	NXT 304	Tommy bar
1	T30 41110	5mm A/F handled Allen key
4	WA 149	Levelling plates
1	NXT 126	"Trued" template (Note : This item is not supplied if
		the machine is fitted with carriage locks).

. ..

۰.

....

# ACCESSORIES FOR VISAGE MACHINES

### WHEELS FOR PROFILE GRINDING

For solid H.S.S. and H.S.S. on iron :-

GW	203	Standard roughing wheel, 5 mm thick, 60 grit
GW	202	Finishing wheel, 5 mm thick, 220 grit
GW	231	8.0mm thick square edge C.B.N. (Borazon) wheel for straight knife grinding

For Tungsten Carbide (T.C.T.) :-

GW	209	4.7 mm thick square edge diamond grinding wheel
GW	210	4.7 mm thick round edge diamond grinding wheel
GW	211	3.0 mm thick round edge diamond grinding wheel
GW	212	3.0 mm thick square edge diamond grinding wheel

Other profiles are available on request.

GW 232 8.0 mm thick square edge diamond wheel for straight knife grinding

Note : All profile grinding wheels are 230 mm diameter and suitable for running at speeds up to 3600 rpm. The bore size is 31.75 mm (1.25").

### PRE MOUNT WHEEL FLANGES

NN

D13 Pre-mount wheel flange unit to allow interchangability whilst retaining the wheel in its originally dressed position. .

.

### PARTS LISTS

**SECTION 6** 

. . . .

STYLUS TURRI	ET ASSEMBLY	(Fig. 6d).	•
ITEM	QTY	PART No.	DESCRIPTION
1	1	K0525472	Brass pad
2	3	K0525473	Brass pad
3	1	K0526265	M10 Stud
4	3	K0526489	M12 dog screw
5	3	K0527111	M12 locknut
6	1	NX 40	Stylus - 4.7mm wide Rad & Square
6	1	NX 110	Stylus – 7.4 mm x 90 deg. point
6	1	NX 111	Stylus – 4.7mm x 30 deg. RH
6	1	NX 112	Stylus - 4,7mm x 30 deg. LH
6	1	NX 131	Stylus - 4.7mm x 45 deg. LH & RH
6	1	NX 133	Stylus - 3.0mm wide Rad & Square
7	6	K0528105	M12 washer
8	1	K5127198	M10 handlever
9.	6	K3009931	'E' retainer
10	1	NN 313	Stylus turret
11	1	NN 315	Turret nut
12	1	K0528113	M10 washer
13	1	K0529102	Pin
14	1.0.	NN 318	Bellows retainer
15	A.	MPG 129	Bellows
16	Nº.	NN 317	Inner belows retainer
17	1	NN 316	Flange
18	1	NN 314	Housing
19	1	K3005165	Bush
20	1	NN 312	Stylus bar
21	1	K3010162	Circlip

#### **HEAVY DUTY ARBORS**

NNT	122	40 mm diameter
NNT	127	45 mm dlameter
NNT	132	50 mm diameter
NNT	137	60 mm diameter
NNT	172	1 1/2" diameter
NNT	177	1 5/8" diameter
NNT	182	1 3/4" diameter
NNT	187	1 13/16" diameter
NNT	192	2 1/8" diameter

Note : Each arbor includes one set of locking collars. Heavy duty arbors have a 37 mm O.D. support bearing. The standard arbor supplied with the machine is NNT 122 unless specified otherwise. ISN2014

### SMALLER ARBOR SIZES

NNT	102 ·	30 mm diameter
NNT	107	35 mm diameter
NNT	112	40 mm diameter
NNT	152	1 1/8" diameter
NNT	167	1 1/4" diameter
NNT	162	1 3/8" diameter

Note : Each arbor includes one set of locking collars. The smaller arbors have a 28 mm O.D. support bearing. If these arbors are used, the following clamp assembly is also required.

NN	C04	Arbor clamp and shell for smaller arbors. (28 mm dia bearing.)
NN	J01	Counter balance for arbor
NXT	140	Dummy cutterhead for grinding a pair of square or scribing cutter cartridges as
		used on the Wadkin SET machine. Mounts direct to standard 40 mm arbor.

#### **CUTTER RESTS**

NN	D14	Carbide tool rest (25mm wide) (fitted as standard on some models)
NN	354	Spare carbide tip for above
NX	454	Hardened steel tool rest (25mm wide)
· · · · · · · · · · · ·		A5 2

A5

A5

------

. .

5

ALTERNATIVE	STYLI	
NX	40	Stylus 4.7mm wide radius and square
NX	110	Stylus 4.7mm wide 90 deg point
NX	111	Stylus 4.7mm wide 30 deg right hand
NX	112	Stylus 4.7mm wide 30 deg left hand
NX	131	Stylus 4.7mm wide 45 deg chamfer right and left hand
NX	133	Stylus 3 mm wide radius and square
NX	E18	Ball bearing stylus. For straight knife grinding of planerheads

#### **TEMPLATES**

-

NXT	126	"Trued" template for straight knife grinding of planerheads
NXT	6	Template steel 330 mm (13") length
тво	650	Template making toolkit

Note : The template making toolkit includes ; toolbox with instructions, template steel, and a selection of hand tools required for template making.

lanea	ior template	thaking.
NXT	5100	Wadkin UltraCare Mirage 2-axis NC template making machine.
NXT	5200	Wadkin UltraCare Outline 3-axis NC template making machine.
		Contact Wadkin UltraCare Limited for full details
	M	

.....

......

A5.3

### COOLANT SYSTEM

	NN	H08	Additional filter tray
--	----	-----	------------------------

- K30 21153 Filtration paper for above
- Semi-synthetic grinding fluid in concentrate form. Supplied in 5 litre containers NXT 138 Note : To be diluted at 50 : 1 ratio
- NXT Anti-bacterial solution concentrate for cleansing coolant system when replacing 145 grinding fluid. Supplied in 5 litre containers

FULL HEALTH AND SAFETY DATA SHEETS ARE AVAILABLE FOR NXT 1387 145 FLUIDS.

#### SETTING AND MEASURING

Т30	49102	Hand held refractometer for measuring concentration of grinding fluid.
		Str.
G AN	ID MEAS	
<u> </u>		
MSS	300	Setting stands, computer aided setting systems, and optical setting and
		measuring systems. Contact Wadkin for full details.

G06 MSS

Set of arbor shells (37 mm dia.). Note : used to adapt existing MSS stands to accept NNT heavy duty type arbors. Mary!

A5

A5.4




-

PARTS LISTS

SECTION 6

Fig. 6e Tempiate slide



.

## PARTS LISTS

**SECTION 6** 

TEMPLATE SLIDE (Fig. 6e)

<u>ITEM</u>	QTY	PART No.	DESCRIPTION
1	1	NN 341	Template mounting plate
2	2	K5127198	M10 handlever
3	2	K0528113	M10 washer
4	1	K0528205	M10 collar
5	1	K0526269	M10 x 60 stud
6	1	K0526265	M10 x 40 stud
7	2	NN 346	Template clamp
8	2	K5127197	M8 handlever
9	2	K0526235	M8 x 35 stud
10	2	K0528103	M8 washer

NOTE: 11

If the plate [11] is moved, access can be gained for lubrication of the adjusting screw and slide shaft. .stin

6.11

I.

PARTS LISTS

**SECTION 6** 

t



## PARTS LISTS

SECTION 6

.. .

TEMPLATE SLIDE (Fig. 6f)

<u>ITEM</u>	<u>QTY</u>	PART No.	DESCRIPTION
1	1	K0530257	Handwheel
2	1	K0528205	Plain collar
3	NOTE:	There are 2 ty	pes of item 3 :-
•	either .	MPG 20	Graduated dial
	or	K0528205	Plain collar
4	1	NN 343	Screw mounting
5	2	K0531302	Bush
6	1	NN 325	Adjucting screw
.7	1	NN 338	Mounting
8	2	K0531589	Bush
9	1	NN 342	Slide shafi
	www	Dations	N.O.

6.13

**SECTION 6** 

